


Service Manual


Air-to-Water Hydromodule + Tank



Indoor Unit
WH-ADC0316M9E81

Outdoor Unit
WH-WXG09ME8
WH-WXG12ME8
WH-WXG16ME8

Destination
Europe



WARNING

This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the products dealt with in this service information by anyone else could result in serious injury or death.

IMPORTANT SAFETY NOTICE

There are special components used in this equipment which are important for safety. These parts are marked by  in the Schematic Diagrams, Circuit Board Diagrams, Exploded Views and Replacement Parts List. It is essential that these critical parts should be replaced with manufacturer's specified parts to prevent shock, fire or other hazards. Do not modify the original design without permission of manufacturer.

PRECAUTION OF LOW TEMPERATURE

In order to avoid frostbite, be assured of no refrigerant leakage during the installation or repairing of refrigerant circuit.

CAUTION

R290 REFRIGERANT

This AIR-TO-WATER HEATPUMP contains and operates with refrigerant R290.
THIS PRODUCT MUST ONLY BE INSTALLED OR SERVICED BY QUALIFIED PERSONNEL
Refer to National, State, Territory and local legislation, regulations, codes, installation & operation manuals, before the installation, maintenance and/or service of this product.

TABLE OF CONTENTS

1. Safety Precautions	4
2. Precaution For Using R290 Refrigerant	7
3. Specifications	12
3.1 WH-ADC0316M9E81 WH-WXG09ME8	12
3.2 WH-ADC0316M9E81 WH-WXG12ME8	16
3.3 WH-ADC0316M9E81 WH-WXG16ME8	20
4. Features	24
5. Location of Controls and Components	25
5.1 Indoor Unit	25
5.2 Outdoor Unit.....	60
6. Dimensions	61
6.1 Indoor Unit	61
6.2 Outdoor Unit.....	62
7. Refrigeration and Water Cycle Diagram	63
8. Block Diagram	64
9. Wiring Connection Diagram	65
9.1 Indoor Unit	65
9.2 Outdoor Unit.....	66
10. Electronic Circuit Diagram	67
10.1 Indoor Unit	67
10.2 Outdoor Unit.....	68
11. Printed Circuit Board	69
11.1 Indoor Unit	69
11.2 Outdoor Unit.....	71
12. Installation Instruction	74
12.1 Indoor Unit	75
12.2 Appendix	87
12.3 Service and Maintenance	118
12.4 Outdoor Unit.....	119
12.5 Appendix	136
12.6 Service and Maintenance	150
13. Installation and Servicing Air-to-Water using R290	151
13.1 About R290 Refrigerant	151
13.2 Characteristics of R290 Refrigerant.....	151
13.3 Refrigerant piping installation • Tools used in services.....	153
13.4 New installation, and Repairing of Refrigerant Cycle System Procedures	157
13.5 Servicing	158
14. Operation and Control	160
14.1 Basic Function	160
14.2 Water Pump	171
14.3 Extra Pump Function (Optional)	175
14.4 Water Circuit Part Safety	177
14.5 Auto Restart Control	177
14.6 Indication Panel	177
14.7 Indoor Back-Up Heater Control (Excluding when Operating in Standalone)	178
14.8 Tank Heater Control (Excluding when Operating in Standalone).....	179
14.9 Base Pan Heater Control (Optional).....	180
14.10 Force Heater Mode	180
14.11 Powerful Operation	182
14.12 Quiet Operation.....	182
14.13 Sterilization Mode	183
14.14 DHW Circulation Pipe Sterilization Operation ..	184
14.15 Outdoor Ambient Thermo OFF Control	184
14.16 Alternative Outdoor Ambient Sensor Control ..	184
14.17 Force DHW mode	185
14.18 SMART DHW mode.....	185
14.19 Efficiency Tank Mode Operation.....	186
14.20 Anti Freeze Control	187
14.21 Solar Operation (Optional).....	190
14.22 Boiler Bivalent Control	191
14.23 External Room Thermostat Control (Optional) ..	193
14.24 Three Ways Valve Control	194
14.25 Two Ways Valve Control.....	194
14.26 Anti-Stick Mode Operation	195
14.27 External OFF/ON Control	196
14.28 External Compressor Switch (Optional PCB) ..	197
14.29 Heat/Cool Switch (Optional PCB).....	197
14.30 SG Ready Control (Optional PCB)	198
14.31 Demand Control (Optional PCB)	200
14.32 Holiday Mode	201
14.33 Dry Concrete	201
14.34 Flow Sensor	201
15. Protection Control	202
15.1 Protection Control for All Operations	202
15.2 Protection Control for Heating Operation.....	204
15.3 Protection Control for Cooling Operation.....	207
16. Servicing Guide	208
16.1 How to take out Front Plate	208
16.2 Test Run	208
16.3 Expansion Vessel (Ⓜ) Pre Pressure Checking ..	208
16.4 How To Adjust Pump Speed.....	209
16.5 How To Unlock Cool Mode	210
16.6 EEPROM Factory Default Data Setup Procedure	211
16.7 Dry Concrete Setup	212
17. Maintenance Guide	214
17.1 Maintenance for Magnetic Water Filter Set	218
18. Troubleshooting Guide	220
18.1 Refrigeration Cycle System	220
18.2 Relationship Between the Condition of the Air-to-Water Heatpump Indoor and Outdoor Units and Electric Current.....	221
18.3 Breakdown Self Diagnosis Function	222

18.4 Error Codes Table	224
18.5 Self-Diagnosis Method	227
19. Disassembly and Assembly Instructions	287
19.1 Indoor Unit	287
19.2 Outdoor Unit	291
20. Technical Data	295
20.1 Operation Characteristics	295
20.2 Heating Capacity Table	307
20.3 Cooling Capacity Table	309
21. Exploded View and Replacement Parts List	310
21.1 Indoor Unit	310
21.2 Outdoor Unit	320

1. Safety Precautions

- Read the following “SAFETY PRECAUTIONS” carefully before installation of Air-To-Water Hydromodule + Tank (here after referred to as “Tank Unit”).
- Electrical works and water installation works must be done by licensed electrician and licensed water system installer respectively. Be sure to use the correct rating and main circuit for the model to be installed.
- The caution items stated here must be followed because these important contents are related to safety. The meaning of each indication used is as below.
Incorrect installation due to ignorance or negligence of the instructions will cause harm or damage, and the seriousness is classified by the following indications.
- Please leave this installation manual with the unit after installation.

 WARNING	This indication shows the possibility of causing death or serious injury.
 CAUTION	This indication shows the possibility of causing injury or damage to properties only.

The items to be followed are classified by the symbols:

	Symbol with white background denotes item that is PROHIBITED.
 	Symbol with dark background denotes item that must be carried out.

- Carry out test run to confirm that no abnormality occurs after the installation. Then, explain to user the operation, care and maintenance as stated in instructions. Please remind the customer to keep the operating instructions for future reference.
- This appliance is not intended for accessibility by the general public.
- If there is any doubt about the installation procedure or operation, always contact the authorized dealer for advice and information.

 WARNING	
1. Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer. Any unfit method or using incompatible material may cause product damage, burst and serious injury.	
2. Do not install outdoor unit near handrail of veranda. When installing outdoor unit at veranda of high rise building, child may climb up to outdoor unit and cross over the handrail and causing accident.	
3. Do not use unspecified cord, modified cord, joint cord or extension cord for power supply cord. Do not share the single outlet with other electrical appliances. Poor contact, poor insulation or over current will cause electrical shock or fire.	
4. Do not tie up the power supply cord into a bundle by band. Abnormal temperature rise on power supply cord may happen.	
5. Do not insert your fingers or other objects into the unit, high speed rotating fan may cause injury. 	
6. Do not sit or step on the unit, you may fall down accidentally. 	
7. Keep plastic bag (packaging material) away from small children, it may cling to nose and mouth and prevent breathing.	
8. Do not purchase unauthorized electrical parts for installation, service, maintenance and etc.. They might cause electrical shock or fire.	
9. Do not modify the wiring of outdoor unit for installation of other components (i.e. heater, etc). Overloaded wiring or wire connection points may cause electrical shock or fire.	
10. Do not pierce or burn as the appliance is pressurized. Do not expose the appliance to heat, flame, sparks, or other sources of ignition. Else, it may explode and cause injury or death.	
11. Do not add or replace refrigerant other than specified type. It may cause product damage, burst and injury etc.	
12. Do not place containers with liquids on top of the Tank Unit. It may cause Tank Unit damage and/or fire could occurs if they leak or spill onto the Tank Unit.	
13. Do not use joint cable for Tank Unit / Outdoor Unit connection cable. Use specified Tank Unit / Outdoor Unit connection cable, refer to instruction  CONNECT THE CABLE TO THE TANK UNIT and connect tightly for Tank Unit / Outdoor Unit connection. Clamp the cable so that no external force will be acted on the terminal. If connection or fixing is not perfect, it will cause heat up or fire at the connection.	
14. For electrical work, follow the national regulation, legislation and this installation instructions. An independent circuit and single outlet must be used. If electrical circuit capacity is not enough or defect found in the electrical work, it will cause electrical shock or fire.	
15. For electrical work, follow local wiring standard, regulation and this installation instruction. An independent circuit and single outlet must be used. If electrical circuit capacity is not enough or defect found in electrical work, it will cause electrical shock or fire.	
16. For water circuit installation work, follow to relevant European and national regulations (including EN61770) and local plumbing and building regulation codes.	

 **WARNING**

17. Engage authorized dealer or specialist for installation. If installation done by the user is incorrect, it will cause water leakage, electrical shock or fire.	
18. Engage dealer or specialist for installation. If installation done by the user is defective, it will cause water leakage, electrical shock or fire.	
19. • The refrigerant cycle is completed inside the outdoor unit. • Refrigerant piping work is not required. • Pump down operation is not also required.	
20. Install at a strong and firm location which is able to withstand weight of the set. If the strength is not enough or installation is not properly done, the set will drop and cause injury.	
21. This equipment is strongly recommended to be installed with Residual Current Device (RCD) on-site according to the respective national wiring rules or country-specific safety measures in terms of residual current.	
22. For refrigeration system work, install according to this installation instructions strictly. If installation is defective, it will cause water leakage, electrical shock or fire.	
23. Do not use joint cable for outdoor connection cable. Use specified outdoor connection cable, refer to instruction ⑥ CONNECT THE CABLE TO THE OUTDOOR UNIT and connect tightly for outdoor connection. Clamp the cable so that no external force will be acted on the terminal. If connection or fixing is not perfect, it will cause heat up or fire at the connection.	
24. Wire routing must be properly arranged so that control board cover is fixed properly. If control board cover is not fixed perfectly, it will cause fire or electrical shock.	
25. After completion of installation, confirm there is no leakage of refrigerant gas. It may lead to the risk of fire or explosion when the refrigerant contacts with fire.	
26. Ventilate the room if there is refrigerant gas leakage during operation. Extinguish all fire sources if present. It may lead to the risk of fire or explosion when the refrigerant contacts with fire.	
27. Use the attached accessories parts and specified parts for installation. Otherwise, it will cause the set to fall, water leakage, fire or electrical shock.	
28. Only use the supplied or specified installation parts. Else, it may causes unit vibrate, fall, water leakage, electrical shock or fire.	
29. If there is any doubt about the installation procedure or operation, always contact the authorized dealer for advice and information.	
30. Select a location where in case of water leakage, the leakage will not cause damage to other properties.	
31. When installing electrical equipment at wooden building of metal lath or wire lath, in accordance with electrical facility standard, no electrical contact between equipment and building is allowed. Insulator must be installed in between.	
32. Any work carried out on the Tank Unit after removing any panels which is secured by screws, must be carried out under the supervision of authorized dealer and licensed installation contractor.	
33. Any work carried out on the outdoor unit after removing any panels which is secured by screws, must be carried out under the supervision of authorized dealer and licensed installation contractor.	
34. This system is multi supply appliance. All circuits must be disconnected before accessing the unit terminals.	
35. For cold water supply has a backflow regulator, check valve or water meter with check valve, provisions for thermal expansion of water in the hot water system must be provided. Otherwise it will cause water leakage.	
36. The piping installation work must be flushed before Tank Unit is connected to remove contaminants. Contaminants may damage the Tank Unit components.	
37. This installation may be subjected to building regulation approval applicable to respective country that may require to notify the local authority before installation.	
38. The Tank Unit must be shipped and stored in upright condition and dry environment. It may laid on its back when being moved into the building.	
39. Work done to the Tank Unit after remove the front plate cover that secured by screws, must be carried out under the supervision of authorized dealer, licensed installation contractor, skilled person and instructed person.	
40. Be aware that refrigerants may not contain an odour.	
41. This equipment must be properly earthed. Earth line must not be connected to gas pipe, water pipe, earth of lightning rod and telephone. Otherwise, it may cause electrical shock in case of equipment breakdown or insulation breakdown.	
42. This unit must be properly earthed. The electrical earth must not be connected to a gas pipe, water pipe, the earth of lightening rod or a telephone. Otherwise there is a danger of electrical shock in the event of an insulation breakdown or electrical earth fault in the outdoor unit.	

 **CAUTION**

1. Do not install the Tank Unit at place where leakage of flammable gas may occur. In case gas leaks and accumulates at surrounding of the unit, it may cause fire.	
2. Do not install the outdoor unit at place where leakage of flammable gas may occur. In case gas leaks and accumulates at surrounding of the unit, it may cause fire.	
3. Prevent liquid or vapor from entering sumps or sewers since vapor is heavier than air and may form suffocating atmospheres.	
4. Do not release refrigerant during repairing a refrigeration parts. Take care of the liquid refrigerant, it may cause frostbite.	
5. Do not install this appliance in a laundry room or other high humidity location. This condition will cause rust and damage to the unit.	
6. Make sure the insulation of power supply cord does not contact hot part (i.e. water piping) to prevent from insulation failure (melt).	
7. Do not touch the sharp aluminium fin, sharp parts may cause injury. 	
8. Do not apply excessive force to water pipes that may damage the pipes. If water leakage occurs, it will cause flooding and damage to other properties.	
9. Do not transport the Tank Unit with water inside the unit. It may cause damage to the unit.	
10. Carry out drainage piping as mentioned in installation instructions. If drainage is not perfect, water may enter the room and damage the furniture.	
11. Select an installation location which is easy for maintenance. Incorrect installation, service or repair of this Tank Unit may increase the risk of rupture and this may result in loss damage or injury and/or property.	
12. Power supply connection <ul style="list-style-type: none"> • Power supply point should be in easily accessible place for power disconnection in case of emergency. • Comply with local national wiring standard, regulation, and this installation instruction. • Strongly recommended to make permanent connection to a circuit breaker. - Power supply: Use approved 20A 4-poles circuit breaker with a minimum contact gap of 3.0mm. 	
13. Ensure the correct polarity is maintained throughout all wiring. Otherwise, it will cause electrical shock or fire.	
14. After installation, check the water leakage condition in connection area during test run. If leakage occurs, it will cause damage to other properties.	
15. If the Tank Unit not operates for long time, the water inside the Tank Unit should be drained.	
16. Installation work. It may need three or more people to carry out the installation work. The weight of Tank Unit might cause injury if carried by one person.	
17. Installation work. It may need two or more people to carry out the installation work. The weight of outdoor unit might cause injury if carried by one person.	
18. Keep any required ventilation openings clear of obstruction.	
19. Water piping in the occupied space shall be installed in such a way to protect against accidental damage in operation and service.	
20. Precautions shall be taken to avoid excessive vibration or pulsation to water piping.	
21. Protect the water piping from accidental rupture due to moving furniture or reconstruction activities.	
22. • Must ensure the installation of water pipe-work shall be kept to a minimum. Avoid use dented pipe and do not allow acute bending. • Must ensure that water pipe-work shall be protected from physical damage.	

2. Precaution For Using R290 Refrigerant

- Pay careful attention to the following points:

 WARNING	
1.	The mixing of different refrigerants within a system is prohibited. 
2.	Operation, maintenance, repairing and refrigerant recovery should be carried out by trained and certified personnel in the use of flammable refrigerants and as recommended by the manufacturer. Any personnel conducting an operation, servicing or maintenance on a system or associated parts of the equipment should be trained and certified. 
3.	Any part of refrigerating circuit (evaporators, air coolers, AHU, condensers or liquid receivers) or piping should not be located in the proximity of heat sources, open flames, operating gas appliance or an operating electric heater. 
4.	The user/owner or their authorized representative shall regularly check the alarms, mechanical ventilation and detectors, at least once a year, where as required by national regulations, to ensure their correct functioning. 
5.	A logbook shall be maintained. The results of these checks shall be recorded in the logbook. 
6.	In case of ventilations in occupied spaces shall be checked to confirm no obstruction. 
7.	Before a new refrigerating system is put into service, the person responsible for placing the system in operation should ensure that trained and certified operating personnel are instructed on the basis of the instruction manual about the construction, supervision, operation and maintenance of the refrigerating system, as well as the safety measures to be observed, and the properties and handling of the refrigerant used. 
8.	The general requirement of trained and certified personnel are indicated as below: a) Knowledge of legislation, regulations and standards relating to flammable refrigerants; and, b) Detailed knowledge of and skills in handling flammable refrigerants, personal protective equipment, refrigerant leakage prevention, handling of cylinders, charging, leak detection, recovery and disposal; and, c) Able to understand and to apply in practice the requirements in the national legislation, regulations and Standards; and, d) Continuously undergo regular and further training to maintain this expertise. 
9.	Ensure protection devices, refrigerating circuit and fittings are well protected against adverse environmental effects (such as the danger of water collecting and freezing in relief pipes or the accumulation of dirt and debris). 

 CAUTION

Installation (Space)

1.
 - Must comply with national gas regulations, state municipal rules and legislation. Notify relevant authorities in accordance with all applicable regulations.
 - Must ensure mechanical connections be accessible for maintenance purposes.
 - In cases that require mechanical ventilation, ventilation openings shall be kept clear of obstruction.
 - When disposal of the product, do follow to the precautions in #12 and comply with national regulations.
 - Always contact to local municipal offices for proper handling.



Servicing

2-1. Service personnel

- Any qualified person who is involved with working on or breaking into a refrigerant circuit should hold a current valid certificate from an industry-accredited assessment authority, which authorizes their competence to handle refrigerants safely in accordance with an industry recognized assessment specification.
- Servicing shall only be performed as recommended by the equipment manufacturer. Maintenance and repair requiring the assistance of other skilled personnel shall be carried out under the supervision of the person competent in the use of flammable refrigerants.
- Servicing shall be performed only as recommended by the manufacturer.
- The system is inspected, regularly supervised and maintained by a trained and certified service personnel who is employed by the person user or party responsible.
- Ensure refrigerant charge not to leak.

2-2. Work

- Prior to beginning work on systems containing flammable refrigerants, safety checks are necessary to ensure that the risk of ignition is minimised.
For repair to the refrigerating system, the precautions in #2-2 to #2-8 must be followed before conducting work on the system.
- Work shall be undertaken under a controlled procedure so as to minimize the risk of a flammable gas or vapour being present while the work is being performed.
- All maintenance staff and others working in the local area shall be instructed and supervised on the nature of work being carried out.
- Avoid working in confined spaces. Always ensure away from source, at least 2 meter of safety distance, or zoning of free space area of at least 2 meter in radius.
- Wear appropriate protective equipment, including respiratory protection, as conditions warrant.
- Keep all sources of ignition and hot metal surfaces away.

2. 2-3. Checking for presence of refrigerant

- The area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially flammable atmospheres.
- Ensure that the leak detection equipment being used is suitable for use with flammable refrigerants, i.e. non sparking, adequately sealed or intrinsically safe.
- In case of leakage/spillage happened, immediately ventilate area and stay upwind and away from spill/release.
- In case of leakage/spillage happened, do notify persons down wind of the leaking/spill, isolate immediate hazard area and keep unauthorized personnel out.

2-4. Presence of fire extinguisher

- If any hot work is to be conducted on the refrigerating equipment or any associated parts, appropriate fire extinguishing equipment shall be available at hand.
- Have a dry powder or CO₂ fire extinguisher adjacent to the charging area.

2-5. No ignition sources

- No person carrying out work in relation to a refrigerating system shall use any sources of ignition in such a manner that it may lead to the risk of fire or explosion. He/She must not be smoking when carrying out such work.
- All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing and disposal, during which flammable refrigerant can possibly be released to the surrounding space.
- Prior to work taking place, the area around the equipment is to be surveyed to make sure that there are no flammable hazards or ignition risks.
- "No Smoking" signs shall be displayed.

2-6. Ventilated area

- Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work.
- A degree of ventilation shall continue during the period that the work is carried out.
- The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.



 **CAUTION**

<p>2-7. Checks to the refrigerating equipment</p> <ul style="list-style-type: none"> • Where electrical components are being changed, they shall be fit for the purpose and to the correct specification. • At all times the manufacturer's maintenance and service guidelines shall be followed. • If in doubt consult the manufacturer's technical department for assistance. • The following checks shall be applied to installations using flammable refrigerants. <ul style="list-style-type: none"> - The ventilation machinery and outlets are operating adequately and are not obstructed. - If an indirect refrigerating circuit is being used, the secondary circuit shall be checked for the presence of refrigerant. - Marking to the equipment continues to be visible and legible. Markings and signs that are illegible shall be corrected. - Refrigerating pipe or components are installed in a position where they are unlikely to be exposed to any substance which may corrode refrigerant containing components, unless the components are constructed of materials which are inherently resistant to being corroded or are properly protected against being so corroded. <p>2. 2-8. Checks to electrical devices</p> <ul style="list-style-type: none"> • Repair and maintenance to electrical components shall include initial safety checks and component inspection procedures. • Initial safety checks shall include but not limit to:- <ul style="list-style-type: none"> - That capacitors are discharged: this shall be done in a safe manner to avoid possibility of sparking. - That there are no live electrical components and wiring are exposed while charging, recovering or purging the system. - That there is continuity of earth bonding. • At all times the manufacturer's maintenance and service guidelines shall be followed. • If in doubt consult the manufacturer's technical department for assistance. • If a fault exists that could compromise safety, then no electrical supply shall be connected to the circuit until it is satisfactorily dealt with. • If the fault cannot be corrected immediately but it is necessary to continue operation, an adequate temporary solution shall be used. • The owner of the equipment must be informed or reported so all parties are advised thereafter. 	
<p>Repairs to sealed components</p> <ul style="list-style-type: none"> • During repairs to sealed components, all electrical supplies shall be disconnected from the equipment being worked upon prior to any removal of sealed covers, etc. • If it is absolutely necessary to have an electrical supply to equipment during servicing, then a permanently operating form of leak detection shall be located at the most critical point to warn of a potentially hazardous situation. • Particular attention shall be paid to the following to ensure that by working on electrical components, the casing is not altered in such a way that the level of protection is affected. This shall include damage to cables, excessive number of connections, terminals not made to original specification, damage to seals, incorrect fitting of glands, etc. <p>3.</p> <ul style="list-style-type: none"> • Ensure that apparatus is mounted securely. • Ensure that seals or sealing materials have not degraded such that they no longer serve the purpose of preventing the ingress of flammable atmospheres. • Replacement parts shall be in accordance with the manufacturer's specifications. <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p>NOTE: The use of silicon sealant may inhibit the effectiveness of some types of leak detection equipment. Intrinsically safe components do not have to be isolated prior to working on them.</p> </div>	
<p>Repair to intrinsically safe components</p> <ul style="list-style-type: none"> • Do not apply any permanent inductive or capacitance loads to the circuit without ensuring that this will not exceed the permissible voltage and current permitted for the equipment in use. • Intrinsically safe components are the only types that can be worked on while live in the presence of a flammable atmosphere. • The test apparatus shall be at the correct rating. • Replace components only with parts specified by the manufacturer. Unspecified parts by manufacturer may result ignition of refrigerant in the atmosphere from a leak. <p>4.</p>	
<p>Cabling</p> <ul style="list-style-type: none"> • Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges or any other adverse environmental effects. • The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans. <p>5.</p>	
<p>Detection of flammable refrigerants</p> <ul style="list-style-type: none"> • Under no circumstances shall potential sources of ignition be used in the searching or detection of refrigerant leaks. • A halide torch (or any other detector using a naked flame) shall not be used. <p>6.</p>	

 **CAUTION**

The following leak detection methods are deemed acceptable for all refrigerant systems.

- No leaks shall be detected when using detection equipment with a sensitivity of 5 grams per year of refrigerant or better under a pressure of at least 0,25 times the maximum allowable pressure (>0.98MPa, max 3.90MPa). For example, a universal sniffer.
- Electronic leak detectors may be used to detect flammable refrigerants, but the sensitivity may not be adequate, or may need re-calibration.
(Detection equipment shall be calibrated in a refrigerant-free area.)
- 7. • Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant used. 
- Leak detection equipment shall be set at a percentage of the LFL of the refrigerant and shall be calibrated to the refrigerant employed and the appropriate percentage of gas (25 % maximum) is confirmed.
- Leak detection fluids are also suitable for use with most refrigerants, for example, bubble method and fluorescent method agents. The use of detergents containing chlorine shall be avoided as the chlorine may react with the refrigerant and corrode the copper pipe-work.
- If a leak is suspected, all ignition sources shall be removed/extinguished.
- If a leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system. The precautions in #8 must be followed to remove the refrigerant.

Removal and evacuation

- When breaking into the refrigerant circuit to make repairs – or for any other purpose – conventional procedures shall be used.
However, it is important that best practice is followed since flammability is a consideration.
The following procedure shall be adhered to:

• remove refrigerant -> • purge the circuit with inert gas -> • evacuate -> • purge with inert gas ->
• open the circuit by cutting.
Brazing must not be used.

- 8. • The refrigerant charge shall be recovered into the correct recovery cylinders. 
- The system shall be purged with OFN to render the appliance safe. (remark: OFN = oxygen free nitrogen, type of inert gas)
- This process may need to be repeated several times.
- Compressed air or oxygen shall not be used for this task.
- Purging shall be achieved by breaking the vacuum in the system with OFN and continuing to fill until the working pressure is achieved, then venting to atmosphere, and finally pulling down to a vacuum.
- This process shall be repeated until no refrigerant is within the system. (Until the concentration of purge gas is 0.25 LFL or less by the leak detector). $\approx 0.25\text{LFL} = 0.525\text{Vol}\%$
- When the final OFN charge is used, the system shall be vented down to atmospheric pressure to enable work to take place.
- This operation is absolutely vital if brazing operations on the pipe work are to take place.
- Ensure that the outlet for the vacuum pump is not close to any potential ignition sources and there is ventilation available.

Charging procedures

- 9. • In addition to conventional charging procedures, the following requirements shall be followed. 
 - Ensure that contamination of different refrigerants does not occur when using charging equipment.
 - Hoses or lines shall be as short as possible to minimize the amount of refrigerant contained in them.
 - Cylinders shall be kept in an appropriate position according to the instructions.
 - Ensure that the refrigerating system is earthed prior to charging the system with refrigerant.
- Label the system when charging is complete (if not already).
- Extreme care shall be taken not to over fill the refrigerating system.
- Prior to recharging the system it shall be pressure tested with OFN (refer to #8).
- The system shall be leak tested on completion of charging but prior to commissioning.
- A follow up leak test shall be carried out prior to leaving the site.
- Electrostatic charge may accumulate and create a hazardous condition when charging and discharging the refrigerant.
To avoid fire or explosion, dissipate static electricity during transfer by grounding and bonding containers and equipment before charging/discharging.

 CAUTION

Decommissioning

- Before carrying out this procedure, it is essential that the technician is completely familiar with the equipment and all its details.
- It is recommended good practice that all refrigerants are recovered safely.
- Re-use of recovered refrigerant is prohibited.
- It is essential that electrical power is available before the task is commenced.
 - a) Become familiar with the equipment and its operation.
 - b) Isolate system electrically.
 - c) Before attempting the procedure ensure that:

10.

- mechanical handling equipment is available, if required, for handling refrigerant cylinders;
- all personal protective equipment and leak detectors are available and being used correctly;
- the recovery process is supervised at all times by a competent person;
- recovery equipment and cylinders conform to the appropriate standards.



- d) Make sure that cylinder is situated on the scales before recovery takes place.
 - e) Start the recovery machine and operate in accordance with instructions.
 - f) Do not over fill cylinders. (No more than 80 % volume liquid charge).
 - g) Do not exceed the maximum working pressure of the cylinder, even temporarily.
 - h) When the cylinders have been filled correctly and the process completed, make sure that the cylinders and the equipment are removed from site promptly and all isolation valves on the equipment are closed off.
- Electrostatic charge may accumulate and create a hazardous condition when charging or discharging the refrigerant. To avoid fire or explosion, dissipate static electricity during transfer by grounding and bonding containers and equipment before charging/discharging.

Labelling

11.

- Equipment shall be labelled stating that it has been de-commissioned and emptied of refrigerant.
- The label shall be dated and signed.
- Ensure that there are labels on the equipment stating the equipment contains flammable refrigerant.



Recovery

12.

- When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.
- When transferring refrigerant into cylinders, ensure that only appropriate refrigerant recovery cylinders are employed.
- Ensure that the correct number of cylinders for holding the total system charge are available.
- All cylinders to be used are designated for the recovered refrigerant and labelled for that refrigerant (i.e. special cylinders for the recovery of refrigerant).
- Cylinders shall be complete with pressure relief valve and associated shut-off valves in good working order.
- Recovery cylinders are evacuated and, if possible, cooled before recovery occurs.
- The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of flammable refrigerants.
- Make sure the recovery equipment is not a potential ignition source and is suitable for the refrigerant you are using.
- In addition, a set of calibrated weighing scales shall be available and in good working order.
- Hoses shall be complete with leak-free disconnect couplings and in good condition.
- Before using the recovery machine, check that it is in satisfactory working order, has been properly maintained and that any associated electrical components are sealed to prevent ignition in the event of a refrigerant release. Consult manufacturer if in doubt.
- The recovered refrigerant shall be returned to the refrigerant supplier in the correct recovery cylinder, and the relevant Waste Transfer Note arranged.
- Do not mix refrigerants in recovery units and especially not in cylinders.
- If compressors or compressor oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that flammable refrigerant does not remain within the lubricant.
- The evacuation process shall be carried out prior to returning the compressor to the suppliers.
- Only electric heating to the compressor body shall be employed to accelerate this process.
- When oil is drained from a system, it shall be carried out safely.



3. Specifications

3.1 WH-ADC0316M9E81 WH-WXG09ME8

Item		Unit	Outdoor Unit			
Performance Test Condition		EN 14511				
		EN 14825				
Cooling Capacity	Condition (Ambient/Water)	A35W7				
	kW	9.00				
	BTU/h	30700				
Cooling EER	W/W	3.61				
Heating Capacity	Condition (Ambient/Water)	A7W35	A2W35			
	kW	9.00	9.00			
	BTU/h	30700	30700			
Heating COP	W/W	5.23	3.81			
Heating Erp	Low Temperature Application (W35)		Warmer	Average	Colder	
	Application	Climate				
	Predesign	kW	9.0	9.0	9.0	
	Tbiv/TOL	°C	2 / 2	-10 / -10	-22 / -22	
	SCOP/ηs	(W/W) / %	6.33 / 250	5.00 / 197	4.45 / 175	
	Annual Consumption	kWh	1901	3721	4990	
	Class		A+++	A+++	A+++	
	Medium Temperature Application (W55)		Warmer	Average	Colder	
	Application	Climate				
	Predesign	kW	9.0	9.0	9.0	
	Tbiv/TOL	°C	2 / 2	-10 / -10	-22 / -22	
	SCOP/ηs	(W/W) / %	4.40 / 173	3.50 / 137	3.20 / 125	
	Annual Consumption	kWh	2735	5318	6939	
	Class		A+++	A++	A++	
	DHW		Warmer	Average	Colder	
	Application	Climate				
	COP / nwh	(W/W) / %	2.70 / 108	2.60 / 104	1.82 / 73	
	AEC	kWh	476	494	706	
	Noise Level	Condition (Ambient/Water)	A35W7	A7W35	A2W35	
		dB (A)	Cooling: -	Heating: -	Heating: -	
Power Level dB		Cooling: 60***	Heating: 58*** Heating: 52***	Heating: 58*** Heating: 52***		
Air Flow	m ³ /min (ft ³ /min)	Cooling: 97.0 (3426) Heating: 83.0 (2931)				
Refrigeration Control Device		Expansion Valve				
Refrigeration Oil	cm ³	PZ68S (1600)				
Refrigerant	kg (oz)	R290, 1.78 (62.8) (Pre-charged) (-) (Maximum)				
F-GAS	GWP	3				
	CO ₂ eq (ton) (Precharged / Maximum)	0.006 / -				
Dimension	Height	mm (inch)	1520 (59-27/32)			
	Width	mm (inch)	1200 (47-1/4)			
	Depth	mm (inch)	430 (16-59/64)			
Net Weight	kg (lbs)	163 (359)				
Pipe Diameter (Inner)	mm	25				

Item		Unit	Outdoor Unit		
Standard Length		m (ft)	5.0 (16.4)		
Maximum Pipe Length		m (ft)	30.0 (98.4)		
I/D & O/D Height Difference		m (ft)	30.0 (98.4)		
Water Pipe Connector	Indoor	inch	1-1/4		
	Outdoor		1-1/4		
Compressor	Type		Hermetic Motor Compressor (Involute Scroll)		
	Motor Type		Synchronous Electric Motor (6-poles)		
	Rated Output	kW	3.10		
Fan	Type		Propeller Fan		
	Material		PP		
	Motor Type		DC (8-poles)		
	Input Power	kW	-		
	Output Power	W	120 × 2		
	Fan Speed	rpm	Cooling: 510 Heating: 400		
Heat Exchanger	Fin material		Aluminium (Blue Coat)		
	Fin Type		Corrugated Fin		
	Row × Stage × FPI		2 × 58 × 19		
	Size (W × H × L)	mm	44 × 1473.2 × 868.2:902.7		
Hot Water Coil	Type		Brazed Plate		
	No. of Plates		36		
	Size (W × H × L)	mm	76.2 × 524 × 117		
	Water Flow Rate	l/min (m ³ /h)	Cooling: 25.8 (1.5) Heating: 25.8 (1.5)		
Power Source (Phase, Voltage, Cycle)		Ø	Three		
		V	400		
		Hz	50		
Input Power	Condition (Ambient/Water)		A35W7	A7W35	A2W35
	kW		Cooling: 2.49	Heating: 1.72	Heating: 2.36
Maximum Input Power For Heatpump System		kW	8.51		
Outdoor Power Supply : Phase (Ø) / Max. Current (A) / Max. Input Power (W)			3Ø / 12.8 / 8.51k		
Indoor Power Supply : Phase (Ø) / Max. Current (A) / Max. Input Power (W)			3Ø / 13.1 / 9.00k		
Power Supply 3 : Phase (Ø) / Max. Current (A) / Max. Input Power (W)			- / - / -		
Starting Current		A	3.8		
Running Current	Condition (Ambient/Water)		A35W7	A7W35	A2W35
	A		Cooling: 3.8	Heating: 2.6	Heating: 3.6
Maximum Current For Heatpump System		A	12.8		
Power Factor Power factor means total figure of compressor and outdoor fan motor.	Condition (Ambient/Water)		A35W7	A7W35	A2W35
	%		Cooling: 95	Heating: 96	Heating: 95
Power Cord	Number of core		-		
	Length	m (ft)	-		
Thermostat			Electronic Control		
Protection Device			Electronic Control		
Pressure Relief Valve Water Circuit		kPa	Open: 400, Close: 280 and below		

Item		Unit	Outdoor Unit
Operation Range	Outdoor Ambient	°C (min. / max.)	Cooling: 10 / 43 Heating (Tank): -28 / 43 Heating (Circuit): -28 / 35
	Water Outlet	°C (min. / max.)	Cooling: 5 / 20 Heating (Tank): - / 65* ³ , Heating (Circuit): 25 / 55 (Below Ambient -25 °C) * ⁴ Heating (Circuit): 25 / 75 (Above Ambient -15 °C) * ⁴
Internal Pressure Differential		kPa	Cooling: 22.0 Heating: 22.0
Pump	Motor Type		Brushless DC Motor (Sensorless vector control system)
	No. of Speed		Variable speed
	Input Power	W	175
Flow Sensor	Type		Vortex (Piezoelectric sensor)
	Measuring range	l/min	5 ~ 60

Item		Unit	Indoor Unit		
Performance Test Condition			EN 14511		
			EN 14825		
Noise Level	Condition (Ambient/Water)		A35W7	A7W35	A2W35
	dB (A)		Cooling: 22***	Heating: 22***	Heating: 22***
	Power Level dB		Cooling: 35***	Heating: 35***	Heating: 35***
Dimension	Depth	mm (inch)	602 (23-45/64)		
	Width	mm (inch)	599 (23-37/64)		
	Height	mm (inch)	1293 (50-29/32)		
Net Weight		kg (lbs)	77 (170)		
Water Pipe Diameter	Room	mm (inch)	31 (1-1/4)		
	Shower	mm (inch)	19 (3/4)		
Water Drain Hose Inner Diameter		mm (inch)	12.00 (17/36)		
Pressure Release Valve (Tank)		kPa	Open: 800, Close: 640 and below		
Protection Device		A	Earth Leakage Circuit Breaker (25A~40A)		
Expansion Vessel	Volume	l	12		
	MWP	bar	10		
Capacity of Integrated Electric Heater / OLP TEMP		kW / °C	9.00 / 85		
Tank Volume (Spec / Nett)		L	127 / 120		
Max. Tank Water Set Temperature		°C	65		
Tank Coil Surface		m ²	1.8		
Maximum Working Pressure	Heat / Cool	Bar	4.0		
	Tank Circuit	Bar	10.0		
Operating Pressure	Tank Unit	Bar	3.5		
	Expansion Relief Valve	Bar	8.0		
Expansion Vessel Pre-charge Pressure (DHW Circuit)		Bar	3.5		
Pressure Reducing Valve Set Pressure (DHW Circuit)		Bar	3.5		

Item		Unit	Indoor Unit
Pressure Vessel	Material		EN14511
	Volume	L	120
	Design Pressure	Bar	10
Heat Exchanger	Material		EN-1.4521
	Diameter	mm	22
	Thickness	mm	0.65
	Surface Area	m ²	1.3
	Total Length	m	18.5
DHW Tank	Total Corrosion ion (Chloride + Sulphate + Nitric)	mg/L	< 150
	Conductivity @ Water Tank Water Temperature < 60°C	µS/cm	< 1250
	Conductivity @ Water Tank Water Temperature < 65°C	µS/cm	< 1200
	Saturation Index (LSI) @ 20°C		> -4.0 / < 0.4
	PH		6.5 - 8.5

Note:

- In case it is necessary to indicate the air flow volume in (l/s), the value in (m³/min.) shall be multiplied by 16.7 and rounded down the decimal point.
- If the EUROVENT Certified models can be operated under the “extra-low” temperature condition, -7°C DB and -8°C WB temperature with rated voltage 230V shall be used.
- Capacity is measured at outdoor temperature 7°C DB and 6°C WB with controlled water inlet 30°C and water outlet 35°C (EN 14511-2)
- Flowrate indicated are based on nominal capacity adjustment of leaving water temperature (LWT) 35°C and ΔT=5°C.
- EER and COP classification is at 230V only in accordance with EU directive 2003/32/EC.
- *** The sound pressure and sound power level is measured with distance 1.0m from the unit and height at 1.5m. (Test carry out for cooling at ambient 35°C DB and Water Out 7°C, heating at ambient 7°C DB / 6°C WB and water out 55°C)
- **** The sound power level is measured with accordance to EN12102 under conditions of the EN14825.
- *** The sound power level is measured with accordance to EN12102 under full load conditions. (Test carry out for cooling at ambient 35°C DB and Water Out 7°C, heating at ambient 7°C DB / 6°C WB and water out 55°C)
- *3 When outdoor ambient is under -15°C, only the backup heater operate above 55°C. (Outdoor unit don't have backup heater.)
- *4 Between outdoor ambient -15°C and -25°C, the water outlet temperature gradually decreases from 75°C to 55°C.

3.2 WH-ADC0316M9E81 WH-WXG12ME8

Item		Unit	Outdoor Unit			
Performance Test Condition		EN 14511				
		EN 14825				
Cooling Capacity	Condition (Ambient/Water)	A35W7				
	kW	9.00				
	BTU/h	30700				
Cooling EER	W/W	3.61				
Heating Capacity	Condition (Ambient/Water)	A7W35	A2W35			
	kW	12.00	12.00			
	BTU/h	40900	40900			
Heating COP	W/W	5.06	3.54			
Heating Erp	Low Temperature Application (W35)		Warmer	Average	Colder	
	Application	Climate				
	Predesign	kW	12.0	12.0	12.0	
	Tbiv/TOL	°C	2 / 2	-10 / -10	-22 / -22	
	SCOP/ηs	(W/W) / %	6.20 / 245	4.73 / 186	4.38 / 172	
	Annual Consumption	kWh	2586	5244	6758	
	Class		A+++	A+++	A++	
	Medium Temperature Application (W55)		Warmer	Average	Colder	
	Application	Climate				
	Predesign	kW	12.0	12.0	10.0	
	Tbiv/TOL	°C	2 / 2	-10 / -10	-22 / -22	
	SCOP/ηs	(W/W) / %	4.40 / 173	3.65 / 143	3.25 / 127	
	Annual Consumption	kWh	3647	6792	9111	
	Class		A+++	A++	A++	
	DHW		Warmer	Average	Colder	
	Application	Climate				
	COP / nwh	(W/W) / %	2.70 / 108	2.60 / 104	1.82 / 73	
	AEC	kWh	476	494	706	
	Noise Level	Condition (Ambient/Water)	A35W7	A7W35	A2W35	
		dB (A)	Cooling: -	Heating: -	Heating: -	
Power Level dB		Cooling: 60***	Heating: 59*** Heating: 53***	Heating: 59*** Heating: 53***		
Air Flow	m³/min (ft³/min)	Cooling: 97.0 (3426) Heating: 92.0 (3249)				
Refrigeration Control Device	Expansion Valve					
Refrigeration Oil	cm³	PZ68S (1600)				
Refrigerant	kg (oz)	R290, 1.78 (62.8) (Pre-charged) (-) (Maximum)				
F-GAS	GWP		3			
	CO ₂ eq (ton) (Precharged / Maximum)		0.006 / -			
Dimension	Height	mm (inch)	1520 (59-27/32)			
	Width	mm (inch)	1200 (47-1/4)			
	Depth	mm (inch)	430 (16-59/64)			
Net Weight	kg (lbs)	163 (359)				
Pipe Diameter (Inner)	mm	32				

Item		Unit	Outdoor Unit		
Standard Length		m (ft)	5.0 (16.4)		
Maximum Pipe Length		m (ft)	30.0 (98.4)		
I/D & O/D Height Difference		m (ft)	30.0 (98.4)		
Water Pipe Connector	Indoor	inch	1-1/4		
	Outdoor		1-1/4		
Compressor	Type		Hermetic Motor Compressor (Involute Scroll)		
	Motor Type		Synchronous Electric Motor (6-poles)		
	Rated Output	kW	3.10		
Fan	Type		Propeller Fan		
	Material		PP		
	Motor Type		DC (8-poles)		
	Input Power	kW	-		
	Output Power	W	120 × 2		
	Fan Speed	rpm	Cooling: 510 Heating: 420		
Heat Exchanger	Fin material		Aluminium (Blue Coat)		
	Fin Type		Corrugated Fin		
	Row × Stage × FPI		2 × 58 × 19		
	Size (W × H × L)	mm	44 × 1473.2 × 868.2:902.7		
Hot Water Coil	Type		Brazed Plate		
	No. of Plates		36		
	Size (W × H × L)	mm	76.2 × 524 × 117		
	Water Flow Rate	l/min (m ³ /h)	Cooling: 25.8 (1.5) Heating: 34.4 (2.1)		
Power Source (Phase, Voltage, Cycle)		Ø	Three		
		V	400		
		Hz	50		
Input Power	Condition (Ambient/Water)		A35W7	A7W35	A2W35
	kW		Cooling: 2.49	Heating: 2.37	Heating: 3.39
Maximum Input Power For Heatpump System		kW	9.84		
Outdoor Power Supply : Phase (Ø) / Max. Current (A) / Max. Input Power (W)			3Ø / 14.8 / 9.84k		
Indoor Power Supply : Phase (Ø) / Max. Current (A) / Max. Input Power (W)			3Ø / 13.1 / 9.00k		
Power Supply 3 : Phase (Ø) / Max. Current (A) / Max. Input Power (W)			- / - / -		
Starting Current		A	3.8		
Running Current	Condition (Ambient/Water)		A35W7	A7W35	A2W35
	A		Cooling: 3.8	Heating: 3.6	Heating: 5.2
Maximum Current For Heatpump System		A	14.8		
Power Factor Power factor means total figure of compressor and outdoor fan motor.	Condition (Ambient/Water)		A35W7	A7W35	A2W35
	%		Cooling: 95	Heating: 96	Heating: 95
Power Cord	Number of core		-		
	Length	m (ft)	-		
Thermostat			Electronic Control		
Protection Device			Electronic Control		
Pressure Relief Valve Water Circuit		kPa	Open: 400, Close: 280 and below		

Item		Unit	Outdoor Unit
Operation Range	Outdoor Ambient	°C (min. / max.)	Cooling: 10 / 43 Heating (Tank): -28 / 43 Heating (Circuit): -28 / 35
	Water Outlet	°C (min. / max.)	Cooling: 5 / 20 Heating (Tank): - / 65* ³ , Heating (Circuit): 25 / 55 (Below Ambient -25 °C) * ⁴ Heating (Circuit): 25 / 75 (Above Ambient -15 °C) * ⁴
Internal Pressure Differential		kPa	Cooling: 22.0 Heating: 39.0
Pump	Motor Type		Brushless DC Motor (Sensorless vector control system)
	No. of Speed		Variable Speed
	Input Power	W	175
Flow Sensor	Type		Vortex (Piezoelectric sensor)
	Measuring range	l/min	5 ~ 60

Item		Unit	Indoor Unit		
Performance Test Condition		EN 14511			
		EN 14825			
Noise Level	Condition (Ambient/Water)		A35W7	A7W35	A2W35
	dB (A)		Cooling: 22***	Heating: 22***	Heating: 22***
	Power Level dB		Cooling: 35***	Heating: 35***	Heating: 35***
Dimension	Depth	mm (inch)	602 (23-45/64)		
	Width	mm (inch)	599 (23-37/64)		
	Height	mm (inch)	1293 (50-29/32)		
Net Weight		kg (lbs)	77 (170)		
Water Pipe Diameter	Room	mm (inch)	31 (1-1/4)		
	Shower	mm (inch)	19 (3/4)		
Water Drain Hose Inner Diameter		mm (inch)	12.00 (17/36)		
Pressure Release Valve (Tank)		kPa	Open: 800, Close: 640 and below		
Protection Device		A	Earth Leakage Circuit Breaker (25A~40A)		
Expansion Vessel	Volume	l	12		
	MWP	bar	10		
Capacity of Integrated Electric Heater / OLP TEMP		kW / °C	9.00 / 85		
Tank Volume (Spec / Nett)		L	127 / 120		
Max. Tank Water Set Temperature		°C	65		
Tank Coil Surface		m ²	1.8		
Maximum Working Pressure	Heat / Cool	Bar	4.0		
	Tank Circuit	Bar	10.0		
Operating Pressure	Tank Unit	Bar	3.5		
	Expansion Relief Valve	Bar	8.0		
Expansion Vessel Pre-charge Pressure (DHW Circuit)		Bar	3.5		
Pressure Reducing Valve Set Pressure (DHW Circuit)		Bar	3.5		

Item		Unit	Indoor Unit
Pressure Vessel	Material		EN14511
	Volume	L	120
	Design Pressure	Bar	10
Heat Exchanger	Material		EN-1.4521
	Diameter	mm	22
	Thickness	mm	0.65
	Surface Area	m ²	1.3
	Total Length	m	18.5
DHW Tank	Total Corrosion ion (Chloride + Sulphate + Nitric)	mg/L	< 150
	Conductivity @ Water Tank Water Temperature < 60°C	µS/cm	< 1250
	Conductivity @ Water Tank Water Temperature < 65°C	µS/cm	< 1200
	Saturation Index (LSI) @ 20°C		> -4.0 / < 0.4
	PH		6.5 - 8.5

Note:

- In case it is necessary to indicate the air flow volume in (l/s), the value in (m³/min.) shall be multiplied by 16.7 and rounded down the decimal point.
- If the EUROVENT Certified models can be operated under the “extra-low” temperature condition, -7°C DB and -8°C WB temperature with rated voltage 230V shall be used.
- Capacity is measured at outdoor temperature 7°C DB and 6°C WB with controlled water inlet 30°C and water outlet 35°C (EN 14511-2)
- Flowrate indicated are based on nominal capacity adjustment of leaving water temperature (LWT) 35°C and ΔT=5°C.
- EER and COP classification is at 230V only in accordance with EU directive 2003/32/EC.
- *** The sound pressure and sound power level is measured with distance 1.0m from the unit and height at 1.5m. (Test carry out for cooling at ambient 35°C DB and Water Out 7°C, heating at ambient 7°C DB / 6°C WB and water out 55°C)
- **** The sound power level is measured with accordance to EN12102 under conditions of the EN14825.
- *** The sound power level is measured with accordance to EN12102 under full load conditions. (Test carry out for cooling at ambient 35°C DB and Water Out 7°C, heating at ambient 7°C DB / 6°C WB and water out 55°C)
- *3 When outdoor ambient is under -15°C, only the backup heater operate above 55°C. (Outdoor unit don't have backup heater.)
- *4 Between outdoor ambient -15°C and -25°C, the water outlet temperature gradually decreases from 75°C to 55°C.

3.3 WH-ADC0316M9E81 WH-WXG16ME8

Item		Unit	Outdoor Unit		
Performance Test Condition		EN 14511			
		EN 14825			
Cooling Capacity	Condition (Ambient/Water)	A35W7			
	kW	9.00			
	BTU/h	30700			
Cooling EER	W/W	3.61			
Heating Capacity	Condition (Ambient/Water)	A7W35	A2W35		
	kW	16.00	16.00		
	BTU/h	54600	54600		
Heating COP	W/W	4.89	3.30		
Heating Erp	Low Temperature Application (W35)		Warmer	Average	Colder
	Application	Climate			
	Predesign	kW	16.0	16.0	16.0
	Tbiv/TOL	°C	2 / 2	-10 / -10	-22 / -22
	SCOP/ηs	(W/W) / %	6.08 / 240	4.75 / 187	4.33 / 170
	Annual Consumption	kWh	3517	6966	9101
	Class		A+++	A+++	A++
	Medium Temperature Application (W55)		Warmer	Average	Colder
	Application	Climate			
	Predesign	kW	16.0	16.0	16.0
	Tbiv/TOL	°C	2 / 2	-10 / -10	-22 / -22
	SCOP/ηs	(W/W) / %	4.45 / 175	3.70 / 145	3.40 / 133
	Annual Consumption	kWh	4801	8935	11613
	Class		A+++	A++	A++
	DHW		Warmer	Average	Colder
	Application	Climate			
	COP / nwh	(W/W) / %	2.51 / 101	2.40 / 96	1.75 / 70
	AEC	kWh	512	536	734
Noise Level	Condition (Ambient/Water)	A35W7	A7W35	A2W35	
	dB (A)	Cooling: -	Heating: -	Heating: -	
	Power Level dB	Cooling: 60***	Heating: 62*** Heating: 57***	Heating: 62*** Heating: 57***	
Air Flow	m³/min (ft³/min)	Cooling: 97.0 (3426) Heating: 108.0 (3814)			
Refrigeration Control Device		Expansion Valve			
Refrigeration Oil	cm³	PZ68S (1600)			
Refrigerant	kg (oz)	R290, 1.77 (62.4) (Pre-charged) (-) (Maximum)			
F-GAS	GWP	3			
	CO ₂ eq (ton) (Precharged / Maximum)	0.006 / -			
Dimension	Height	mm (inch)	1520 (59-27/32)		
	Width	mm (inch)	1200 (47-1/4)		
	Depth	mm (inch)	430 (16-59/64)		
Net Weight	kg (lbs)	165 (364)			
Pipe Diameter (Inner)	mm	32			

Item		Unit	Outdoor Unit		
Standard Length		m (ft)	5.0 (16.4)		
Maximum Pipe Length		m (ft)	30.0 (98.4)		
I/D & O/D Height Difference		m (ft)	30.0 (98.4)		
Water Pipe Connector	Indoor	inch	1-1/4		
	Outdoor		1-1/4		
Compressor	Type		Hermetic Motor Compressor (Involute Scroll)		
	Motor Type		Synchronous Electric Motor (6-poles)		
	Rated Output	kW	3.10		
Fan	Type		Propeller Fan		
	Material		PP		
	Motor Type		DC (8-poles)		
	Input Power	kW	-		
	Output Power	W	120 × 2		
	Fan Speed	rpm	Cooling: 510 Heating: 480		
Heat Exchanger	Fin material		Aluminium (Blue Coat)		
	Fin Type		Corrugated Fin		
	Row × Stage × FPI		2 × 58 × 19		
	Size (W × H × L)	mm	44 × 1473.2 × 868.2:902.7		
Hot Water Coil	Type		Brazed Plate		
	No. of Plates		44		
	Size (W × H × L)	mm	72.0 × 535 × 120.5		
	Water Flow Rate	l/min (m ³ /h)	Cooling: 25.8 (1.5) Heating: 45.9 (2.8)		
Power Source (Phase, Voltage, Cycle)		Ø	Three		
		V	400		
		Hz	50		
Input Power	Condition (Ambient/Water)		A35W7	A7W35	A2W35
	kW		Cooling: 2.49	Heating: 3.27	Heating: 4.85
Maximum Input Power For Heatpump System		kW	12.80		
Outdoor Power Supply : Phase (Ø) / Max. Current (A) / Max. Input Power (W)			3Ø / 19.0 / 12.8k		
Indoor Power Supply : Phase (Ø) / Max. Current (A) / Max. Input Power (W)			3Ø / 13.1 / 9.00k		
Power Supply 3 : Phase (Ø) / Max. Current (A) / Max. Input Power (W)			- / - / -		
Starting Current		A	4.9		
Running Current	Condition (Ambient/Water)		A35W7	A7W35	A2W35
	A		Cooling: 3.8	Heating: 4.9	Heating: 7.3
Maximum Current For Heatpump System		A	19.0		
Power Factor Power factor means total figure of compressor and outdoor fan motor.	Condition (Ambient/Water)		A35W7	A7W35	A2W35
	%		Cooling: 95	Heating: 97	Heating: 96
Power Cord	Number of core		-		
	Length	m (ft)	-		
Thermostat			Electronic Control		
Protection Device			Electronic Control		
Pressure Relief Valve Water Circuit		kPa	Open: 400, Close: 280 and below		

Item		Unit	Outdoor Unit
Operation Range	Outdoor Ambient	°C (min. / max.)	Cooling: 10 / 43 Heating (Tank): -28 / 43 Heating (Circuit): -28 / 35
	Water Outlet	°C (min. / max.)	Cooling: 5 / 20 Heating (Tank): - / 65* ³ , Heating (Circuit): 25 / 55 (Below Ambient -25 °C) * ⁴ Heating (Circuit): 25 / 75 (Above Ambient -15 °C) * ⁴
Internal Pressure Differential		kPa	Cooling: 22.0 Heating: 63.0
Pump	Motor Type		Brushless DC Motor (Sensorless vector control system)
	No. of Speed		Variable Speed
	Input Power	W	175
Flow Sensor	Type		Vortex (Piezoelectric sensor)
	Measuring range	l/min	5 ~ 60

Item		Unit	Indoor Unit		
Performance Test Condition			EN 14511		
			EN 14825		
Noise Level	Condition (Ambient/Water)		A35W7	A7W35	A2W35
	dB (A)		Cooling: 22***	Heating: 22***	Heating: 22***
	Power Level dB		Cooling: 35***	Heating: 35***	Heating: 35***
Dimension	Depth	mm (inch)	602 (23-45/64)		
	Width	mm (inch)	599 (23-37/64)		
	Height	mm (inch)	1293 (50-29/32)		
Net Weight		kg (lbs)	77 (170)		
Water Pipe Diameter	Room	mm (inch)	31 (1-1/4)		
	Shower	mm (inch)	19 (3/4)		
Water Drain Hose Inner Diameter		mm (inch)	12.00 (17/36)		
Pressure Release Valve (Tank)		kPa	Open: 800, Close: 640 and below		
Protection Device		A	Earth Leakage Circuit Breaker (25A~40A)		
Expansion Vessel	Volume	l	12		
	MWP	bar	10		
Capacity of Integrated Electric Heater / OLP TEMP		kW / °C	9.00 / 85		
Tank Volume (Spec / Nett)		L	127 / 120		
Max. Tank Water Set Temperature		°C	65		
Tank Coil Surface		m ²	1.8		
Maximum Working Pressure	Heat / Cool	Bar	4.0		
	Tank Circuit	Bar	10.0		
Operating Pressure	Tank Unit	Bar	3.5		
	Expansion Relief Valve	Bar	8.0		
Expansion Vessel Pre-charge Pressure (DHW Circuit)		Bar	3.5		
Pressure Reducing Valve Set Pressure (DHW Circuit)		Bar	3.5		

Item		Unit	Indoor Unit
Pressure Vessel	Material		EN14511
	Volume	L	120
	Design Pressure	Bar	10
Heat Exchanger	Material		EN-1.4521
	Diameter	mm	22
	Thickness	mm	0.65
	Surface Area	m ²	1.3
	Total Length	m	18.5
DHW Tank	Total Corrosion ion (Chloride + Sulphate + Nitric)	mg/L	< 150
	Conductivity @ Water Tank Water Temperature < 60°C	µS/cm	< 1250
	Conductivity @ Water Tank Water Temperature < 65°C	µS/cm	< 1200
	Saturation Index (LSI) @ 20°C		> -4.0 / < 0.4
	PH		6.5 - 8.5

Note:

- In case it is necessary to indicate the air flow volume in (l/s), the value in (m³/min.) shall be multiplied by 16.7 and rounded down the decimal point.
- If the EUROVENT Certified models can be operated under the “extra-low” temperature condition, -7°C DB and -8°C WB temperature with rated voltage 230V shall be used.
- Capacity is measured at outdoor temperature 7°C DB and 6°C WB with controlled water inlet 30°C and water outlet 35°C (EN 14511-2)
- Flowrate indicated are based on nominal capacity adjustment of leaving water temperature (LWT) 35°C and ΔT=5°C.
- EER and COP classification is at 230V only in accordance with EU directive 2003/32/EC.
- *** The sound pressure and sound power level is measured with distance 1.0m from the unit and height at 1.5m. (Test carry out for cooling at ambient 35°C DB and Water Out 7°C, heating at ambient 7°C DB / 6°C WB and water out 55°C)
- **** The sound power level is measured with accordance to EN12102 under conditions of the EN14825.
- *** The sound power level is measured with accordance to EN12102 under full load conditions. (Test carry out for cooling at ambient 35°C DB and Water Out 7°C, heating at ambient 7°C DB / 6°C WB and water out 55°C)
- *3 When outdoor ambient is under -15°C, only the backup heater operate above 55°C. (Outdoor unit don't have backup heater.)
- *4 Between outdoor ambient -15°C and -25°C, the water outlet temperature gradually decreases from 75°C to 55°C.

4. Features

- **Inverter Technology**
 - Energy saving
- **High Efficiency**
- **Long Installation Piping**
 - Long piping up to 30 meter
- **A-class energy efficiency pump**
 - Water pump speed can be set by selection at control panel
- **Improved deice cycle**
- **Protection Feature**
 - Random auto restart after power failure for safety restart operation
 - Gas leakage protection
 - Prevent compressor reverse cycle
 - Inner protector to protect compressor
- **Serviceability Feature**
 - Breakdown Self Diagnosis function
 - System Status Check Buttons for servicing purpose
 - System Pumpdown Button for servicing purpose
 - Front maintenance design for outdoor unit

5. Location of Controls and Components

5.1 Indoor Unit

5.1.1 Remote Controller Buttons and Display


The LCD display as shown in this manual are for instructional purpose only, and may differ from the actual unit.

Buttons / Indicator	
①	Quick Menu button
②	Back button Returns to the previous screen
③	LCD Display (Actual - Dark background with white icons)
④	Main Menu button For function setup
⑤	ON/OFF button Starts/Stops operation
⑥	Operation indicator Illuminates during operation, blinks during alarm.

When the backlight is off, press any button to turn it on.


(Do not press button ⑤)

The time until the backlight turns off can be changed in the Menu (Personal setup)



Cross key buttons


Selects an item.




Enter button

Fixes the selected content.

 Press centre



 No glove




 No pen



Display


(A) Mode selection



(B) Operation icons

The status of operation is displayed.

Icon will not display (under operation OFF screen) whenever operation is OFF except weekly timer.



(C) Temperature of each zone


The zone 2 will shown in LCD display if is connected with Optional PCB.

(D) Time and day

(E) Water Tank temperature (with electric anode operation icon)

(F) Outdoor temperature

(G) Sensor type/Set temperature type icons



(H) Water pressure (bar)

*1 The system is locked to operate without COOL mode. It can be unlocked only by authorised installers or our authorised service partners.
 *2 Only displayed when COOL mode is unlocked (This means when COOL mode is available).
 *3 Only displayed when Tank connection is Yes.

5.1.2 Initialization

Before starting to install the various menu settings, please initiate the Remote Controller by selecting the language of operation and installing the date and time correctly. When power is turned on for the first time, it becomes the setting screen automatically. It can also be set from personal setting of the menu.

Selecting the language

Wait while the display is initializing.
When initializing screen ends, it turns to normal screen.
When any button is pressed, language setting screen appears.

- ① Scroll with ∇ and \blacktriangle to select the language.
- ② Press \leftarrow to confirm the selection.









Setting the clock

- ① Select with ∇ or \blacktriangle how to display the time, either 24h or am/pm format (for example, 15:00 or 3:00pm).
- ② Press \leftarrow to confirm the selection.
- ③ Use ∇ and \blacktriangle to select year, month, day, hour and minutes. (Select and move with \blacktriangleright and press \leftarrow to confirm.)
- ④ Once the time is set, time and day will appear on the display even if the Remote Controller is turned OFF.

Checking the front grilles

Final precaution step to check and confirm whether outdoor front grille is fixed before operating the unit for safety purpose. Select Yes if outdoor front grille is already fixed. Then it will proceed to main screen. Select No if outdoor front grille is not yet fixed. A caution message will pop up to remind on the installation.

*The display will not appear once you set it.




5.1.3 Quick Menu

After the initial settings have been completed, you can select a quick menu from the following options and edit the setting.



① Press to display the quick menu.



② Use to select menu.

③ Press to turn on/off the select menu.

Quick Menu

Force DHW	Powerful	Quiet	Force Heater
Weekly Timer	Force Defrost	Error Reset	R/C Lock

Select
 ON/OFF

Select each setting and confirm the setting according to the instructions displayed at the bottom of the screen. (The icons refer to each selection key.)

To return to the Main Screen,

Press or .

*1 Only displayed when Tank connection is Yes.


*2 It is not displayed when the outdoor unit is used alone. When the indoor unit has the heater, it is displayed even if set not to operate the heater.

5.1.4 How to Use the Quick Menu

Force DHW

Select this icon to turn the Tank DHW on or off.

Press  to confirm your selection.



Note:


- Force DHW is disabled when Force Heater is turned on.
 - When Force DHW is turned off, operation & mode should change back to the previous memorized status.
-

Powerful

Select this icon to operate the heating system powerfully.

Press  to confirm your selection.

(The powerful operation starts approximately 1 minute after  is pressed.)



Note:


- Powerful is disabled when operation is turned OFF.

Quiet

Select this icon to operate quietly.

Press  to confirm your selection.

(The quiet operation starts approximately 1 minute after  is pressed.)



Do you want to edit Quiet timer pattern?

Yes No

Pattern	Time	Level
1	6:00 am	2
2	8:00 pm	1
3	10:00 pm	0

Edit Delete

12 : 00 pm



Select "Yes".

- Select "Yes" using < > buttons.

Select pattern "1" ~ "6".

Select "Edit".

- If you select "Delete", the timer setting of the selected pattern will be deleted.

Set the hour and minutes.

Select the level of Quiet.

Set time is overlapped!

[⇒]Close

Note:


- If the time overlaps with another pattern, "Set time is overlapped!" will appear on the screen.

Force Heater

Select to force the Heater on.

Press  to confirm your selection.

(The Force Heater mode starts approximately 1 minute after  is pressed.)



Note:

- Force Heater is disabled whenever operation is already on and "Disabled due to operation ON!" will be displayed.
- It is not displayed when the outdoor unit is used alone, and when the heater is set to OFF even if the indoor unit is connected.

Disabled due to
operation ON!


Close

Force Defrost

Select to defrost the frozen pipes.

Press  to confirm your selection.

(When the mode is accepted, below screen will be displayed.)




Error Reset

Select to restore the previous settings when error has occurred.

Press  to confirm your selection.

(When the mode has been accepted, below screen will be displayed.)




- Make sure all units are turned off before selecting this mode which restores the whole system to the previous settings.

R/C Lock

Select to lock the Remote Controller.

Press  to confirm your selection.

(When the mode has been accepted, below screen will be displayed.)



Select "Yes".

(The Main Screen will be locked.)

- If "No" is selected, the screen will return to the Main Screen.

To unlock the Remote Controller

Press any key.

(When the mode has been accepted, below screen will be displayed.)



Enter any 4 digits of number (if the number is correct, the screen will be unlocked).


To reset forgotten password (under operation OFF screen)

Press ,  and  continuously for 5 seconds.

(When the mode has been accepted, below screen will be displayed.)



Select "Reset".



(The screen will be off after 3 seconds.)

5.1.5 Menus (For User)


Select menus and determine settings according to the system available in the household. All initial settings must be done by an authorised dealer or a specialist. It is recommended that all alterations of the initial settings are also done by an authorised dealer or a specialist.

- After initial installation, you may manually adjust the settings.
- The initial setting remains active until the user changes it.
- The Remote Controller can be used for multiple installations.
- Ensure the operation indicator is OFF before setting.
- The system may not work properly if set wrongly. Please consult an authorised dealer/specialist.

To display <Main Menu>: 

To select menu:    

To confirm the selected content: 




Menu	Default Setting	Setting Options / Display
1 Function setup		
1.1 > Weekly timer		
Once the weekly timer is set up, User can edit from Quick Menu. To set up to 6 patterns of operation on a daily basis. • Disabled if Heat-Cool SW is select "Yes" or if Force Heater is on.	Timer setup Select day of the week and set the patterns needed (Time / Operation ON/OFF / Mode) Timer copy Select day of the week	Weekly timer 10:34am, Mon Sun Mon Tue Wed Thu Fri Sat 1. 8:00am ON  40°C 2. 12:00pm ON  24/28°C 40°C 3. 1:00pm ON  12/10°C ⌂Day ↕Pattern [↔]Edit
1.2 > Holiday timer		
To save energy, a holiday period may be set to either turn OFF the system or lower the temperature during the period. • Weekly timer setting may be temporarily disabled during Holiday timer setting but it will be restored once the Holiday timer is completed.	OFF ON ↑ OFF > ON Holiday start and end. Date and time OFF or lowered temperature	Holiday: End 10:34am, Mon Year/Month/Day Hour : Min 2024 / 01 / 01 10 : 34 am ⌂Select [↔]Confirm
1.3 > Quiet timer		
To operate quietly during the preset period. 6 patterns may be set. Level 0 means the mode is off.	Time to start Quiet : Date and time Level of quietness: 0 ~ 3	Quiet 10:34am, Mon Pattern Time Level 1 8:00am 0 2 5:00pm 1 3 11:00pm 3 ↕Select [↔]Edit

Menu	Default Setting	Setting Options / Display
1.4 > Quiet priority		
<ul style="list-style-type: none"> To select priority during Quiet mode between Sound and Capacity. If Sound priority is selected, unit will operate in quiet condition only. If Capacity priority is selected, unit will operate in quiet condition but it will prioritize on providing required capacity at the same time. 	Sound	<div style="text-align: center;"> <div style="border: 1px solid black; background-color: black; color: white; padding: 2px; display: inline-block;">Sound</div> ▼ <div style="border: 1px solid black; background-color: black; color: white; padding: 2px; display: inline-block;">Capacity</div> </div>
1.5 > *1 Room heater		
To set the room heater ON or OFF.	OFF	<div style="text-align: center;"> ON <div style="border: 1px solid black; background-color: black; color: white; padding: 2px; display: inline-block;">OFF</div> </div>
1.6 > *2 Tank heater		
To set the tank heater ON or OFF.	OFF	<div style="text-align: center;"> ON <div style="border: 1px solid black; background-color: black; color: white; padding: 2px; display: inline-block;">OFF</div> </div>
1.7 > *2 Sterilization		
To set the auto sterilization ON or OFF.	ON	<div style="text-align: center;"> <div style="border: 1px solid black; background-color: black; color: white; padding: 2px; display: inline-block;">ON</div> ▼ OFF </div>
<ul style="list-style-type: none"> Do not use the system during sterilization in order to prevent scalding with hot water, or overheating of shower. Ask an authorised dealer/specialist to determine the level of sterilization function field settings according to the local laws and regulations. 		
1.8 > *3 DHW mode (Domestic Hot Water)		
<p>To set the DHW mode to Standard or Smart.</p> <ul style="list-style-type: none"> Standard mode have faster DHW Tank heat up time. Meanwhile Smart mode take longer time to heat up DHW time with lower energy consumption. 	Standard	<div style="text-align: center;"> <div style="border: 1px solid black; background-color: black; color: white; padding: 2px; display: inline-block;">Standard</div> ▼ <div style="border: 1px solid black; background-color: black; color: white; padding: 2px; display: inline-block;">Smart</div> </div>
<p>To set the tank sensor to Top or Center.</p> <ul style="list-style-type: none"> Selection of the tank sensor to top slow down the start of boiling up the tank and reduce power consumption. Please change this selection to "Center" when the hot water becomes insufficient. 	Top	<div style="text-align: center;"> <div style="border: 1px solid black; background-color: black; color: white; padding: 2px; display: inline-block;">Top</div> ▼ <div style="border: 1px solid black; background-color: black; color: white; padding: 2px; display: inline-block;">Center</div> </div>

*1 It is not displayed when the outdoor unit is used alone or depending on the settings.

*2 Only displayed when Tank connection is Yes.

*3 Only displayed when connect Panasonic AIR-TO-WATER HYDROMODULE+TANK.

Menu	Default Setting	Setting Options / Display
2 System check		
2.1 > Energy monitor		
Present or historical chart of energy consumption, generation or COP.	Present Select and retrieve	Total consumption (1year) 
	Historical chart Select and retrieve	
<ul style="list-style-type: none"> • COP= Coefficient of Performance. • For historical chart, the period is selected from 1 day/1 week/1year. • Energy consumption (kWh) of heating, *¹, *² cooling, *⁵ tank and total may be retrieved. • The total power consumption is an estimated value based on AC 230 V and may differ from value measured by precise equipment. 		
2.2 > *³ System information		
Shows all system information in each area.	Actual system information of 11 items: Inlet / Outlet / Zone 1 / Zone 2 / Tank / Buffer tank / Solar / Pool / COMP frequency / Pump flowrate / Water pressure * ⁷ Select and retrieve	System information 10:34am, Mon 1. Inlet : 0°C 2. Outlet : 0°C 3. Zone 1 : 0°C 4. Zone 2 : 0°C ↓Page
2.3 > Error history		
<ul style="list-style-type: none"> • Refer to Troubleshooting for error codes. • The most recent error code is displayed at the top. 	Select and retrieve	Error history 10:34am, Mon 1. -- 2. -- 3. -- 4. -- [←] Clear history
2.4 > Compressor		
Shows the compressor performance.	Select and retrieve	Compressor 10:34am, Mon 1. Current frequency : 0 Hz 2. (OFF-ON) counter : 0 3. Total ON time : 0 h [↩] Back
2.5 > Heater		
Total hours of ON time for * ⁴ Room heater/ * ⁵ Tank heater.	Select and retrieve	Heater 10:34am, Mon Total ON time  : 0h  : 0h [↩] Back

(NOTE) : If [Approx.] is shown on Energy Monitor display, data displayed on the remote controller is obtained through heat pump's internal calculation.
If [Approx.] is NOT shown on Energy Monitor display, data** displayed on the remote controller is obtained by External Meters.
Data stored on the Aquarea unit can be mixed between internal calculation and External Meters.
**In order to know the exact consumption or generation, please use as reference always the External Meters' data.

*¹ The system is locked to operate without COOL mode. It can be unlocked only by authorised installers or our authorised service partners.
*² Only displayed when COOL mode is unlocked (This means when COOL mode is available).
*³ The items displayed differ depending on the Appliance and connected units.
*⁴ It is not displayed when the outdoor unit is used alone.
*⁵ Only displayed when Tank connection is Yes.
*⁶ If [Approx.] is shown on Energy Monitor display, data displayed on the remote controller is obtained through heat pump's internal calculation.
If [Approx.] is NOT shown on Energy Monitor display, data displayed on the remote controller is obtained by External Meters.
*⁷ Only displayed when each connection is Yes.

Menu	Default Setting	Setting Options / Display
3 Personal setup		
3.1 > Remote control No.		
<ul style="list-style-type: none"> To display remote control number of a particular remote controller so that installer and end user are well informed. Main remote controller is displayed as RC-1. Second remote controller is displayed as RC-2. 	Select and retrieve	RC No. 10:34am, Mon RC-1 [←] Confirm
3.2 > Touch sound		
Turns the operation sound.	3	Touch sound 9:53am, Mon Level 3 ↕ Select [←] Confirm
3.3 > LCD contrast		
Sets the screen contrast.	3	LCD contrast 10:34am, Mon Low High ◀ [Progress bar] ▶ ⬅ Select [←] Confirm
3.4 > Backlight		
Sets the duration of screen backlight.	1 min	Backlight 10:34am, Mon 15 secs 5 mins 1 min 10 mins ↗ Select [←] Confirm
3.5 > Backlight intensity		
Sets screen backlight brightness.	4	Backlight intensity 10:34am, Mon Dark Bright ◀ [Progress bar] ▶ ◀ Select [←] Confirm
3.6 > *1 Clock format		
Sets the type of clock display.	am/pm	Clock format 10:34am, Mon 24h am/pm ↗ Select [←] Confirm
3.7 > Date & Time		
Sets the present date and time.	Year / Month / Day / Hour / Min	Date & Time 10:34am, Mon Year/Month/Day Hour : Min 2024 / 01 / 01 10 : 34 am ↕ Select [←] Confirm

*1 The default setting is am/pm, but 24h is displayed on the selection screen.

Menu	Default Setting	Setting Options / Display
3.8 > Language		
Sets the display language for the top screen.	ENGLISH / FRANÇAIS / DEUTSCH / ITALIANO / ESPAÑOL / DANISH / SWEDISH / NORWEGIAN / POLISH / CZECH / NEDERLANDS / TÜRKÇE / SUOMI / MAGYAR / SLOVENŠČINA / HRVATSKI / LIETUVIŲ / PORTUGUÊS / БЪЛГАРСКИ / EESTI / LATVIEŠU / ROMÂNĂ / SHQIP / SLOVENČINA / МАКЕДОНСКИ / УКРАЇНСЬКА / ΕΛΛΗΝΙΚΑ	<p>Language 10:34am, Mon</p> <p>ENGLISH</p> <p>FRANÇAIS</p> <p>DEUTSCH</p> <p>ITALIANO</p> <hr/> <p>↕Select [←] Confirm</p>
3.9 > Unlock password		
4 digit password for all the settings.	0000	<p>Unlock password 10:34am, Mon</p> <p>0000</p> <hr/> <p>↕Select [←] Confirm</p>
4 Service contact		
4.1 > Contact 1 / Contact 2		
Preset contact number for installer.	Select and retrieve	<p>Service setup 10:34am, Mon</p> <p>Contact 1</p> <p>Name : Bryan Adams</p> <p> : 0881 2345678</p> <hr/> <p>↕Select</p>

5.1.6 Menus (For Installer)

Menu	Default Setting	Setting Options / Display
5 Installer setup > System setup		
5.1 > *1 Optional PCB connectivity		
To connect to the external PCB required for servicing.	No	Yes ▲ No
<ul style="list-style-type: none"> • If the external PCB is connected (optional), the system will have following additional functions: <ol style="list-style-type: none"> ① Control over 2 zones (including the swimming pool and the function to heat water in it). ② Solar function (the solar thermal panels connected to either the DHW (Domestic Hot Water) Tank or the Buffer Tank. <ul style="list-style-type: none"> • DHW is not applicable for WH-ADC *models. ③ External compressor switch. ④ External error signal. ⑤ SG ready control. ⑥ Demand control. ⑦ Heat-Cool SW 		
5.2 > Zone & Sensor		
To select the sensors and to select either 1 zone or 2 zone system.	Zone <ul style="list-style-type: none"> • After selecting 1 or 2 zone system, proceed to the selection of room or swimming pool. • If the swimming pool is selected, the temperature must be selected for ΔT temperature between 0°C ~ 10 °C. Sensor <ul style="list-style-type: none"> * For room thermostat, there is a further selection of external or internal. • If select internal, there is a further selection of RC-1 or RC-2 (only available when Zone selection is 1 zone system). Select RC-1 if main remote controller's thermistor is to be used for room temperature control and vice versa. 	Zone & Sensor 10:34am, Mon Zone 1 Zone system 2 Zones system ▼Select [-] Confirm Zone & Sensor 10:34am, Mon Sensor Water temperature Room thermostat Room thermistor ▼Select [-] Confirm
5.3 > *1 Heater capacity		
To reduce the heater power if unnecessary.* 3 kW / 6 kW / 9 kW		Heater capacity 10:34am, Mon 3 kW [-] Confirm
* Options of kW vary depending on the model.		
5.4 > Anti freezing		
To activate or deactivate the water freeze prevention when the system is OFF	Yes	Yes ▼ No
5.5 > *2 Tank connection		
To connect tank to the system.	No	Yes ▲ No

*1 It is not displayed when the outdoor unit is used alone.

*2 It is not displayed when connect Panasonic AIR-TO-WATER HYDROMODULE+TANK.

Menu	Default Setting	Setting Options / Display
5.6 > *1 DHW capacity		
<p>To select tank heating capacity to variable or standard. Variable capacity heat up tank with fast mode and keep the tank temperature with efficient mode. While standard capacity heat up tank with rated heating capacity. When "Efficiency" is selected the "5.25 Heating control" setting, the tank heat-up process will be delayed until a much lower tank water temperature is reached, which improves the efficiency of the heating process. To ensure sufficient hot water, select either "Standard" in this setting or "Comfort" in the "5.25 Heating control" setting.</p>	Variable	<p style="text-align: center;">Variable</p> <p style="text-align: center;">▼</p> <p style="text-align: center;">Standard</p>
5.7 > *2 Buffer tank connection		
<p>To connect tank to the system and if selected YES, to set ΔT temperature.</p>	No	<p style="text-align: center;">Yes</p> <p style="text-align: center;">▲</p> <p style="text-align: center;">No</p>
	> Yes	
	5 °C	<p>Set ΔT for Buffer Tank</p> <p>Buffer tank 10:34am, Mon</p> <p>ΔT for Buffer tank</p> <p>Range: (0°C~10°C)</p> <p>Steps: $\pm 1^\circ\text{C}$</p> <p style="text-align: center;">5 °C</p> <p>▲</p> <p>▼</p> <p>↕Select [↔] Confirm</p>
5.8 > *1 Tank heater		
<p>To select external or internal tank heater and if External is selected, set a timer for the heater to come on.</p> <p>* This option is available if Tank connection is selected (YES).</p>	External	<p>Tank heater 10:34am, Mon</p> <p style="text-align: center;">External</p> <p style="text-align: center;">▼</p> <p style="text-align: center;">Internal</p> <p>↕Select [↔] Confirm</p>
	> External	
	1:30	<p>Tank heater 10:34am, Mon</p> <p>Tank heater: ON time</p> <p>Range: (0:20~3:00)</p> <p>Steps: $\pm 0:05$</p> <p style="text-align: center;">1:30</p> <p>▲</p> <p>▼</p> <p>↕Select [↔] Confirm</p>

*1 Only displayed when Tank connection is Yes.
 *2 It is not displayed when the outdoor unit is used alone and Panasonic AIR-TO-WATER HYDROMODULE+TANK 2 Zone model.

Menu	Default Setting	Setting Options / Display
5.9 > Base pan heater		
To select whether or not optional base pan heater is connected. * Type A - The base pan heater activates only during deice operation. * Type B - The base pan heater activates when outdoor ambient temperature is 5 °C or lower.	No	Yes No
	> Yes	
	A	Base pan heater type 10:34am, Mon A B ↓Select [←] Confirm
5.10 > *1 Alternative outdoor sensor		
To select an alternative outdoor sensor.	No	Yes No
5.11 > Bivalent connection		
To select to enable or disable bivalent connection.	No	Yes No
> Yes		
To select either auto control pattern or SG ready input control pattern or smart control pattern. * This selection only display to select when optional pcb connection set to Yes.	Auto	Auto SG ready Smart
To select a bivalent connection to allow an additional heat source such as a boiler to heat-up the buffer tank and domestic hot water tank when heatpump capacity is insufficient at low outdoor temperature. The bivalent feature can be set-up either in alternative mode (heatpump and boiler operate alternately), or in parallel mode (both heatpump and boiler operate simultaneously), or in advance parallel mode (heatpump operates and boiler turns on for buffer-tank and/or domestic hot water depending on the control pattern setting options).	> Yes > Auto	
	-5 °C	Set outdoor temperature for turn ON Bivalent connection. Bivalent connection 10:34am, Mon Turn ON: Outdoor temp Range: (-15°C~35°C) Steps: ±1°C -5 °C ⇄Select [←] Confirm
	Yes > After selecting the outdoor temperature	
	Control pattern Alternative / Parallel / Advanced parallel • Select advanced parallel for bivalent use of the tanks.	Bivalent connection 10:34am, Mon Control pattern Alternative Parallel Advanced parallel ^Select [←] Confirm
Control pattern > Alternative		
OFF	Option to set external pump either ON or OFF during bivalent operation. Set to ON if system is simple bivalent connection.	Bivalent connection 10:34am, Mon External pump ON OFF ^Select [←] Confirm

*1 It is not displayed when the outdoor unit is used alone.

Menu	Default Setting	Setting Options / Display
Control pattern > Advanced parallel		
Heat	Selection of the tank	Bivalent connection 10:34am, Mon Advanced parallel Heat DHW ↓Select [←] Confirm
• "Heat" implies Buffer Tank and "DHW" implies Domestic Hot Water Tank.		
Control pattern > Advanced parallel > Heat > Yes		
• Buffer Tank is activated only after selecting "Yes".		Bivalent connection 10:34am, Mon Advanced parallel: Heat Yes No ↓Select [←] Confirm
-8 °C	Set the temperature threshold to start the bivalent heat source.	Bivalent connection 10:34am, Mon Heat start: Target temp. Range: (-10°C-0°C) Steps: ±1°C -8 °C ↕Select [←] Confirm
0:30	Delay timer to start the bivalent heat source (in hour and minutes).	Bivalent connection 10:34am, Mon Heat start: Delay time Range: (0:00-1:30) Steps: ±0:05 0:30 ↕Select [←] Confirm
-2 °C	Set the temperature threshold to stop the bivalent heat source.	Bivalent connection 10:34am, Mon Heat stop: Target temp. Range: (-10°C-0°C) Steps: ±1°C -2 °C ↕Select [←] Confirm
0:30	Delay timer to stop the bivalent heat source (in hour and minutes).	Bivalent connection 10:34am, Mon Heat stop: Delay time Range: (0:00-1:30) Steps: ±0:05 0:30 ↕Select [←] Confirm
Control pattern > Advanced parallel > DHW > Yes		
• DHW Tank is activated only after selecting "Yes".		Bivalent connection 10:34am, Mon Advanced parallel: DHW Yes No ↓Select [←] Confirm
0:30	Delay timer to start the bivalent heat source (in hour and minutes).	Bivalent connection 10:34am, Mon DHW: Delay time Range: (0:30-1:30) Steps: ±0:05 0:30 ↕Select [←] Confirm

Menu	Default Setting	Setting Options / Display																		
<p>SG ready input control for bivalent system follow below input condition.</p> <table border="1"> <thead> <tr> <th colspan="2">SG signal</th> <th>Operation pattern</th> </tr> <tr> <th>Vcc-bit1</th> <th>Vcc-bit2</th> <th></th> </tr> </thead> <tbody> <tr> <td>Open</td> <td>Open</td> <td>Heat Pump OFF, Boiler OFF</td> </tr> <tr> <td>Short</td> <td>Open</td> <td>Heat Pump ON, Boiler OFF</td> </tr> <tr> <td>Open</td> <td>Short</td> <td>Heat Pump OFF, Boiler ON</td> </tr> <tr> <td>Short</td> <td>Short</td> <td>Heat Pump ON, Boiler ON</td> </tr> </tbody> </table>	SG signal		Operation pattern	Vcc-bit1	Vcc-bit2		Open	Open	Heat Pump OFF, Boiler OFF	Short	Open	Heat Pump ON, Boiler OFF	Open	Short	Heat Pump OFF, Boiler ON	Short	Short	Heat Pump ON, Boiler ON	<p>> Yes > SG ready</p> <p>OFF</p> <p>Option to set external pump either ON or OFF during bivalent operation. Set to ON if system is simple bivalent connection.</p>	<p>Bivalent connection 10:34am, Mon</p> <p>External pump</p> <p>ON</p> <p>OFF</p> <p>^Select [-] Confirm</p>
SG signal		Operation pattern																		
Vcc-bit1	Vcc-bit2																			
Open	Open	Heat Pump OFF, Boiler OFF																		
Short	Open	Heat Pump ON, Boiler OFF																		
Open	Short	Heat Pump OFF, Boiler ON																		
Short	Short	Heat Pump ON, Boiler ON																		
<p>To do settings related to electricity and boiler so that unit is able to determine whether to operate heat pump or boiler at a particular period depends on operating cost of both heat sources. These settings are electricity price, boiler price, season, schedule etc.</p>	<p>> Yes > Smart</p> <p>OFF</p> <p>Option to set external pump either ON or OFF during bivalent operation. Set to ON if system is simple bivalent connection.</p>	<p>Bivalent connection 10:34am, Mon</p> <p>External pump</p> <p>ON</p> <p>OFF</p> <p>^Select [-] Confirm</p>																		
	<p>> Yes > Smart > After selecting for the external pump > Energy price</p> <p>- Select Electricity to set on electricity price. - Select Boiler to set on boiler price and its efficiency.</p>	<p>Bivalent connection 10:34am, Mon</p> <p>Energy price</p> <p>Electricity</p> <p>Boiler</p> <p>↓Select [-] Confirm</p>																		
	<p>> Yes > Smart > After selecting for the external pump > Energy price > Electricity</p> <p>0.0 * / kWh</p> <p>- There are total 10 different prices can be set for Electricity: Electricity price 1 ~ Electricity price 10</p> <p>- Range is 0 ~ 999.9 * / kWh</p> <p>- Press ^ or v to enter a setting screen as shown in Figure 1. Then start setting the value of electricity price.</p> <p>- After finish setting a particular electricity price (eg. Electricity price 1), press < or > to go and set for other electricity price.</p> <p>* Set the price according to value provided by electrical supply company.</p>	<p>Bivalent connection 10:34am, Mon</p> <p>Electricity price 1</p> <p>Range: (0~999.9 * / kWh)</p> <p>Steps: ±0.1 * / kWh</p> <p>0.0</p> <p>↔Select</p> <p>Figure 1</p> <p>Bivalent connection 10:34am, Mon</p> <p>000.0</p> <p>↔Select [-] Confirm</p>																		

Remark : * Currency setting depends on where you use this product.

Menu	Default Setting	Setting Options / Display								
	<p>> Yes > Smart > After selecting for the external pump > Energy price > Boiler</p> <p>0.0 * / kWh - Refer to method of Electricity price setting above for setting of boiler price. - After finish setting of boiler price, set the boiler efficiency (Range : 0 ~ 99%).</p> <p>0% * Set the price according to value provided by boiler or gas supply company.</p>	<p>Bivalent connection 10:34am, Mon</p> <p>Boiler price</p> <p>Range: (0~999.9 */kWh) Steps: ±0.1*/kWh 0.0</p> <p>↕Select [-] Confirm</p> <hr/> <p>Bivalent connection 10:34am, Mon</p> <p>Boiler efficiency</p> <p>Range: (0~99%) Steps: ±1% 0</p> <p>↕Select [-] Confirm</p>								
	<p>> Yes > Smart > After selecting for the external pump > Schedule > Season setting</p> <p>Season 1 : Dec (Refers to Winter season) Season 2 : Mar (Refers to Spring season) Season 3 : Jun (Refers to Summer season) Season 4 : Oct (Refers to Autumn season) - There are total 4 seasons to be set - Set the starting month for each season. (Eg. when Season 1 is set to Dec and Season 2 is set to Mar, month of December to February will be treated as Season 1).</p>	<p>Bivalent connection 10:34am, Mon</p> <p>Schedule</p> <p>Season setting Schedule setting</p> <p>↕Select [-] Confirm</p> <hr/> <p>Bivalent connection 10:34am, Mon</p> <p>Season 1: Start month</p> <p>Range: (Jan~Dec) Steps: ±1month Dec</p> <p>↕Select [-] Confirm</p>								
	<p>> Yes > Smart > After selecting for the external pump > Schedule > Schedule setting</p> <p>Start time (Pattern 1) : 3:00am Start time (Pattern 2) : 9:00am Start time (Pattern 3) : 4:00pm Start time (Pattern 4) : 9:00pm - For each season, there are total 4 patterns can be set.</p> <p>Price (Pattern 1/2/3/4) : 1 - Set the target start time and the appropriate electricity price for each pattern.</p> <p>- Select "1" to edit both start time and electricity price. Select "2" to edit electricity price only.</p>	<p>Bivalent connection 10:34am, Mon</p> <p>Schedule setting</p> <p>Season 1 Season 2 Season 3</p> <p>↕Select [-] Confirm</p> <hr/> <p>Season 1 10:34am, Mon</p> <table border="1"> <thead> <tr> <th>Start time</th> <th>Price(*kWh)</th> </tr> </thead> <tbody> <tr> <td>1. 3:00am</td> <td>0.0</td> </tr> <tr> <td>2. 9:00am</td> <td>0.0</td> </tr> <tr> <td>3. 4:00pm</td> <td>0.0</td> </tr> </tbody> </table> <p>↕Select [-] Edit</p> <hr/> <p>Bivalent connection 10:34am, Mon</p> <p>Select</p> <p>1: To edit time & price 2: To edit price only</p> <p>1 ▶ 2</p> <p>↕Select [-] Confirm</p>	Start time	Price(*kWh)	1. 3:00am	0.0	2. 9:00am	0.0	3. 4:00pm	0.0
Start time	Price(*kWh)									
1. 3:00am	0.0									
2. 9:00am	0.0									
3. 4:00pm	0.0									

Remark : * Currency setting depends on where you use this product.

Menu	Default Setting	Setting Options / Display	
	<p>- Range of start time displayed can be in "24h" or "am/pm" format depend on setting of "Clock format".</p> <p>- Range of electricity price is 0 ~ 10 which refers back to the 10 different electricity price set previously (under "Energy price > Electricity": Electricity price 1 ~ Electricity price 10). The price displayed on the upper right corner indicates the previous set value of Electricity price 1 to Electricity price 10.</p> <p>* When the price is set to "0", the electricity price will be treated as 0.0 * / kWh. It is for the convenience of installer when 0.0 is the desired setting value for a particular time.</p>	<p>Season 1 10:34am, Mon</p> <p>Pattern 1: Start time</p> <p>Range: (0.00~23.00)</p> <p>Steps: ±1hour</p> <p>3.00</p> <p>↕Select [-] Confirm</p> <hr/> <p>Season 1 10:34am, Mon</p> <p>Pattern 1: Price</p> <p>0.0 */kWh</p> <p>Range: (0~10)</p> <p>Steps: ±1</p> <p>0</p> <p>↕Select [-] Confirm</p>	
5.12 > *1 External SW			
	No	Yes No	
5.13 > *2 Solar connection			
<ul style="list-style-type: none"> The optional PCB connectivity must be selected YES to enable the function. If the optional PCB connectivity is not selected, the function will not appear on the display. DHW is not applicable for WH-ADC models. 	No	Yes No	
	> Yes		
	Buffer tank	Selection of the tank	<p>Solar connection 10:34am, Mon</p> <p>Buffer tank</p> <p>DHW tank</p> <p>↕Select [-] Confirm</p>
	> Yes > After selecting the tank		
	10 °C	Set ΔT ON temperature	<p>Solar connection 10:34am, Mon</p> <p>ΔT Turn ON</p> <p>Range: (6°C~15°C)</p> <p>Steps: ±1°C</p> <p>10 °C</p> <p>↕Select [-] Confirm</p>
> Yes > After selecting the tank > ΔT ON temperature			
5 °C	Set ΔT OFF temperature	<p>Solar connection 10:34am, Mon</p> <p>ΔT Turn OFF</p> <p>Range: (2°C~9°C)</p> <p>Steps: ±1°C</p> <p>5 °C</p> <p>↕Select [-] Confirm</p>	

*1 It is not displayed when the outdoor unit is used alone.

*2 It is not displayed when the outdoor unit is used alone and Panasonic AIR-TO-WATER HYDROMODULE+TANK 2 Zone model.

Menu	Default Setting	Setting Options / Display
		<p>> Yes > After selecting the tank > ΔT ON temperature > ΔT OFF temperature</p> <p>Solar connection 10:34am, Mon</p> <p>Anti freeze</p> <p>Range: (-20°C~10°C)</p> <p>Steps: ±1°C</p> <p>5 °C</p> <p>Set Antifreeze temperature</p> <p>↕Select [-] Confirm</p>
		<p>> Yes > After selecting the tank > ΔT ON temperature > ΔT OFF temperature > After setting the antifreeze temperature</p> <p>Solar connection 10:34am, Mon</p> <p>Hi limit</p> <p>Range: (70°C~90°C)</p> <p>Steps: ±5°C</p> <p>80 °C</p> <p>Set Hi limit</p> <p>↕Select [-] Confirm</p>
5.14	> *1 External error signal	<p>No</p> <p>Yes</p> <p>No</p>
5.15	> *1 Demand control	<p>No</p> <p>Yes</p> <p>No</p>
5.16	> *1 SG ready	<p>No</p> <p>Yes</p> <p>No</p>
		<p>> Yes > After selecting Capacity</p> <p>SG ready 10:34am, Mon</p> <p>Capacity [1-0]: DHW</p> <p>Range: (50%~150%)</p> <p>Steps: ±5%</p> <p>120 %</p> <p>Capacity (1) & (2) of DHW (in %), Heat (in %) and Cool (in °C)</p> <p>↕Select [-] Confirm</p>
		<p>> Yes > After selecting Power consumption > *HPU stop consumption</p> <p>SG ready 10:34am, Mon</p> <p>HPU stop consumption</p> <p>Range: (0.5kW~10.0kW)</p> <p>Steps: ±0.1kW</p> <p>3.6</p> <p>*2, *4 3.6kW</p> <p>*HPU stop consumption</p> <p>↕Select [-] Confirm</p>
		<p>> Yes > After selecting *HPU stop consumption > Consumption</p> <p>SG ready 10:34am, Mon</p> <p>Consumption [1-0]: DHW</p> <p>Range: (0.5kW~10.0kW)</p> <p>Steps: ±0.1kW</p> <p>3.6</p> <p>*3 3.6kW</p> <p>Consumption (1) & (2) of DHW (in kW), Heat (in kW) and Cool (in kW)</p> <p>↕Select [-] Confirm</p>

Remark : * HPU means Heat pump unit (Outdoor unit).

*1 It is not displayed when the outdoor unit is used alone.

*2 Depending on the model, it may be less than 3.6kW.

*3 Depending on the model, it may be less than 3.6kW or more than 3.6kW.

*4 Even though the setting value is lower than 3.0kW, actual power consumption can be 3.0kW caused by back-up heater operation.

Menu	Default Setting	Setting Options / Display
5.17 > *1 External compressor SW		
	No	Yes ▲ No
	> Yes	
	Heat source	Ext. compressor SW 11:34am, Mon Heater ▲ Heat source
		▲Select [←] Confirm
5.18 > Circulation liquid		
To select whether to circulate water or glycol in the system.	Water	Circulation liquid 10:34am, Mon Water ▼ Glycol
		▼Select [←] Confirm
5.19 > *1, *2 Heat-Cool SW		
	No	Yes ▲ No
5.20 > *1 Force heater		
To turn on Force heater either manually (by default) or automatically.	Manual	Force heater 10:34am, Mon Auto ▲ Manual
		▲Select [←] Confirm
5.21 > Force defrost		
If auto selection is set, outdoor unit will start defrost operation if long heating hour operate during low outdoor temperature.	Manual	Auto ▲ Manual
5.22 > *1 Defrost signal		
To turn on defrost signal to stop fan coil during defrost operation. (If defrost signal set to yes, bivalent function will not available to use)	No	Yes ▲ No

*1 It is not displayed when the outdoor unit is used alone.

*2 Only displayed when COOL mode is unlocked. (This mean when COOL mode is available)

Menu	Default Setting	Setting Options / Display
5.23 > Pump flowrate		
To set variable flow pump control or fix pump duty control.	ΔT	<div style="text-align: center;"> ΔT ▼ Max. Duty </div>
5.24 > DHW Defrost		
Allow system to run defrost by using hot water instead of room unit for better room comfort.	Yes	<div style="text-align: center;"> Yes ▼ No </div>
5.25 > Heating control		
<p>To select unit operation condition whether to achieve set temperature faster or to save energy.</p> <p>When "Efficiency" is selected, the time setting will transition to 1st, 2nd, and 3rd stage. Increasing the time will slowly increase the capacity. It is a function for Heating + Tank operation.</p> <p>When "Variable" is selected in the "5.6 DHW capacity" setting, the tank heat-up process will be delayed until a much lower tank water temperature is reached, which improves the efficiency of the heating process. To ensure sufficient hot water, select either "Comfort" in this setting or "Standard" in the "5.6 DHW capacity" setting.</p>	Comfort	<div style="text-align: center;"> Comfort ▼ Efficiency </div>
	> Efficiency	0:20
5.26 > External meter		
<p>To set which external meter to be used depends on meter connection.</p> <p>There are generation meters and various types of electricity meters.</p> <p>For generation meters, there are two connection systems :-</p> <p>a) One generation meter system : Heat-cool meter only</p> <p>b) Two generation meter system : Heat-cool meter and Tank meter</p>	<p>Heat-cool meter : No</p> <p>* Tank meter : No</p> <p>Elec. meter HP : No</p> <p>Elec. meter 1 (PV) : No</p> <p>Elec. meter 2 (Building) : No</p> <p>Elec. meter 3 (Reserve) : No</p> <p>* Only available if both Heat-cool meter and Tank connection are set to Yes.</p>	<div style="text-align: right;"> <p>External meter 10:34am, Mon</p> <p>Heat-Cool meter</p> <p>Tank meter</p> <p>Elec. meter HP</p> <p>Elec. meter 1 (PV)</p> <hr/> <p>↕Select [←] Confirm</p> <p>External meter 10:34am, Mon</p> <p>Elec. meter HP</p> <p>Elec. meter 1 (PV)</p> <p>Elec. meter 2 (Building)</p> <p>Elec. meter 3 (Reserve)</p> <hr/> <p>^Select [←] Confirm</p> </div>
	> Heat-cool meter	<p>- Set Heat-cool meter to Yes when this generation meter is connected.</p> <p>- It is to measure energy generation of heat pump unit during heating and cooling only operation (one generation meter system) or during heating, cooling and DHW operation (two generation meter system).</p>

Remark : Elec. means "Electricity", HP means "Heat pump"

Menu	Default Setting	Setting Options / Display
> Tank meter		
<ul style="list-style-type: none"> - Set Tank meter to Yes when this generation meter is connected. - It is to measure energy generation of heat pump unit during DHW operation*. * Only available if both Heat-cool meter and Tank connection are set to Yes. Only set Tank meter to Yes when the connection is two generation meter system. 		
		Yes  No
> Elec. meter HP		
<ul style="list-style-type: none"> - Set Elec. meter HP to Yes when this electricity meter is connected. - It is to measure energy consumption of heat pump unit. 		
		Yes  No
> Elec. meter 1 (PV)		
<ul style="list-style-type: none"> - Set Elec. meter 1 (PV) to Yes when this electricity meter is connected. - It is to measure energy generation of solar system. This data will be displayed only on Cloud system. 		
		Yes  No
> Elec. meter 2 (Building)		
<ul style="list-style-type: none"> - Set Elec. meter 2 (Building) to Yes when this electricity meter is connected. - It is to measure energy consumption of the building. This data will be displayed only on Cloud system. 		
		Yes  No
> Elec. meter 3 (Reserve)		
<ul style="list-style-type: none"> - Set Elec. meter 3 (Reserve) to Yes when this electricity meter is connected. - It is to measure energy consumption. This data will be displayed only on Cloud system. 		
		Yes  No
5.27 > Electrical anode To enable or disable operation of electrical anode.	Yes (for -AN models) No (for non -AN models) Yes : display No : no display error : blinking	<div style="border: 1px solid black; padding: 5px; display: inline-block;">  <div style="font-size: 24pt; font-weight: bold;">40°C</div> </div> <div style="text-align: center; margin-top: 10px;"> Yes  No </div>

Remark : Elec. means "Electricity"
 HP means "Heat pump"

Menu	Default Setting	Setting Options / Display	
5.28	> *1 Extra pump		
<p>Selects whether the extra pump is used in the circulation circuit for heating or in the circulation circuit for DHW, or it is not used. If set to "No", the pump is not used.</p> <p>If set to "Heat", the extra pump is used as a pump for the circulation circuit (for heating/cooling).</p> <p>If set to "DHW", the extra pump circulates domestic hot water in the circuit for DHW to prevent the domestic hot water from getting cold.</p> <ul style="list-style-type: none"> - If set to "Comfort", hot water is continuously circulated during DHW operation. - If set to "Efficiency", the extra pump turns ON and OFF alternatively following ON/OFF time setting. 	No	<div style="text-align: center;"> No Heat DHW </div>	
	> DHW		
	8:00 am / 8:00	Set Pump ON time	DHW 11:34pm, Mon Pump ON time <div style="text-align: center;"> 8 : 00 am ↕ ↕ </div> ⇄ Select [-] Confirm
	8:00 pm / 20:00	Set Pump OFF time	DHW 11:34pm, Mon Pump OFF time <div style="text-align: center;"> 8 : 00 pm ↕ ↕ </div> ⇄ Select [-] Confirm
	Efficiency	Select Comfort or Efficiency	DHW 11:34pm, Mon <div style="text-align: center;"> Comfort ▲ Efficiency ▼ </div> ^Select [-] Confirm
	> DHW > After selecting Efficiency		
	0:15	Set ON time	DHW 11:34pm, Mon ON time Range: (0:05~1:00) Steps: ±0:05 <div style="text-align: center;"> 0:15 ↕ ↕ </div> ⇄ Select [-] Confirm
	0:15	Set OFF time	DHW 11:34pm, Mon OFF time Range: (0:05~1:00) Steps: ±0:05 <div style="text-align: center;"> 0:15 ↕ ↕ </div> ⇄ Select [-] Confirm
5.29	> External heater		
Set to "YES" after an external heater is installed. (This menu is only displayed for the Control Module model (indoor unit))	No	<div style="text-align: center;"> Yes ▲ No ▼ </div>	
5.30	> Static pressure		
If set to "No", the fans in the outdoor unit rotate at a normal speed. If set to "YES", the fans in the outdoor unit rotate at a higher speed than normal for response to high static pressure.	No	<div style="text-align: center;"> Yes ▲ No ▼ </div>	

*1 It is not displayed when the outdoor unit is used alone.

Menu	Default Setting	Setting Options / Display
5.31 > *1 Cooling capacity		
<p>Selects the cooling capacity. If set to "Efficiency", the cooling operation is performed at rated capacity for efficient cooling. If set to "Comfort", the cooling operation is performed at maximum capacity.</p>	<p>Efficiency</p>	


*1 Only displayed when COOL mode is unlocked (This means when COOL mode is available).

Menu	Default Setting	Setting Options / Display
6 Installer setup > Operation setup		
To access to the four major functions or modes.	4 main modes Heat / *1, *2 Cool / *1, *2 Auto / *3 Tank	Operation setup 10:34am, Mon Heat Cool Auto Tank ↓Select [←] Confirm
6.1 > Heat		
To set various water & ambient temperatures for heating.	Water temp. for heating ON / Outdoor temp. for heating OFF / ΔT for heating ON / Heater ON/OFF	Operation setup 10:34am, Mon Heat Water temp. for heating ON Outdoor temp. for heating OFF ΔT for heating ON ↓Select [←] Confirm
> Water temp. for heating ON		
Compensation curve	Heating ON temperatures in compensation curve or direct input.	Operation setup 10:34am, Mon Heat ON: Water temp. Compensation curve Direct ↓Select [←] Confirm
> Water temp. for heating ON > Compensation curve		
X axis: -5 °C, 15 °C Y axis: 55 °C, 35 °C	Input the 4 temperature points (2 on horizontal X axis, 2 on vertical Y axis).	Heat ON: Water temp.:Zone1 ↔Select [←] Confirm
<ul style="list-style-type: none"> • Temperature range: X axis: -20 °C ~ 15 °C, Y axis: See below • Temperature range for the Y axis input: WH-WXG model: 25 °C ~ 75 °C Regardless of the above setting, there is a limit to the water temperature. Refer to the operating condition on page 3. • If 2 zone system is selected, the 4 temperature points must also be input for Zone 2. • "Zone 1" and "Zone 2" will not appear on the display if only 1 zone system. 		
> Water temp. for heating ON > Direct		
35 °C	Temperature for heating ON	Operation setup 10:34am, Mon Heat ON: Water temp.:Zone2 Range: (25°C~75°C) Steps: ±1°C 35 °C ↕Select [←] Confirm
<ul style="list-style-type: none"> • Min. ~ Max. range is 25 °C ~ 75 °C: WH-WXG model: 25 °C ~ 75 °C Regardless of the above setting, there is a limit to the water temperature. Refer to the operating condition on page 3. • If 2 zone system is selected, temperature set point must input for Zone 2. • "Zone 1" and "Zone 2" will not appear on the display if only 1 zone system. 		

*1 The system is locked to operate without COOL mode. It can be unlocked only by authorised installers or our authorised service partners.
*2 Only displayed when COOL mode is unlocked (This means when COOL mode is available).
*3 Only displayed when Tank connection is Yes.

Menu	Default Setting	Setting Options / Display
> Outdoor temp. for heating OFF		
> Outdoor temp. for heating OFF > Heat OFF outdoor temp.		
24 °C	Set outdoor temp to stop heating. Setting range is 6°C~35°C	Operation setup 10:34am, Mon Heat OFF: Outdoor temp. Range: (6°C~35°C) Steps: ±1°C 24 °C ↕Select [←] Confirm
> Outdoor temp. for heating OFF > Heat ON outdoor temp.		
23 °C	Set outdoor temp to start heating. Setting range is 5°C~X°C (X is heating OFF temp. -1)	Operation setup 10:34am, Mon Heat ON: Outdoor temp. Range: (5°C~23°C) Steps: ±1°C 23 °C ↕Select [←] Confirm
> Outdoor temp. for heating OFF > Heat ON Delay time.		
0:30 min	Set delay time from heating OFF to heating ON.	Operation setup 10:34am, Mon Heat ON: Delay time Range: (0:30~24:00) Steps: ±0:30 0:30 ↕Select [←] Confirm
> ΔT for heating ON		
5 °C	Set ΔT for heating ON. * This setting will not available to set when pump flowrate set to Max. duty.	Operation setup 10:34am, Mon Heat ON: ΔT Range: (1°C~15°C) Steps: ±1°C 5 °C ↕Select [←] Confirm
> *1 Heater ON/OFF		
> Heater ON/OFF > Outdoor temp. for heater ON		
0 °C	Temperature for heater ON	Operation setup 10:34am, Mon Heater ON: Outdoor temp. Range: (-20°C~15°C) Steps: ±1°C 0 °C ↕Select [←] Confirm
> Heater ON/OFF > Delay time for heater ON		
0:30 min	Delay time for heater to turn on	Operation setup 10:34am, Mon Heater ON: Delay time Range: (0:10~1:00) Steps: ±0:10 0:30 ↕Select [←] Confirm
> Heater ON/OFF > Water temperature for heater ON		
-4 °C	Setting of water temperature to turn on from water set temperature.	Operation setup 10:34am, Mon Heater ON: ΔT of target Temp. Range: (-10°C~-2°C) Steps: ±1°C -4 °C ↕Select [←] Confirm

*1 It is not displayed when the outdoor unit is used alone.

Menu	Default Setting	Setting Options / Display
		> Heater ON/OFF > Water temperature for heater OFF Operation setup 10:34am, Mon Heater OFF: ΔT of target Temp. Range: (-8°C~0°C) Steps: ±1°C -2 °C Select [-] Confirm
6.2	> *1, *2 Cool	
To set various water & ambient temperatures for cooling.	Water temperatures for cooling ON and ΔT for cooling ON.	Operation setup 10:34am, Mon Cool Water temp. for cooling ON ΔT for cooling ON Select [-] Confirm
		> Water temp. for cooling ON Operation setup 10:34am, Mon Cool ON: Water temp. Compensation curve Direct Select [-] Confirm
	Compensation curve	Cooling ON temperatures in compensation curve or direct input. Select [-] Confirm
		> Water temp. for cooling ON > Compensation curve Cool ON: Water temp: Zone1  Select [-] Confirm
	X axis: 20 °C, 30 °C Y axis: 15 °C, 10 °C	Input the 4 temperature points (2 on horizontal X axis, 2 on vertical Y axis) • If 2 zone system is selected, the 4 temperature points must also be input for Zone 2. • "Zone 1" and "Zone 2" will not appear on the display if only 1 zone system.
		> Water temp. for cooling ON > Direct Operation setup 10:34am, Mon Cool ON: Water temp.: Zone2 Range: (5°C~20°C) Steps: ±1°C 10 °C Select [-] Confirm
	10 °C	Set temperature for Cooling ON • If 2 zone system is selected, temperature set point must input for Zone 2. • "Zone 1" and "Zone 2" will not appear on the display if only 1 zone system.
		> ΔT for cooling ON Operation setup 10:34am, Mon Cool ON: ΔT Range: (1°C~15°C) Steps: ±1°C 5 °C Select [-] Confirm
	5 °C	Set ΔT for cooling ON * This setting will not available to set when pump flowrate set to Max. duty.

*1 The system is locked to operate without COOL mode. It can be unlocked only by authorised installers or our authorised service partners.
 *2 Only displayed when COOL mode is unlocked (This means when COOL mode is available).

Menu	Default Setting	Setting Options / Display
6.3	> *1, *2 Auto	
Automatic switch from Heat to Cool or Cool to Heat.	Outdoor temperatures for switching from Heat to Cool or Cool to Heat. Outdoor temp. for (Heat to Cool) / Outdoor temp. for (Cool to Heat)	Operation setup 10:34am, Mon Auto Outdoor temp. for (Heat to Cool) Outdoor temp. for (Cool to Heat) ↓Select [←] Confirm
	> Outdoor temp. for (Heat to Cool)	
	15 °C Set outdoor temperature for switching from Heat to Cool.	Operation setup 10:34am, Mon Auto: Outdoor temp.(Heat to Cool) Range: (11°C~25°C) Steps: ±1°C 15 °C ↕Select [←] Confirm
	> Outdoor temp. for (Cool to Heat)	
	10 °C Set outdoor temperature for switching from Cool to Heat.	Operation setup 10:34am, Mon Auto: Outdoor temp.(Cool to Heat) Range: (5°C~14°C) Steps: ±1°C 10 °C ↕Select [←] Confirm
6.4	> *3 Tank	
Setting functions for the tank.	Floor operation time (max) / Tank heat up time (max) / Tank re-heat temp. / Sterilization	Operation setup 10:34am, Mon Tank Floor operation time (max) Tank heat up time (max) Tank re-heat temp. ↓Select [←] Confirm
	• The display will show 3 functions at a time.	
	> Floor operation time (max)	
	8:00 Maximum time for floor operation (in hours and minutes)	Operation setup 10:34am, Mon Tank: Floor op. time (max) Range: (0:30~10:00) Steps: ±0:30 8:00 ↕Select [←] Confirm
	> Tank heat up time (max)	
	1:00 Maximum time for heating the tank (in hours and minutes)	Operation setup 10:34am, Mon Tank: Heat up time (max) Range: (0:05~4:00) Steps: ±0:05 1:00 ↕Select [←] Confirm
	> Tank re-heat temp.	
	-8 °C Set temperature to perform reboil of tank water.	Operation setup 10:34am, Mon Tank: Re-heat temp. Range: (-12°C~-2°C) Steps: ±1°C -8 °C ↕Select [←] Confirm

*1 The system is locked to operate without COOL mode. It can be unlocked only by authorised installers or our authorised service partners.

*2 Only displayed when COOL mode is unlocked (This means when COOL mode is available).

*3 Only displayed when Tank connection is Yes.

Menu	Default Setting	Setting Options / Display														
> Sterilization																
Monday	Sterilization may be set for 1 or more days of the week. Sun / Mon / Tue / Wed / Thu / Fri / Sat	Operation setup 10:34am, Mon Sterilization: Day <table border="1"> <tr> <td>Sun</td> <td>Mon</td> <td>Tue</td> <td>Wed</td> <td>Thu</td> <td>Fri</td> <td>Sat</td> </tr> <tr> <td>-</td> <td>✓</td> <td>-</td> <td>-</td> <td>-</td> <td>-</td> <td>-</td> </tr> </table> ⏪ Day ⏩ [☑/☐] [-] Confirm	Sun	Mon	Tue	Wed	Thu	Fri	Sat	-	✓	-	-	-	-	-
Sun	Mon	Tue	Wed	Thu	Fri	Sat										
-	✓	-	-	-	-	-										
> Sterilization: Time																
12:00	Time of the selected day(s) of the week to sterilize the tank 0:00 ~ 23:59	Operation setup 10:34am, Mon Sterilization: Time <div style="text-align: center; font-size: 2em; font-weight: bold;">12:00 pm</div> ⏪ Select [-] Confirm														
> Sterilization: Boiling temp.																
65 °C	Set boiling temperatures for sterilize the tank.	Operation setup 10:34am, Mon Sterilization: Boiling temp. *1 Range: (55°C~65°C) Steps: ±1°C <div style="text-align: center; font-size: 1.5em; font-weight: bold;">65 °C</div> ⏪ Select [-] Confirm														
> Sterilization: Ope. time (max)																
0:10	Set sterilizing time (in hours and minutes)	Operation setup 10:34am, Mon Sterilization: Ope. time (max) Range: (0:05~1:00) Steps: ±0:05 <div style="text-align: center; font-size: 1.5em; font-weight: bold;">0:10</div> ⏪ Select [-] Confirm														

7 Installer setup > Service setup

7.1 > Pump maximum speed

To set the maximum speed of the pump.

Setting the flow rate, max. duty and operation ON/OFF of the pump.

Flow rate: XX.X L/min
 Max. Duty: 0x40 ~ 0xFE,
 Pump: ON/OFF/Air Purge

Service setup 10:34am, Mon
 Flow rate Max. Duty Operation
 46.0 L/min **0xCE** OFF
 ⏪ Select

7.2 > *2 Zone2 pump speed

To set the zone2 pump speed.

Flow rate: XX.X L/min
 Max. Duty: 0x46 ~ 0xC5,
 Pump: ON/OFF

Service setup 11:34pm, Mon
 Flow rate Max. Duty Operation
 10.0 L/min **0x50** OFF
 ⏪ Select

*1 When using external heater, 55°C ~ 75°C.


*2 Only displayed when Panasonic AIR-TO-WATER HYDROMODULE+TANK 2Zone model.

Menu	Default Setting	Setting Options / Display	
7.3 > Dry concrete			
<p>To dry the concrete (floor, walls, etc.) during construction.</p> <p>Do not use this menu for any other purposes and in period other than during construction</p>	Edit to set the temperature of dry concrete. ON / Edit	Service setup 10:34am, Mon Dry concrete ON Edit ↓Select [←] Confirm	
	> Edit		
	Stages: 1 Temperature: 25 °C	Heating temperature for drying the concrete. Select the desired stages: 1 ~ 10, range: 1 ~ 99	Service setup 10:34am, Mon Dry concrete: 1/10 Range: (25°C~55°C) Steps: ±1°C 25 °C ^Select [←] Confirm
	> ON		
Confirm the setting temperatures of dry concrete for each stage.		Service setup 10:34am, Mon Dry concrete: Status Stage : 1/10 Water set temp. : 25°C Actual water temp. : 25°C/25°C [☺] OFF	
7.4 > Service contact			
<p>To set up to 2 contact names and numbers for the User.</p>	Service engineer's name and contact number. Contact 1 / Contact 2	Service setup 10:34am, Mon Service contact: Contact 1 Contact 2 ↓Select [←] Confirm	
	> Contact 1 / Contact 2		
	Contact name or number. Name / phone icon	Service contact 10:34am, Mon Contact 1 Name : Bryan Adams  : 08812345678 ↓Select [←] Edit	
	Input name and number Contact name: alphabet a ~ z. Contact number: 1 ~ 9	Contact-1 <input type="text"/> ABC/abc 0-9/Other ABCDEFGHI JKLMNOPQR Space STUVWXYZ abcdefghi BS jklmnopqr stuvwxyz Conf ←Select [←] Enter Number: <input type="text"/> 1 2 3 (4 5 6) 7 8 9 - BS * 0 # _ Conf ←Select [←] Enter	

8 Installer setup > Remote control setup		
--	--	--


<ul style="list-style-type: none"> To select whether to use one remote controller or two remote controllers. Select Single when one remote controller is connected. Select Dual when two remote controllers are connected. Second remote controller can be used for zone 2 room temperature control. 	Single	Selection of one or two remote controllers.	<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">Single</div> <div style="text-align: center;">▼</div> <div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">Dual</div>
		When Dual is selected, Main remote controller (RC-1) will start to communicate with second remote controller (RC-2) and display "RC-1 & RC-2 sync. in progress". They are ready to be used after this pop up screen disappears.	<div style="border: 1px solid black; padding: 10px; width: fit-content; margin: 0 auto;"> <p style="text-align: center;">RC-1 & RC-2 sync. in progress!</p> </div>
		When both remote controllers have communication failure, it will display "Communication with RC-2 failed".	<div style="border: 1px solid black; padding: 10px; width: fit-content; margin: 0 auto;"> <p style="text-align: center;">Communication with RC-2 failed!</p> <p style="text-align: center;">[↵] Close</p> </div>

5.1.7 Main Components




- | | | |
|--------------------------|------------------------------------|--|
| ① Remote Controller | ⑩ Overload Protector (Not Visible) | ⑲ Tank Sensor (Not Visible) |
| ② Left Decoration Panel | ⑪ Expansion Vessel | ⑳ Bushing (4 pieces) |
| ③ Right Decoration Panel | ⑫ Drain plug | ㉑ Safety Relief Valve |
| ④ Control Board Cover | ⑬ Tank | ㉒ Network Adaptor Holder |
| ⑤ Control Board | ⑭ Front Plate | ㉓ Electric Anode Bar
(Not Visible - Applicable only
for WH-ADC0316M9E8AN1,
WH-ADC0916M3E5AN1) |
| ⑥ Main PCB | ⑮ Right Plate | ㉔ Electric anode PCB
(Applicable only for
WH-ADC0316M9E8AN1,
WH-ADC0916M3E5AN1) |
| ⑦ 3 Phase RCCB/ELCB | ⑯ Left Plate | |
| ⑧ Heater Assembly | ⑰ Rear Plate | |
| ⑨ 3-Way Valve | | |

5.2 Outdoor Unit



6. Dimensions

6.1 Indoor Unit




Tube Connector	Function	Connector Size
①	Zone 1 Water Inlet (From Space Heating/Cooling)	R 1¼"
②	Zone 1 Water Outlet (To Space Heating/Cooling)	R 1¼"
③	Cold Water Inlet (Domestic Hot Water Tank)	R ¾"
④	Hot Water Outlet (Domestic Hot Water Tank)	R ¾"
⑤	Water Inlet (From Outdoor Unit)	R 1¼"
⑥	Water Outlet (To Outdoor Unit)	R 1¼"
⑨	Domestic Hot Water Tank Discharge (Drain Tap) Type: Ball Valve	Rc 1/2"
⑧	Drain Water Hole	---


Unit: mm

6.2 Outdoor Unit


<Top View>




<Front View>




<Side View>



<Rear View>



<Bottom View>




Unit: mm

7. Refrigeration and Water Cycle Diagram


OUTDOOR UNIT

INDOOR UNIT




TH1	Outdoor discharge sensor
TH2	-
TH3	Outdoor heat exchanger sensor
TH4	Outdoor ambient sensor
TH5	Evaporator outlet sensor
TH6	Refrigerant sensor
TH7	Water inlet 2 sensor
TH8	Water outlet sensor 2
TH9	Outdoor heat exchanger middle sensor
TH10	Bypass outlet sensor
TH11	Bypass inlet sensor
TH12	Economizer outlet sensor

8. Block Diagram




10. Electronic Circuit Diagram

10.1 Indoor Unit




10.2 Outdoor Unit



11. Printed Circuit Board


11.1 Indoor Unit

11.1.1 Main Printed Circuit Board




11.2 Outdoor Unit


11.2.1 Main Printed Circuit Board



11.2.2 Noise Filter Printed Circuit Board



11.2.3 Sub Printed Circuit Board



12. Installation Instruction

Attached accessories

No.	Accessory part	Qty.
1	Adjustable Feet 	4
2	Drain Elbow 	1
3	Packing for drain 	1
4	Network Adaptor (CZ-TAW*) 	1

Optional Accessories

No.	Accessories part	Qty.
5	Remote Controller Case (PAW-A2W-COV-KL)	1
6	Extension Cable (CZ-TAW1-CBL)	1
7	Optional PCB (CZ-NS6P)	1
8	*1Remote Controller (CZ-RTW2, CZ-RTW2-1)	1

*1 If you need the 2nd remote controller, buy 8 and set it up as the 2nd remote controller.

Field Supply Accessories (Optional)

No.	Part		Model	Specifications	Maker
i	2-way valve kit *Cooling model	Electromotoric Actuator	SFA21/18	AC230V, 12 VA	Siemens
		2-port Valve	VVI 46/25		Siemens
ii	Room thermostat	Wired	PAW-A2W-RTWIRED	AC230V	-
		Wireless	PAW-A2W-RTWIRELESS		
iii	Mixing valve	-	13020800	AC230V, 5VA	ESBE
iv	Pump	-	Yonos PICO1.0 25/1-8	AC 230V, 0.6 A max	Wilo
v	Buffer tank sensor	-	PAW-A2W-TSBU	-	-
vi	Outdoor sensor	-	PAW-A2W-TSOD	-	-
vii	Zone water sensor	-	PAW-A2W-TSHC	-	-
viii	Zone room sensor	-	PAW-A2W-TSRT	-	-
ix	Solar sensor	-	PAW-A2W-TSSO	-	-
x	Wall mount bracket	-	-	-	-

- It is recommended to purchase the field supply accessories listed in above table.

12.1 Indoor Unit

12.1.1 Select the Best Location


Obtain customer' approval before deciding on the installation location.

- Install the tank unit indoors in a weatherproof, frost-free location.
- Must be installed on a flat, solid hard surface.
- Ensure that there are no heat sources or vapours near the tank unit.
- Good air circulation in the room.
- Places where drainage is easy (e.g. utility rooms).
- Where the operating noise of the tank unit does not cause discomfort to the user.
- Where tank unit is located away from doorways.
- Location accessible for maintenance.
- Ensure to keep minimum distance of spaces as illustrated below from wall, ceiling, or other obstacles.
- Where leakage of flammable gases is unlikely to occur.
- Secure the tank unit to prevent it from falling over accidentally or during an earthquake.

Do not install the tank unit in such a way that it is placed in the following conditions.


- Unusual environmental conditions, installation in the presence of frost, unfavourable weather conditions
- Input voltage exceeding specified voltage

12.1.1.1 Space Required for Installation



12.1.1.2 Delivery and Handling

- When transporting the unit, take care not to damage it due to impact.
- Packaging can be removed only when you reach the installation site.
- Installation may require more than three people. The tank unit is heavy and may cause injury if carried alone.
- Tank units can be carried in either vertically or horizontally.
 - If the product is transported horizontally, ensure that the front of the packaging material (the side marked 'FRONT') is facing upwards.
 - If you wish to carry it in vertically, use the hand holes on the side and slide it to the desired location.
- If the tank unit is to be installed on an uneven surface, fix the Adjustable Feet **1**.




12.1.2 Install a Sleeve of Piping (Drill a Hole in the Wall)

1. Make a through hole. (Check pipe diameter and insulation thickness)
2. Insert the piping sleeve into the hole.
3. Fix the bushing to the sleeve.
4. Cut the sleeve until it extrudes about 15 mm from the wall.

 CAUTION
! When the wall is hollow, please be sure to use the sleeve for tube assembly to prevent dangers caused by mice biting the connection cable.

5. Finish by sealing the sleeve with putty or caulking compound at the final stage.




12.1.3 Piping Installation

12.1.3.1 Water Quality Requirement


Must use water that complies with European Drinking Water Directive (EU)2020/2184. The lifespan of the Tank Unit will be shorter if groundwater (include spring water and well water) is used.
The Tank Unit shall not be used with the tap water containing contaminants such as salt, acid, and other impurities which may corrode the tank and its component.
Use sanitized water that is free of Legionella and other bacteria and microorganisms. If the water contains Legionella bacteria, it may harm the health of the user.

12.1.3.2 Typical Piping Installation



12.1.3.3 Access to Internal Components

⚠ WARNING
This section is intended for licensed electricians/water system installers. Work inside screw-fastened fronts must be carried out under the supervision of a qualified installer, installation technician or service shop.



⚠ CAUTION
Open and close the front plate carefully. The front plate is heavy and may cause injury to fingers.

*The remote control cable is connected to the front panel, so take care when removing the panel.


Opening and closing the Front Plate ⑭.

- 1 Remove the two mounting screws from the Front Plate ⑭.
- 2 Unhook the Front Plate ⑭ by sliding it upwards.
- 3 Reverse steps 1 - 2 above and close.

12.1.3.4 Water Piping Installation

- The installation of this water circuit should be carried out by a licensed water circuit installer.
- Follow relevant European and national regulations (including EN61770) and local plumbing and building codes for the installation of water circuits.
- Ensure that components installed in the water circuit can withstand the water pressure during operation.
- Do not use worn tubes or detachable hoses.
- Applying excessive force to the pipework may damage it.
- Select a suitable sealer that can withstand the pressure and temperature of the system.
- Tighten the connection with two spanners. In addition, tighten the nuts to the specified torque using a torque spanner.
- When inserting through a wall, cover the end of the pipe to prevent dirt and dust.
- When installing using metal pipe other than brass, always insulate the pipe to prevent electrolytic corrosion.
- Do not connect galvanised pipes. That may cause electrolytic corrosion.
- Use the correct nut for the tank unit tube connections and flush all tubes with tap water before installation. See tube position diagram for details.

Tube connector	Nut size	Torque
Ⓐ & Ⓑ & Ⓔ & Ⓕ	RP 1 1/4"	117.6 N•m
Ⓒ & Ⓓ	RP 3/4"	58.8 N•m



CAUTION

⊘ Do not over-tighten as this may cause water leakage.

- Make sure to insulate the water circuit pipes to prevent reduction of heating capacity.
- After installation, check the connections for leaks during test run.
- Incorrect tubing connections may cause the tank unit to fail.
- Protection from frost:
If the tank unit is exposed to frost during power supply failure or pump malfunction, drain the system. Pooled water in the system can lead to freezing, which may damage the system. Ensure that the power supply is turned off before draining. Heater Assembly (g) may be damaged if heated without water. The outdoor unit needs to be drained inside, contact a service person.
- Corrosion resistance:
Duplex stainless steels are corrosion resistant to water supply. No specific maintenance is required to maintain this resistance. Note, however, that tank unit is not guaranteed for use on private water supplies.
- It is recommended that a tray (supplied on site) is used to collect water from the tank unit in case a leak occurs.

Recommended pipework installation sequence:

(e) → (b) → (f) → (a) → (c) → (d)

(A) Space heating/cooling pipework

- The tank unit tube connector (a) must be connected to the outlet connector of Zone 1 panel/floor heater.
- The tank unit tube connector (b) must be connected to the inlet connector of Zone 1 panel/floor heater.
- Incorrect tubing connections may cause the tank unit to fail.
- For the rated flow rate of each outdoor unit, refer to the installation instructions for the outdoor unit.

*Do not install automatic air purge valves on indoor water pipes. In the unlikely event that R290 refrigerant leaks into the water circuit, there is a risk of refrigerant leaking into the room.

(B) Circulating pipework


- Connect the tank unit tube connector (f) to the inlet socket on the outdoor unit.
- Connect the tank unit tube connector (e) to the outlet socket on the outdoor unit.
- If the connection is not made correctly, the system will stop with an error.
- Refer to the installation instructions for the outdoor unit for the inner diameter of the pipe.

(C) Domestic hot water tank pipework


- It is strongly recommended to install an expansion vessel (supplied on site) in the circuit of the domestic hot water tank. For the location of the expansion vessel, see "Typical piping installation".
 - Type and specification of expansion vessel:
 - Size : 10L.
 - Connection diameter: Less than 3/4".
 - Pre-charge pressure: 3.5 bar (0.35 MPa)
- Additional expansion vessel may be required if the pipe volume is increased, e.g. by using a secondary return circuit.
- Where water pressure is high or the water supply exceeds 5 bar, install a pressure reducing valve for the water supply. If the pressure higher than that, it may damage the tank unit.
- A pressure reducing valve (supplied on site) of the following specification must be installed on the line of the tank unit's tube connector (c). For the location of this valve, see "Typical piping installation".
 - Type and specification of pressure reducing valve:
 - Connection diameter: 3/4" or 1/2".
 - Set pressure : 3.5 bar (0.35 MPa)
- The pressure downstream of the pressure reducing valve is below 3.5 bar (0.35 MPa).
- In order to supply water at a temperature suitable for showers and tap usage, the tank unit's tube connector (d) must be connected to main water supply. Failure to make this connection may result in burns.
- Incorrect tubing connections may cause the tank unit to fail.

(D) Installation of drain elbows and hoses

- Fix Drain Elbow [2] and Packing [3] to the bottom of Drain Water Hole (h).



- Use a commercially available drain hose with an inner diameter 17 mm and fix it to the drain elbow [2].
- This hose must always be installed continuously downwards and used in a frost-free environment. Improper drainpipes may cause leaks and damage furniture.
- If the drain hose is long, use a metal support in the middle to ensure that the drain pipe does not wave.
- Guide the drain hose outdoors as shown in the diagram.



- Do not insert this hose into sewers or drains where ammonia or sulphur gases are generated.
- If necessary, use hose clamps to further tighten the hose at the drain hose connector to prevent leakage.
- The outlet of this hose must be located in an area where the outlet cannot become blocked, as water drops from this hose.
- If the drain hose is located indoors (where condensation may occur), use POLY-E FOAM with a minimum thickness of 6 mm to improve insulation.

(E) Domestic hot water tank drains (drain taps) and safety relief valve pipework

- Built-in 8 bar (0.8 MPa) safety relief valve on domestic hot water tank.
- The tank drain and the safety relief valve discharge port share the same drain port.
- Use R1/2" male connector for this drain connection (tube connector 9).
- Pipework must always be installed continuously downwards. The length should be no more than 2 m and no more than two elbows, so as not to cause condensation or freezing.
- Do not block the pipe from this drain fitting. It must be able to drain freely.
- The end of this pipework should be constructed so that the drain outlet is visible and not damaged. Keep away from electrical components.
- It is recommended that a tundish is fitted to this 9 pipework. Mount the tundish in an easily visible location away from frost environment and electrical components.

12.1.4 Connect the Cable to the Tank Unit

⚠ WARNING

This section is intended for licensed electricians. Work inside the Control Board Cover ④ secured with screws must be carried out under the supervision of a qualified installation shop, installation technician or service shop.

⚠ CAUTION

Care must be taken when opening the control board cover ④ and control board ⑤ for unit installation and servicing. It may cause injury.




12.1.4.1 Fixing of Power Supply Cable and Connecting Cable

- The isolating device must be connected to the power supply cable.
 - Isolation device (disconnecting means) must have a contact gap of at least 3.0 mm.
 - Connect approved polychloroprene sheathed power cable of type designation 60245 IEC 57 or heavier to the terminal board and connect the other end of the cable to an isolating device (disconnecting means). See table below for cable size requirements.

Power Supply Cable


Model	WH-ADC0316M9E81 WH-ADC0316M9E8AN1	WH-ADC0916M3E51 WH-ADC0916M3E5AN1
Cable Size	5 × min 1.5 mm ²	3 × min 1.5 mm ²
Isolating Devices	20A	15/16A
Recommended RCD	30mA, 4P, type A	30mA, 2P, type A




Terminal screw	Tightening torque cN•m {kgf•cm}
M4	157~196 {16~20}
M5	196~245 {20~25}

*1 - Earth wire should be longer than other cables for safety reasons

2. The connecting cable between the tank unit and the outdoor unit must be as follows:
- Cable size: $2 \times \text{min } 0.75 \text{ mm}^2$
 - Cable type: 60245 IEC 57 or heavier, with an approved double-insulated polychloroprene sheath.
- * Do not connect a 1-phase indoor unit to a 3-phase outdoor unit.**



12.1.4.2 Wire Stripping and Connecting Requirement



12.1.4.3 Connection Requirement

For model WH-ADC0316M9E81, WH-ADC0316M9E8AN1, WH-ADC0916M3E51, WH-ADC0916M3E5AN1

- The equipment's Power Supply complies with IEC/EN 61000-3-2.
- The equipment's Power Supply complies with IEC/EN 61000-3-3 and can be connected to current supply network.

12.1.5 Charging and Discharging the Water

- Make sure all the piping installations are properly done before carrying out the steps below.

12.1.5.1 Charge the Water

For domestic hot water tank


1. Set the Domestic Hot Water Tank Discharge (Drain Tap) ⑨ to “CLOSE”.



2. Set all taps/showers to “OPEN”.
3. Starts filling water into the domestic hot water tank via the tube connector ③. After 10-30 minutes, water should come out of the tap or shower. If the water does not run, contact your local authorized dealer.
4. Check and make sure no water leaking at the tube connecting points.
5. Set the Domestic Hot Water Tank Discharge (Drain Tap) ⑨ to “OPEN” for 10 seconds to release air from this pipeline. Then set it to “CLOSE”.
6. Turn the Safety Relief Valve ⑳ knob counterclockwise slightly and hold for 10 seconds to release air from this pipeline. Then recover the knob to original position.
7. Ensure Step 5 & 6 is carried out each time after charging water to Domestic Hot Water Tank.
8. Turn the Safety Relief Valve ⑳ knob counterclockwise to prevent back pressure to the valve.

For Space heating/cooling

1. Start filling water into the space heating/cooling circuit through the tube connector ① (with pressure more than 1 bar (0.1 MPa)).
2. If water is flowing through the drain pipe of the pressure relief valve, stop filling water. (Check the Outdoor Unit)
3. Turn on the tank unit.
4. Remote control menu → Installer setup → Service setup → Pump maximum speed → Turn on the pump.
5. Ensure that the water pump is working.
6. Check and make sure no water leaking at the tube connecting points.



12.1.5.2 Discharge the Water

For domestic hot water tank


1. Turn OFF the power supply.
 2. Set the Domestic Hot Water Tank Discharge (Drain Tap) ⑨ to “OPEN”.
 3. Open the tap/shower to allow air to enter.
 4. Turn the Safety Relief Valve ⑳ knob counterclockwise slightly and hold it until all air is released from this pipeline. Then recover the knob to its original position after ensured the pipeline is emptied.
 5. After discharge, set the Domestic Hot Water Tank Discharge (Drain Tap) ⑨ to “CLOSE”.
- * When discharging the water from the tank, also discharge the water from the outdoor unit. In particular, always discharge the water in the magnetic water filter. (may be damaged by freezing).

12.1.6 Reconfirmation

12.1.6.1 Check Water Pressure

* (0.50 bar = 0.05 MPa)

Water pressure should not be lower than 0.5 bar.
(Check the water pressure by the remote controller.) If necessary, fill Space Heating/Cooling pipes with water (through the tube connector ② on the outdoor unit).




12.1.6.1.1 Special Installation Patterns

Special construction patterns mentioned here refer to the case where there is a substantial difference in elevation (e.g. more than 10 m) between the outdoor unit installation and the Panel/Floor heater (or indoor unit).


In this case, attention must be paid since incorrect water filling during installation may prevent the system from operating correctly and may cause water leak.

① When outdoor unit is located below and Panel/Floor heater is 30 m above it



- Pressure checked by remote controller: 3.5~4 bar. (at an elevation difference of 30 m)
- When installing an extra pump, connect it to the water outlet of the outdoor unit. (If installed to the water inlet, the safety valve is activated and the water is drained)

② When outdoor unit is located above and Panel/Floor heater is 30 m below it




- Pressure checked by remote controller: 0.5~1.0 bar. (at an elevation difference of 30 m)
- When installing an extra pump, connect it to the water outlet from the tank unit to the outdoor unit.

Elevation difference between outdoor unit and tank unit		Water pressure in outdoor unit
Outdoor unit above the tank unit.	Up to 30 m	0.5~1.0bar
	Up to 20 m	1.0~2.0bar
	Up to 10 m	1.0~3.0bar
Outdoor unit below the tank unit.	Up to 10 m	1.5~4.0bar
	Up to 20 m	2.5~4.0bar
	Up to 30 m	3.5~4.0bar

12.1.6.2 Check Pressure Relief Valve

*Pressure relief valve is located on outdoor unit.

1. Pull the lever in the horizontal direction and confirm that the pressure relief valve works properly.
2. Release the lever when water comes out of the drain pipe of the pressure relief valve. (While the air continues to come out of the drain pipe, keep raising the lever to completely discharge the air.)
3. Confirm that the water from the drain pipe stops.
4. If water is leaking, pull the lever several times and return it to make sure the water stops.
5. If water keeps coming out of the drain, drain water. Turn off the system and contact your local authorized dealer.



12.1.6.3 Check Air Accumulation

- Open the air vent plugs on the heating panel, fan convector, etc., and remove the air accumulated in the equipment and piping.
- If the outdoor unit and indoor unit are installed on different floors, open the air vent plug on the water plug of the outdoor unit and the air vent plug on the heater bottle inside the indoor unit to remove the air (note that water will come out).

12.1.6.4 Expansion Vessel (11) Pre Pressure Checking

12.1.6.4.1 For Space Heating/Cooling

- The tank unit is equipped with an expansion vessel with the capacity of 12 L and the initial pressure of 1 bar.
- The total volume of water in the system should not exceed 200 L. (The volume in the pipe of the tank unit is approximately 5 L).
- If the total water volume exceeds 200 L, add an expansion vessel. (Field supply)
- The installed height difference of the water circuit of the system should not exceed 30 m. (Extra pump may be required).
*However, in case of 30 m, set the pressure in the circulation circuit to 0.5~1.0 bar. Higher than 1.0 bar may cause water leakage due to component breakage.

12.1.6.5 Check RCCB/ELCB

Ensure the RCCB/ELCB is set to "ON" condition before checking RCCB/ELCB.

Turn on the tank unit.

This test can only be performed when power is supplied to the tank unit.

⚠ WARNING

When power is supplied to the tank unit, take care not to touch any part other than RCCB/ELCB test button. Else, electrical shock may happen. Before obtaining access to terminals, all supply circuits must be disconnected.

Press the TEST button on the RCCB/ELCB. The lever would turn down if it functions normal.

- If the RCCB/ELCB malfunctions, contact authorized dealer.
- Turn off the tank unit.
- If the RCCB/ELCB operates correctly, set the lever to 'ON' again after the test.


12.1.7 Installation when Remote Controller is Used as a Room Thermostat

- The remote controller (1) mounted to the tank unit can be moved to the room and used as a room thermostat.

12.1.7.1 Installation Location

- Install at a height of 1 to 1.5 m above the floor (where the average room temperature can be detected).
- Install vertically against the wall.
- Avoid the following locations for installation.
 1. By the window, etc. where is exposed to direct sunlight or direct air
 2. In the shadow or backside of objects deviated from the room airflow
 3. Location where condensation occurs (Remote Controller is not moisture proof or drip proof)
 4. Location near heat source
 5. Uneven surface
- Keep distance of 1 m or more from the TV, radio and PC. (Cause of fuzzy image or noise)


12.1.7.2 Wiring the Remote Control




- Remote Controller cable shall be (2 × min 0.3 mm²) of double insulation PVC-sheathed or rubber sheathed cable. Total cable length shall be 50 m or less.
- Take care not to connect cables to other terminals on the tank unit (e.g. power supply wiring terminals). Malfunction may occur.
- Do not bundle together with the power source wiring or store in the same metal tube. Operation error may occur.
- When using the 2nd. Remote Controller (option), connect it to the terminal of the tank unit by tightening it together.

12.1.7.3 Remove the Remote Controller from the Tank Unit


1. Remove both the left decoration panel (2) and the right decoration panel (3) from the front panel (17) while pressing gently from behind.




2. Remove the 4 screws and remove the holder together with the remote controller (1).



3. Remove the body from the base.




4. Remove the wiring between the remote controller (1) and the tank unit terminal.



12.1.7.4 Mounting the Remote Controller


For exposure type

Preparation: Drill 2 holes for screws with a screwdriver.




For embedded type

Preparation: Drill 2 holes for screws with a screwdriver.



12.1.7.5 Replace the Remote Controller Cover

- In order to plug the hole after the remote controller has been removed, fit a remote controller case [5] in place of the removed remote controller.
 - Refer Section "Remove the remote controller from the tank unit" for removing the remote controller.
 - Remove the body from the base of the remote controller case [5].



- Reverse steps 1-4 under "Remove the remote controller from the tank unit" to secure the remote controller case [5] to the tank unit.


12.1.8 Test Run

- Before test run, ensure that the following items are checked.
 - Pipework are properly done.
 - Electric cable connecting work are properly done.
 - Tank Unit is filled up with water and trapped air is released.
 - Please turn on the power supply after filling the tank until full.
- Switch ON the power supply of the Tank Unit. Set the Tank Unit RCCB/ELCB to "ON" condition. Then, please refer to the Operation Instruction for operation of Remote Controller ①.

Note:

During winter, turn on the power supply and standby the unit for at least 15 minutes before test run. Allow sufficient time to warm up refrigerant and prevent wrong error code judgement.

- For normal operation, the water pressure reading should be in between 0.5 bar and 4 bar (0.05 MPa and 0.4 MPa). If necessary, adjust the speed of the water pump to bring it into the normal water pressure operating range. If adjusting the speed of the water pump does not solve the problem, contact a local authorized dealer.
- For the WH-ADC0316M9E8AN1, WH-ADC0916M3E5AN1, make sure that the 'electric anode icon' on the remote controller ① is lit.



- After test run, clean the magnetic water filter set with reference to "Maintenance for magnetic water filter" in the Installation Manual of the AIR-TO-WATER HEATPUMP OUTDOOR UNIT. Reinstall it after the cleaning is finished.

12.1.8.1 Check Water Flow of Water Circuit

Ensure that the air purge operation is carried out to remove air from the pipes.

Select Installer setup → Service setup → Pump maximum speed → Air purge.

Confirm the maximum water flow during main pump operation not less than 25 l/min.

* Water flow can be check in Service setup (Pump maximum speed)


[Heating operation at low water temperature with lower water flow may trigger "H75" during defrost process.]

* If there is no water flow or H62 is displayed, stop pump operation and release the air (see "CHECK AIR ACCUMULATION").

12.1.8.2 Reset Overload Protector (10)

Overload protector (10) is a safety device to prevent water overheating. If the overload protector (10) is activated, reset it using the following procedure.

1. Remove the cover.
2. Reset the overload protector (10) by gently pressing the central button with the test pen.
3. Secure the cover in place as before.



Press this button with a test pen to reset (10).

12.1.9 Maintenance

- To ensure the safety and optimum performance of the tank unit, seasonal inspections of the tank unit and functional checks of RCCB/ELCB, field wiring and pipe should be carried out on a regular basis. This maintenance and scheduled inspection should be carried out by authorized dealer.

12.1.9.1 Maintenance for Safety Relief Valve (21)

- To ensure the pipe is not blocked and to remove lime deposit, it is strongly recommended to operate the valve by turn the knob counter clockwise and confirm free water flow through discharge pipe at regular intervals.


If the hot water supply is not used for more than 60 days, drain the stagnant water in the tank unit.

12.1.9.2 Maintenance for Expansion Vessel (11)

- Regular maintenance of the expansion vessel (at least once a year) is recommended and should be performed by an authorized dealer. First, make sure that the expansion or pressure tank is completely drained of water, that the system is switched off, and that there are no live electrical components. If you need to reset the preload pressure, set it to 1bar.

12.1.9.3 How to Access the Expansion Vessel

Open the control board.




Expansion vessel is here

12.1.9.4 Installation of Ventilation Unit on Top of Tank Unit (Optional)

- If the ventilation unit is installed above the tank unit, refer to the installation instructions for the ventilation unit.

CAUTION

Before installing the ventilation unit, fix the legs supplied with the ventilation unit to the half-punched holes in the tank unit top panel. Heavy ventilation units may fall and cause injury.



12.2 Appendix



12.2.1 Variation of System

This section introduces variation of various systems using Air-To-Water Heatpump and actual setting method.
(Note): For this model, the Zone 1 external room thermistor and Zone 1 external room thermostat must always be connected to the main PCB (main indoor PCB).

12.2.1.1 Introduce Applications Related to Temperature Setting


12.2.1.1.1 Temperature Setting Variation for Heating

1. Remote Controller




Connect floor heating and radiators directly to the tank unit.
The remote controller is located on the tank unit.
This is the basic form of the simplest system.

2. Room Thermostat




The tank unit controls the HP and circulation pumps by receiving control signals (ON/OFF) from the remote controller. There is a build-in thermistor in the remote controller.




Connect floor heating and radiators directly to the tank unit.
Remove the remote controller from the tank unit and install it in the room where the floor heating is installed.
This is an application that uses remote controller as Room Thermostat.

3. External Room Thermostat



Connect floor heating and radiators directly to the tank unit.
 The remote controller is located on the tank unit.
 Install separate External Room Thermostat (field supply) in the room where floor heating is installed.
 This is an application that uses External Room Thermostat.

4. Room Thermistor




Connect floor heating or radiator directly to the tank unit.
 The remote controller is located on the tank unit.
 An external room thermistor (specified by Panasonic) is installed in the room where the floor heating is installed.
 This is an application that uses an external room thermistor.

There are two ways of setting the circulating water temperature.
 Direct: Sets the circulating water temperature directly (fixed value).
 Correction curve: sets the circulating water temperature according to the outside temperature.
 In case of Room thermistor, the compensation curve is shifted according to the thermo ON/OFF situation.

- (Example) If room temperature increasing speed is;
 If very slow → Shift the compensation curve upwards
 If very fast → Shift compensation curve downwards


12.2.1.1.2 Examples of Installations

Floor heating 1 + Floor heating 2




Connect Floor heating to the 2 circuits via buffer tank as shown in the figure. Install mixing valves, pumps and thermistors (specified by Panasonic) on both circuits. Remove the remote controller from the tank unit and attach it to either circuit to use as a Room Thermostat. Install an external Room Thermostat (field-supply) on a another circuit. Both circuits can set the circulating water temperature independently. Install the buffer tank thermistor on the buffer tank. The buffer tank connection settings and the ΔT temperature settings for heating operation are required separately. This system requires an Optional PCB (CZ-NS6P). Note: Buffer tank thermistor must be connected to main indoor PCB only.

Floor heating + Radiator



Connect Floor heating and radiators to the 2 circuits via buffer tank, as shown in the figure. Install pumps and thermistors (specified by Panasonic) on both circuits. Install a mixing valve in the circuit with lower temperature among the 2 circuits. (Generally, where floor heating and radiator circuits are installed in 2 zones, install mixing valve in the floor heating circuit.) The remote controller is located on the tank unit. The temperature setting selects the circulating water temperature for both circuits. Both circuits can set the circulating water temperature independently. Install the buffer tank thermistor on the buffer tank. The buffer tank connection settings and the ΔT temperature settings for heating operation are required separately. This system requires the Optional PCB (CZ-NS6P). Note that if there is no mixing valve on the secondary side, the circulating water temperature may be higher than the set temperature. Note: Buffer tank thermistor must be connected to main indoor PCB only.


Floor heating + Swimming pool



Connect floor heating and swimming pool to the 2 circuits via buffer tank, as shown in the figure. Install mixing valves, pumps and thermistors (specified by Panasonic) on both circuits. Additional pool heat exchanger, pool pumps and pool sensor are then installed in the pool circuit. Remove the remote controller from the tank unit and install it in the room where the floor heating is installed. Floor heating and pool circulation water temperatures can be set separately. Install buffer tank thermistor on the buffer tank. The buffer tank connection settings and the ΔT temperature settings for heating operation are required separately. This system requires the Optional PCB (CZ-NS6P).


※ Be sure to connect the pool to "Zone 2".
When connected to a swimming pool, operating in 'Cool' will stop the pool operation.
Note: Buffer tank thermistor must be connected to main indoor PCB only.

Swimming pool only



This is an application that connect to the swimming pool only. Connect the pool heat exchanger directly to the tank unit without using buffer tank. Install a pool pump and pool thermistor (specified by Panasonic) at the secondary side of the pool heat exchanger. The pool temperature can be set with a remote controller. This system requires the Optional PCB (CZ-NS6P). The cooling mode cannot be selected for this application. (Not displayed on the remote controller).

Simple 2 zone (Floor heating + Radiators)



Setting of remote controller	
Installer setup	
System setup	Optional PCB connectivity - Yes
Zone & Sensor: - 2-zone system	
Zone 1: Sensor	Water temperature
Zone 2: Sensor	Room
	Water temperature
Operation setup	
Heat	ΔT for heating ON - 1°C
Cool	ΔT for cooling ON - 1°C

This is an example of simple 2 zone control without buffer tank.

The built-in pump in the tank unit acts as the pump for zone 1.

Install mixing valve, pump and thermistor (specified by Panasonic) at zone 2 circuit.

The temperature in Zone 1 is not adjustable, so always assign the hot side to Zone 1.

To display the temperature of zone 1 on the remote controller, zone 1 thermistor is required.

The circulating water temperature for both circuits can be set independently.

(However, the temperature of high temperature side and low temperature side cannot be reversed.)

This system requires the Optional PCB (CZ-NS6P).


(Note)

- Thermistor 1 has no direct influence on the operation. However, if thermistor 1 is not installed, an error will occur.
- Adjust the flow rate so that zone 1 and zone 2 are balanced. If not correctly adjusted, performance may be affected.

(If the pump flow rate in zone 2 is too high, hot water may not flow to zone 1)

The flow rate can be checked from “Actuator Check” under maintenance menu.

Buffer tank connection



Setting of remote controller	
Installer setup	
System setup	Optional PCB connectivity - No
Buffer tank connection - Yes	ΔT for Buffer tank


This is an application that connects the Buffer tank unit to the tank unit.

The temperature of the buffer tank is detected by a buffer tank thermistor (specified by Panasonic).

If Optional PCB is not connected, external pump can be used for circulation in the floor heating circuit.

Note: Buffer tank thermistor must be connected to main indoor PCB only.

Buffer tank + Solar



Setting of remote controller	
Installer setup	
System setup	
Optional PCB connectivity	- Yes
Buffer tank connection	- Yes
ΔT for Buffer tank	
Solar connection	- Yes
Buffer tank	
ΔT	Turn ON
ΔT	Turn OFF
Anti freeze	
Hi limit	

This is an application that connect the buffer tank unit to the tank unit and then to the solar water heater to heat the Buffer tank.

The temperature of the buffer tank is detected by a buffer tank thermistor (specified by Panasonic).

The temperature of the solar panel is detected by a solar thermistor (specified by Panasonic).

Buffer tanks are stand-alone tanks with built-in solar heat exchange coils.


During winter season, solar pump for circuit protection will be activated continuously. If does not want to activate the solar pump operation, please use glycol and set the anti-freezing operation start temperature to -20°C.

Heat accumulation operates automatically by comparing the temperature of tank thermistor and solar thermistor.

This system requires the Optional PCB (CZ-NS6P).

Note: Buffer tank thermistor must be connected to main indoor PCB only.

Boiler connection



Setting of remote controller	
Installer setup	
System setup	
Optional PCB connectivity	- Yes
Bivalent	- Yes
Turn ON	outdoor temp
Control pattern	

This is an application that connects the boiler to the tank unit, to compensate for insufficient capacity by operate boiler when outdoor temperature drops & heat pump capacity is insufficient.

Boiler is connected parallel with heat pump and used as heating circuit.

The boiler output can be controlled either by SG-ready input from a board (sold separately) or by automatic control via three mode selection patterns.

(Operation setting of boiler shall be responsible by installer.)

This system requires the Optional PCB (CZ-NS6P) for SG-ready input control.

Depending on the settings of the boiler, it is recommended to install buffer tank as temperature of circulating water may get higher. (In particular, if the advanced parallel setting is selected, it must be connected to a buffer tank.)

Note: Buffer tank thermistor must be connected to main indoor PCB only.

⚠ WARNING

Panasonic is NOT responsible for incorrect or unsafe situation of the boiler system.

⚠ CAUTION


Make sure the boiler and its integration in the system complies with applicable legislation.
Ensure that the return water temperature from the heating circuit to the tank unit does not exceed 70°C.
Boiler is turned off by safety control when the water temperature of the heating circuit exceed 85°C.

12.2.2 How to Fix the Cables


12.2.2.1 Connection with External Device (Optional)

- All connections shall follow to the local national wiring standard.
 - It is strongly recommended to use manufacturer-recommended parts and accessories for installation.
 - For connection to main PCB ⑥.
1. Two-way valve shall be spring and electronic type, refer to “Field Supply Accessories” table for details. Valve cable shall be (3 × min 1.5 mm²), of type designation 60245 IEC 57 or heavier, or similarly double insulation sheathed cable.
*note: - Two-way Valve shall be CE marking compliance component.
- Maximum load for the valve is 12VA.
 2. Room thermostat cable must be (4 or 3 × min 0.5 mm²), of type designation 60245 IEC 57 or heavier cord, or similarly double insulation sheathed cable.
 3. Extra pump cable shall be (2 × min 1.5 mm²), of type designation 60245 IEC 57 or heavier.
 4. Boiler contact cable shall be (2 × min 0.5 mm²), of type designation 60245 IEC 57 or heavier.
 5. External control shall be connected to 1-pole switch with min 3.0 mm contact gap. Its cable must be (2 × min 0.5 mm²), double insulation layer of PVC-sheathed or rubber-sheathed cable.
*note: - Switch used shall be CE compliance component.
- Maximum operating current shall be less than 3A_{rms}.
 6. Room sensor zone 1 cable shall be (2 × min 0.3 mm²) double insulation layer of PVC-sheathed or rubber-sheathed.
 7. Outdoor air sensor cable shall be (2 × min 0.3 mm²) double insulation layer of PVC-sheathed or rubber-sheathed.
 8. Buffer tank sensor cable shall be (2 × min 0.3 mm²), double insulation layer (with insulation strength of minimum 30V) of PVC-sheathed or rubber-sheathed cable.


Please wire referring to the diagram below. Wire according to the solid or dotted lines. (Solid line priority. Can be used in combination)



How to guide the optional cables and power supply cord connecting (view without internal wiring)



- For connection to Optional PCB 7.
1. By connecting Optional PCB, 2 Zone temperature control can be achieved. Please connect mixing valves, water pumps and thermistors in zone 1 and zone 2 to each terminals in Optional PCB. Temperature of each zone can be controlled independently by remote controller.
 2. Pump zone 1 and zone 2 cable shall be (2 × min 1.5 mm²), of type designation 60245 IEC 57 or heavier.
 3. Solar pump cable shall be (2 × min 1.5 mm²), of type designation 60245 IEC 57 or heavier.
 4. Pool pump cable shall be (2 × min 1.5 mm²), of type designation 60245 IEC 57 or heavier.
 5. Room thermostat zone 2 cable shall be (4 or 3 × min 0.5 mm²), of type designation 60245 IEC 57 or heavier.
 6. Mixing valve zone 1 and zone 2 cable shall be (3 × min 1.5 mm²), of type designation 60245 IEC 57 or heavier.
 7. Room sensor zone 1 and zone 2 cable shall be (2 × min 0.3 mm²), double insulation layer (with insulation strength of minimum 30V) of PVC-sheathed or rubber-sheathed cable.
 8. Pool water sensor and solar sensor cable shall be (2 × min 0.3 mm²), double insulation layer (with insulation strength of minimum 30V) of PVC-sheathed or rubber-sheathed cable.
 9. Water sensor zone 1 and zone 2 cable shall be (2 × min 0.3 mm²), double insulation layer of PVC-sheathed or rubber-sheathed cable.
 10. Demand signal cable shall be (2 × min 0.3 mm²), double insulation layer of PVC-sheathed or rubber-sheathed cable.
 11. SG signal cable shall be (3 × min 0.3 mm²), double insulation layer of PVC-sheathed or rubber-sheathed cable.
 12. Heat/Cool switch cable shall be (2 × min 0.3 mm²), double insulation layer of PVC-sheathed or rubber-sheathed cable.
 13. External compressor switch cable shall be (2 × min 0.3 mm²), double insulation layer of PVC-sheathed or rubber-sheathed cable.




* For installation on how to route lead wires between Optional PCB 7 and main PCB 6, please refer to the "Optional PCB (CZ-NS6P)" manual.

12.2.2.2 Guide Optional Cables and Power Supply Cables to Bushings

 CAUTION
Wire guiding shall be free from hot surfaces. Else, cable insulator damage and electrical shock may happen.
Wire ways shall be smooth and free from sharp edges. Else, cable insulator damage and electrical shock may happen.

- Use either “Combination-1” or “Combination-2” for guiding Optional Cables and Power Supply Cables to Bushings.




- A-1 and A-2 bushings are used for
 - Power Supply cable
 - Indoor unit/Outdoor unit connecting cable
 - Pump zone 1 cable
 - Pump zone 2 cable
 - Solar pump cable
 - Room thermostat zone 1 cable
 - Room thermostat zone 2 cable
 - Mixing valve zone 1 cable
 - Mixing valve zone 2 cable
 - 2-way valve cable
 - Extra pump cable
 - Boiler contact cable
- D-1 and D-2's bushings are used for the following
 - External control cable
 - Outdoor air sensor cable
 - Remote controller cable
 - Room sensor zone 1 cable
 - Room sensor zone 2 cable
 - Buffer tank sensor cable
 - Pool sensor cable
 - Water sensor zone 1 cable
 - Water sensor zone 2 cable
 - Demand signal cable
 - Solar sensor cable
 - SG signal cable
 - Heat/Cool switch cable
 - External compressor switch cable
- Ensure all sensor cables are not in touching with the front panel.
- Once all wiring work done, tie the cable with the banding strap (field supply), to prevent them touching with hot surfaces such as Heater Assembly.

12.2.2.3 Connecting Cables Length

When connecting cables between the tank unit and external devices, the cable length must not exceed the maximum lengths given in the table.

External device	Maximum cable length (m)
2-way valve	50
Mixing valve	50
Room Thermostat	50
Extra pump	50
Solar pump	50
Pool pump	50
Zone pump	50
Boiler contact/Defrost signal	50
External control	50
Room sensor	30
Outdoor air sensor	30
Buffer tank sensor	30
Pool water sensor	30
Solar sensor	30
Water sensor	30
Demand signal	50
SG signal	50
Heat/Cool switch	50
External compressor switch	50

12.2.2.4 Connection of Main PCB



■ Signal inputs

Optional Thermostat	L N=AC230V, Heat, Cool=Thermostat heat, Cool terminal
External control	Dry contact Open=not operate, Short=operate (system setup required) Operation can be switched on and off by an external switch
Remote controller	Already connected (use 2-core wire for relocation and extension. The total length of the cable shall be 50m or less.)


■ Outputs

3-way valve	AC230V N=Neutral Open, Close=direction (for switching the circuit when connecting a DHW tank)	AC230V, 12 VA
2-way valve	AC230V N=Neutral Open, Close (prevent water circuit pass in Cool mode)	AC230V, 12 VA
Extra pump	AC230V (for use when the pump capacity of the tank unit is insufficient).	AC230V, 0.6 A max.
Boiler contact/ Defrost signal	Dry contact (System setup required)	

■ Thermistor inputs

Zone 1 room sensor	PAW-A2W-TSRT
Outdoor air sensor	PAW-A2W-TSOD (total cable length 30 m or less)

12.2.2.5 Connection of Optional PCB (CZ-NS6P)



■ Signal inputs

Optional Thermostat	L N=AC230V, Heat, Cool=Thermostat Heat/Cool terminals
SG signal	Dry contact Vcc-Bit1, Vcc-Bit2 Open/short (system setup required) Switching SW (connect to 2-contact controller).
Heat/Cool SW	Dry contacts Open=Heat, short=Cool (system setup required)
External comp. SW	Dry contact Open=Comp. OFF, short=Comp. ON (System setup required).
Demand signal	DC 0-10 V (System setup required) Connect to a controller with DC 0-10 V.

■ Outputs

Mixing valve	AC230V N=Neutral Open, Close = mixed direction Operating time: 30 s to 120 s	AC230V, 6 VA
Pool pump	AC230V	AC230V, 0.6 A max.
Solar pump	AC230V	AC230V, 0.6 A max.
Zone pump	AC230V	AC230V, 0.6 A max.

■ Thermistor inputs

Zone room sensor	PAW-A2W-TSRT
Buffer tank sensor	PAW-A2W-TSBU
Pool water sensor	PAW-A2W-TSHC
Zone water sensor	PAW-A2W-TSHC
Solar sensor	PAW-A2W-TSSO

12.2.2.6 Recommended External Device Specification


This section describes the external devices (optional) recommended by Panasonic. Always use the correct external devices when installing the system.

For optional sensor

1. Buffer tank sensor: PAW-A2W-TSBU

Use for measurement of the buffer tank temperature.


Insert the sensor into the sensor pocket and affix it to the buffer tank surface.



2. Zone water sensor: PAW-A2W-TSHC

Use to detect water temperature of the control zone.


Attach to water pipework using stainless steel metal straps and contact paste (both are included).



3. Outdoor sensor: PAW-A2W-TSOD


If the outdoor unit's installation location is exposed to direct sunlight, the outdoor air temperature sensor will not be able to correctly measure the actual outdoor temperature.

In this case, the outdoor temperature can be measured more accurately by fixing the optional outdoor temperature sensor in the appropriate location.



4. Room sensor: PAW-A2W-TSRT


Install room temperature sensor in room where room temperature control is required.



5. Solar sensor: PAW-A2W-TSSO

Use to measure the temperature of solar panel.

Insert the sensor into the sensor pocket and paste it to the solar panel surface.




6. See the table below for sensor characteristics of the above sensors.


Temperature. (°C)	Resistance value (kΩ)
30	5.326
25	6.523
20	8.044
15	9.980
10	12.443
5	15.604
0	19.70
-5	25.05
-10	32.10
-15	41.45
-20	53.92
-25	70.53
-30	93.05
-35	124.24
-40	167.82

Temperature. (°C)	Resistance value (kΩ)
150	0.147
140	0.186
130	0.236
120	0.302
110	0.390
100	0.511
90	0.686
80	0.932
70	1.279
65	1.504
60	1.777
55	2.106
50	2.508
45	3.003
40	3.615
35	4.375

For optional pump
 Power supply: AC230V/50 Hz, <500 W
 Recommended part: Yonos PICO 1.0 25/1-8: Made by Wilo



For optional mixing valve
 Power supply: AC230V/50 Hz (Input open/Output close)
 Operating time: 120 seconds.
 Recommended part: 13020800: Made by ESBE




WARNING


This section is for authorized and licensed electrician/water system installer only. Work behind the front plate secured by screws must only be carried out under supervision of qualified contractor, installation engineer or service person.

12.2.2.7 Network Adaptor 4 Installation


1. Insert a flat head screwdriver into the slot on the top of the adaptor and remove the cover.



2. Connect cable coming out from the left side of the network adaptor holder to the connector inside the adaptor.



3. Pull the CN-CNT cable through the hole in the bottom of the adaptor and re-attach the front cover to the back cover.




4. Fix the Network Adaptor 4 to Network Adaptor Holder.
 Guide the cable as shown in the diagram so that external forces cannot act on the connector in the adaptor.

12.2.2.8 Connection of M-Bus or Modbus, etc.

When connecting devices such as Panasonic A2W compatible M-Bus or Modbus, etc.


- It will be necessary to change the connection position of the CZ-TAW1* on the PCB.



- ① Replace the lead wire connector of CZ-TAW1* connected to CN-CNT2 with CN-CNT.
- ② Insert the M-Bus or Modbus, etc. lead wire connector into CN-CNT2.

When connecting Panasonic A2W Optional PCB to devices such as M-Bus or Modbus, etc.

- It will be necessary to change the connection position of the CZ-TAW1* on the PCB.




- ① Insert the Optional PCB lead wire connector into CN-CNT.
- ② Replace the lead wire connector of CZ-TAW1* connected to CN-CNT2 with CN-CNT on Optional PCB.
- ③ Insert the M-Bus or Modbus, etc. lead wire connector into CN-CNT2.

12.2.3 System Installation


12.2.3.1 Remote Controller Outline

The LCD display as shown in this manual are for instructional purpose only, and may differ from the actual unit.



Name	Function
A: Main screen	Display information
B: Menu	Open/Close the main menu
C: Triangle (Move)	Select and change item
D: Operate	Start/Stop operation
E: Back	Back to previous item
F: Quick Menu	Open/Close the Quick menu
G: Enter	Confirm

LCD Display
(Actual - Dark background with white icons).




Name	Function										
1: Function icon	Displays the set functions/status.										
	<table border="0"> <tr> <td> Holiday mode</td> <td> Demand control</td> </tr> <tr> <td> Weekly timer</td> <td> Room heater</td> </tr> <tr> <td> Quiet mode</td> <td> Tank heater</td> </tr> <tr> <td> Remote controller room thermostat</td> <td> Solar</td> </tr> <tr> <td> Powerful mode</td> <td> Boiler</td> </tr> </table>	Holiday mode	Demand control	Weekly timer	Room heater	Quiet mode	Tank heater	Remote controller room thermostat	Solar	Powerful mode	Boiler
Holiday mode	Demand control										
Weekly timer	Room heater										
Quiet mode	Tank heater										
Remote controller room thermostat	Solar										
Powerful mode	Boiler										
2: Water pressure (circulation circuit) (1.50)	Displays water pressure in bar (blinks when less than 0.5)										
3: Mode	Displays the setting mode and the current mode status.										
	<table border="0"> <tr> <td> Heating</td> <td> Cooling</td> <td> Hot water supply</td> <td> Auto heating</td> <td> Auto cooling</td> </tr> <tr> <td> Auto</td> <td> Heat pump operating</td> <td></td> <td></td> <td></td> </tr> </table>	Heating	Cooling	Hot water supply	Auto heating	Auto cooling	Auto	Heat pump operating			
Heating	Cooling	Hot water supply	Auto heating	Auto cooling							
Auto	Heat pump operating										
4: Temp setting	<table border="0"> <tr> <td> Set room temp</td> <td> Compensation curve</td> <td> Set direct water temp</td> <td> Set pool temp</td> </tr> </table>	Set room temp	Compensation curve	Set direct water temp	Set pool temp						
Set room temp	Compensation curve	Set direct water temp	Set pool temp								
5: Display Heat temp	Displays current heating temperature (it is set temperature when enclosed by line)										
6: Outdoor temp	Displays outdoor temperature										
7: Display tank temp	Displays current tank temperature (it is set temperature when enclosed by line)										
8: Electrical anodes	<table border="0"> <tr> <td> Normal</td> <td> Abnormal (Flashing)</td> <td> Not used (Hidden)</td> </tr> </table>	Normal	Abnormal (Flashing)	Not used (Hidden)							
Normal	Abnormal (Flashing)	Not used (Hidden)									


First time of power ON (Start of installation)



When the power is ON, firstly the initialization screen appears (approx. 10 sec)




When the initialization screen ends, it turns to normal screen.




When any button is pressed, language setting screen appears.
(NOTE) If initial setting is not performed, it does not go into menu.
When there are two remote controllers installed from the beginning, the first remote controller used to set and confirm language will be recognised as the main remote controller.

↓ Set language & confirm




When language is set, setting screen of time display appears (24h/am/pm)

↓ Set time display & confirm




YYYY/MM/DD/Time setup screen appears


↓ Set YY/MM/DD/Time & confirm



Select 'No' to confirm, before continuing with the operation, a caution message confirming the installation of the outdoor front grille will be displayed.



↓ Set Yes & confirm if outdoor front grille has been installed




Back to initial screen


↓ Press Menu and select Installer setup


Main menu	12:00 pm, Mon
System check	
Personal setup	
Service contact	
Installer setup	
▲ Select	[↵] Confirm

↓ Confirm to go into Installer setup

12.2.3.2 Installer Setup







12.2.3.3 System Setup

<div style="border: 1px solid black; display: inline-block; padding: 2px 5px;">1. Optional PCB connectivity</div>	<div style="border: 1px solid black; display: inline-block; padding: 2px 5px;">Initial setting: No</div>	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: right;">System setup</td> <td style="text-align: right;">12:00 pm, Mon</td> </tr> <tr> <td colspan="2" style="background-color: black; color: white;">Optional PCB connectivity</td> </tr> <tr> <td colspan="2">Zone & Sensor</td> </tr> <tr> <td colspan="2">Heater capacity</td> </tr> <tr> <td colspan="2">Anti freezing</td> </tr> <tr> <td style="text-align: right;">▼ Select</td> <td style="text-align: right;">[↵] Confirm</td> </tr> </table>	System setup	12:00 pm, Mon	Optional PCB connectivity		Zone & Sensor		Heater capacity		Anti freezing		▼ Select	[↵] Confirm
System setup	12:00 pm, Mon													
Optional PCB connectivity														
Zone & Sensor														
Heater capacity														
Anti freezing														
▼ Select	[↵] Confirm													

If function below is necessary, please purchase and install Optional PCB.
Please select Yes after installing Optional PCB.

- 2-zone control
- Pool
- Solar
- External error signal output
- Demand control
- SG ready
- Stop heat source unit by external SW
- Heat-Cool SW

<div style="border: 1px solid black; display: inline-block; padding: 2px 5px;">2. Zone & Sensor</div>	<div style="border: 1px solid black; display: inline-block; padding: 2px 5px;">Initial setting: Room and Water temp.</div>	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: right;">System setup</td> <td style="text-align: right;">12:00 pm, Mon</td> </tr> <tr> <td colspan="2" style="background-color: black; color: white;">Optional PCB connectivity</td> </tr> <tr> <td colspan="2" style="background-color: black; color: white;">Zone & Sensor</td> </tr> <tr> <td colspan="2">Heater capacity</td> </tr> <tr> <td colspan="2">Anti freezing</td> </tr> <tr> <td style="text-align: right;">⬆ Select</td> <td style="text-align: right;">[↵] Confirm</td> </tr> </table>	System setup	12:00 pm, Mon	Optional PCB connectivity		Zone & Sensor		Heater capacity		Anti freezing		⬆ Select	[↵] Confirm
System setup	12:00 pm, Mon													
Optional PCB connectivity														
Zone & Sensor														
Heater capacity														
Anti freezing														
⬆ Select	[↵] Confirm													

If no Optional PCB connectivity
Select sensor of room temperature control from the following 3 items

- ① Water temperature (circulation water temperature)
- ② Room thermostat (External or Internal)
- ③ Room thermistor

If there is Optional PCB connectivity

- ① Select either 1-zone control or 2-zone control.
If 1-zone control is selected, select either room or pool. If room is selected, select sensor.
If pool is selected, set ΔT for the pool.
If 2-zone control is selected, select sensor for zone 1, then set the same items as above for zone 2.

(NOTE) In a 2-zone system, pool function can be set at zone 2 only.

<div style="border: 1px solid black; display: inline-block; padding: 2px 5px;">3. Heater capacity</div>	<div style="border: 1px solid black; display: inline-block; padding: 2px 5px;">Initial setting: Depend on model</div>	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: right;">System setup</td> <td style="text-align: right;">12:00 pm, Mon</td> </tr> <tr> <td colspan="2" style="background-color: black; color: white;">Optional PCB connectivity</td> </tr> <tr> <td colspan="2" style="background-color: black; color: white;">Zone & Sensor</td> </tr> <tr> <td colspan="2" style="background-color: black; color: white;">Heater capacity</td> </tr> <tr> <td colspan="2">Anti freezing</td> </tr> <tr> <td style="text-align: right;">⬆ Select</td> <td style="text-align: right;">[↵] Confirm</td> </tr> </table>	System setup	12:00 pm, Mon	Optional PCB connectivity		Zone & Sensor		Heater capacity		Anti freezing		⬆ Select	[↵] Confirm
System setup	12:00 pm, Mon													
Optional PCB connectivity														
Zone & Sensor														
Heater capacity														
Anti freezing														
⬆ Select	[↵] Confirm													

If there is built-in Heater, set the selectable heater capacity.

(NOTE) There are models which cannot select Heater capacity.

<div style="border: 1px solid black; display: inline-block; padding: 2px 5px;">4. Anti freezing</div>	<div style="border: 1px solid black; display: inline-block; padding: 2px 5px;">Initial setting: Yes</div>	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: right;">System setup</td> <td style="text-align: right;">12:00 pm, Mon</td> </tr> <tr> <td colspan="2" style="background-color: black; color: white;">Optional PCB connectivity</td> </tr> <tr> <td colspan="2" style="background-color: black; color: white;">Zone & Sensor</td> </tr> <tr> <td colspan="2" style="background-color: black; color: white;">Heater capacity</td> </tr> <tr> <td colspan="2" style="background-color: black; color: white;">Anti freezing</td> </tr> <tr> <td style="text-align: right;">⬆ Select</td> <td style="text-align: right;">[↵] Confirm</td> </tr> </table>	System setup	12:00 pm, Mon	Optional PCB connectivity		Zone & Sensor		Heater capacity		Anti freezing		⬆ Select	[↵] Confirm
System setup	12:00 pm, Mon													
Optional PCB connectivity														
Zone & Sensor														
Heater capacity														
Anti freezing														
⬆ Select	[↵] Confirm													

Operate anti-freezing of water circulation circuit.
If select Yes, when the water temperature is reaching its freezing temperature, the circulation pump will start up. If the water temperature does not reach the pump stop temperature, back-up heater will be activated.

(NOTE) If set No, when the water temperature is reaching its freezing temperature or below 0°C, the water circulation circuit may freeze and cause malfunction.

<div style="border: 1px solid black; display: inline-block; padding: 2px 5px;">5. DHW capacity</div>	<div style="border: 1px solid black; display: inline-block; padding: 2px 5px;">Initial setting: Variable</div>	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: right;">System setup</td> <td style="text-align: right;">12:00 pm, Mon</td> </tr> <tr> <td colspan="2" style="background-color: black; color: white;">Zone & Sensor</td> </tr> <tr> <td colspan="2" style="background-color: black; color: white;">Heater capacity</td> </tr> <tr> <td colspan="2" style="background-color: black; color: white;">Anti freezing</td> </tr> <tr> <td colspan="2" style="background-color: black; color: white;">DHW capacity</td> </tr> <tr> <td style="text-align: right;">⬆ Select</td> <td style="text-align: right;">[↵] Confirm</td> </tr> </table>	System setup	12:00 pm, Mon	Zone & Sensor		Heater capacity		Anti freezing		DHW capacity		⬆ Select	[↵] Confirm
System setup	12:00 pm, Mon													
Zone & Sensor														
Heater capacity														
Anti freezing														
DHW capacity														
⬆ Select	[↵] Confirm													

Select "Variable"

- The heat pump runs with efficient boiling, which is an energy-saving mode.

However, if hot water usage is high and the tank water temperature is low, the heat pump will switch to fast heat-up mode, which uses higher heating capacity to heat up the tank. When "Efficiency" is selected in the "23. Heating control" setting, the tank heat-up process will be delayed until a much lower tank water temperature is reached, which improves the efficiency of the heating process. To ensure sufficient hot water, select either "Standard" in this setting or "Comfort" in the "23. Heating control" setting.

Select "Standard"

- The heat pump operates at its rated heating capacity during tank heating.

6. Buffer Tank connection

Initial setting: No

Select whether it is connected to buffer tank for heating or not.
 If buffer tank is used, please set Yes.
 Connect buffer tank thermistor and set, ΔT (ΔT use to increase primary side temp against secondary side target temp).
 If the buffer tank capacity is not so large, please set larger value for ΔT.

System setup	12:00 pm, Mon
Heater capacity	
Anti freezing	
Tank connection	
Buffer tank connection	
⬆ Select	[←] Confirm

7. Base pan heater

Initial setting: No

Select whether Base pan heater is installed or not.
 If set Yes, select to use either heater A or B.

A: Turn on Heater when heating with defrost operation only
 B: Turn on Heater at heating

System setup	12:00 pm, Mon
Anti freezing	
Tank connection	
Buffer tank connection	
Base pan heater	
⬆ Select	[←] Confirm

8. Alternative outdoor sensor

Initial setting: No

Set Yes if outdoor sensor is installed.
 Controlled by optional outdoor sensor without reading the outdoor sensor of heat pump unit.

System setup	12:00 pm, Mon
Tank connection	
Buffer tank connection	
Base pan heater	
Alternative outdoor sensor	
⬆ Select	[←] Confirm

9. Bivalent connection

Initial setting: No

Set if heat pump linked with boiler operation.
 Connect the start signal of the boiler in boiler contact terminal (main PCB).
 Set Bivalent connection to YES.
 After that, please begin setting according to remote controller instruction.
 Boiler icon will be displayed on remote controller top screen.

System setup	12:00 pm, Mon
Buffer tank connection	
Base pan heater	
Alternative outdoor sensor	
Bivalent connection	
⬆ Select	[←] Confirm

After Bivalent connection set to YES, there are three options of control pattern (SG Ready / Auto / Smart).

- 1) SG Ready (Only available to set when optional PCB set to YES)
 - SG Ready input from optional PCB terminal control ON/OFF of boiler and heat pump as below condition

SG signal		Operation pattern
Vcc-bit1	Vcc-bit2	
Open	Open	Heat pump OFF, Boiler OFF
Short	Open	Heat pump ON, Boiler OFF
Open	Short	Heat pump OFF, Boiler ON
Short	Short	Heat pump ON, Boiler ON

* This bivalent SG Ready input is sharing same terminal as [14. SG Ready] connection. Only one of these two setting can be set at the same time.

When one is set, another setting will reset to not set.

- 2) Auto

There are 3 different modes in the boiler auto pattern operation. Movement of each modes are shown below.


- ① Alternative (switch to boiler operation when drops below setting temperature)
- ② Parallel (allow boiler operation when drops below setting temperature)
- ③ Advanced Parallel (able to slightly delay boiler operation time of parallel operation)

When the boiler operation is "ON", "boiler contact" is "ON", "_(underscore)" will be displayed below the boiler icon.


Please set target temperature of boiler to be the same as heat pump temperature.

When boiler temperature is higher than heat pump temperature, zone temperature cannot be achieved if mixing valve is not installed.
 This product only allows one signal to control the boiler operation. Operation setting of boiler shall be responsible by installer.

Alternative mode




Parallel mode






Advanced Parallel mode

For heating




For DHW tank



In Advanced Parallel mode, setting for both heating and tank can be made simultaneously. During operation of "Heating/Tank" mode, when each time the mode is switched, the boiler output will be reset to OFF. Please have good understanding on the boiler control characteristic in order to select the optimal setting for the system.

3) Smart

There are Energy price (both electricity and boiler) and Schedule to be set on remote controller. Operation setting of Energy price and Schedule shall be responsible by installer. Based on these settings, system will calculate the final price for both electricity and boiler. When final price of Electricity is lower than Boiler's, heat pump will operate. When final price of Electricity is higher than Boiler's, boiler will operate.



10. External SW

Initial setting: No

Able to turn ON/OFF the operation by external switch.

System setup	12:00 pm, Mon
Base pan heater	
Alternative outdoor sensor	
Bivalent connection	
External SW	
⬆ Select	[↵] Confirm

11. Solar connection

Initial setting: No

Set when solar water heater is installed.

Setting include items below.

- ① Set either buffer tank or DHW tank for connection with solar water heater.
- ② Set temperature difference between solar panel thermistor and buffer tank or DHW tank thermistor to operate the solar pump.
- ③ Set temperature difference between solar panel thermistor and buffer tank or DHW tank thermistor to stop the solar pump.
- ④ Anti-freezing operation start temperature (please change setting based on usage of glycol.)
- ⑤ Solar pump stop operation when it exceeds high limit temperature (when tank temperature exceed designated temperature (70~90°C))

System setup	12:00 pm, Mon
Alternative outdoor sensor	
Bivalent connection	
External SW	
Solar connection	
⬆ Select	[↵] Confirm

12. External Error Signal

Initial setting: No

Set when external error display unit is installed.
Turn on Dry Contact SW when error happened.

(NOTE) Does not display when there is no Optional PCB.
When error occurs, error signal will be ON.
After turn off "close" from the display, error signal will still remain ON.

System setup	12:00 pm, Mon
Bivalent connection	
External SW	
Solar connection	
External error signal	
◀ Select	[←] Confirm

13. Demand control

Initial setting: No

Set when there is demand control.
Adjust terminal voltage within 1 ~ 10 V to change the operating current limit.

(NOTE) Does not display when there is no Optional PCB.

System setup	12:00 pm, Mon
External SW	
Solar connection	
External error signal	
Demand control	
◀ Select	[←] Confirm

Analog input [V]	Rate [%]
0.0	not activate
0.1 ~ 0.6	not activate
0.7	10
0.8	not activate
0.9 ~ 1.1	10
1.2	15
1.3	10
1.4 ~ 1.6	15
1.7	20
1.8	15
1.9 ~ 2.1	20
2.2	25
2.3	20
2.4 ~ 2.6	25
2.7	30
2.8	25
2.9 ~ 3.1	30
3.2	35
3.3	30
3.4 ~ 3.6	35
3.7	40
3.8	35

Analog input [V]	Rate [%]
3.9 ~ 4.1	40
4.2	45
4.3	40
4.4 ~ 4.6	45
4.7	50
4.8	45
4.9 ~ 5.1	50
5.2	55
5.3	50
5.4 ~ 5.6	55
5.7	60
5.8	55
5.9 ~ 6.1	60
6.2	65
6.3	60
6.4 ~ 6.6	65
6.7	70
6.8	65
6.9 ~ 7.1	70
7.2	75
7.3	70

Analog input [V]	Rate [%]
7.4 ~ 7.6	75
7.7	80
7.8	75
7.9 ~ 8.1	80
8.2	85
8.3	80
8.4 ~ 8.6	85
8.7	90
8.8	85
8.9 ~ 9.1	90
9.2	95
9.3	90
9.4 ~ 9.6	95
9.7	100
9.8	95
9.9 ~	100

*A minimum operating current is applied on each model for protection purpose.
*0.2 voltage hysteresis is provided.
*The value of voltage after 2nd decimal point are cut off.

14. SG Ready

Initial setting: No

System setup	12:00 pm, Mon
Solar connection	
External error signal	
Demand control	
SG Ready	
⬆ Select	[↵] Confirm

Switch operation of heat pump by open-short of 2 terminals.
 The following settings are possible.
 Capacity: limit by capacity.
 Power consumption: limit by power consumption.

SG signal		Operation pattern
Vcc-bit1	Vcc-bit2	
Open	Open	Normal
Short	Open	Heat pump/heater OFF
Open	Short	Capacity 1
Short	Short	Capacity 2

Select Capacity

Capacity setting 1

- DHW capacity ___%.
- Heating capacity ___%.
- Cooling capacity ___°C

Capacity setting 2

- DHW capacity ___%.
- Heating capacity ___%.
- Cooling capacity ___°C

} SG ready - Yes - Capacity setting

Select Power consumption

HPU stop consumption ___kW

HPU stop consumption value is never exceeded

If the value is exceeded, heating is provided by the heater only.

Power consumption setting 1

- Power consumption of DHW ___kW
- Heating power consumption ___kW
- Cooling power consumption ___kW

Power consumption setting 2

- Power consumption of DHW ___kW
- Heating power consumption ___kW
- Cooling power consumption ___kW

} SG ready - Yes - Power consumption setting

(If SG ready is set to 'Yes', Bivalent control pattern is set to 'Auto').
 (Note): Does not display if there is no Optional PCB.

15. External compressor SW

Initial setting: No

Set when the external compressor SW is connected.
 After the external compressor SW is set to 'Yes', there are 2 control pattern options to select from: Heat Source and Heater.

1) Heat source

An open signal will stop the heat pump, outdoor water pump, and heater (booster heater and back-up heater) operations. Optional functions will remain active.

2) Heater

An open signal will stop the back-up heater operations.

The heat pump and optional functions will remain active.

*Optional functions includes solar, boiler, zone control and others.

(Note): Does not display if there is no Optional PCB.

System setup	12:00 pm, Mon
External error signal	
Demand control	
SG Ready	
External compressor SW	
◀ Select	[↵] Confirm

16. Circulation Liquid

Initial setting: Water

Set circulation of heating water.

There are 2 types of settings, water and glycol.

(NOTE) Please set glycol when using anti-freeze liquid.
 It may cause error if setting is wrong.

System setup	12:00 pm, Mon
Demand control	
SG Ready	
External compressor SW	
Circulation liquid	
◀ Select	[↵] Confirm

17. Heat-Cool SW

Initial setting: Disable

Able to switch (fix) heating & cooling by external switch.

(Open) : Fix at Heating (Heating +DHW)

(Short) : Fix at Cooling (Cooling +DHW)

(NOTE) This setting is disabled for model without Cooling.

(NOTE) Does not display if there is no Optional PCB.

Timer function cannot be used. Cannot use Auto mode.

System setup	12:00 pm, Mon
SG Ready	
External compressor SW	
Circulation liquid	
Heat-Cool SW	
◀ Select	[↵] Confirm

18. Force Heater

Initial setting: Manual

Under manual mode, user can turn on force heater through quick menu.

If selection is 'auto', force heater mode will turn automatically if pop up error happen during operation.

Force heater will operate follow the latest mode selection, mode selection is disable under force heater operation.

Heater source will ON during force heater mode.

System setup	12:00 pm, Mon
External compressor SW	
Circulation liquid	
Heat-Cool SW	
Force heater	
◀ Select	[↵] Confirm

19. Force Defrost

Initial setting: Manual

Under manual mode, user can turn on force defrost through quick menu.

If selection is 'auto', outdoor unit will run defrost operation once if heat pump have long hour of heating without any defrost operation before at low ambient condition.
 (Even if auto is selected, user still can turn on force defrost through quick menu)

System setup	12:00 pm, Mon
Circulation liquid	
Heat-Cool SW	
Force heater	
Force defrost	
◀ Select	[↵] Confirm

20. Defrost signal

Initial setting: No

The defrost signal and bivalent connection share the same connection port on the main PCB. When defrost signal set to YES, bivalent connection reset to NO. Only one function can be set between defrost signal and bivalent.

When defrost signal set to YES, during defrost operation is running at outdoor unit defrost signal contact turn ON. Defrost signal contact turn OFF after defrost operation end.

(Purpose of this contact output is to stop indoor fan coil or water pump during defrost operation).

System setup	12:00 pm, Mon
Heat-Cool SW	
Force heater	
Force defrost	
Defrost signal	
◀ Select	[↵] Confirm

21. Pump flowrate

Initial setting: ΔT

If pump flowrate setting is ΔT , unit adjust pump duty to get different of water inlet and outlet base on setting on * ΔT for heating ON and * ΔT for cooling ON in operation setup menu during room side operation.

If pump flowrate setting is set to Max. duty, unit will set the pump duty to the set duty at * Pump maximum speed in service setup menu during room side operation.

System setup	12:00 pm, Mon
Force heater	
Force defrost	
Defrost signal	
Pump flowrate	
◀ Select	[↵] Confirm

22. DHW defrost

Initial setting: Yes

When DHW defrost set to YES, hot water of domestic hot water tank will be used during defrost cycle.

When DHW defrost set to NO, hot water of floor heating circuit will be used during defrost cycle.

System setup	12:00 pm, Mon
Force defrost	
Defrost signal	
Pump flowrate	
DHW Defrost	
◀ Select	[↵] Confirm

23. Heating control

Initial setting: Comfort

Compressor frequency control can be selected from two modes: Comfort and Efficiency.

Select "Comfort"

- The compressor operates at maximum frequency at the upper zone limit and reaches the set temperature faster.

Select "Efficiency"

- The compressor frequency is gradually increased to reduce power consumption.

The system has 3 steps to achieve maximum compressor frequency. You can set the duration of each stage on the remote control (R/C).

(compressor frequency for each stage)

1st stage : 50% of the maximum frequency

2nd stage : 66% of the maximum frequency


3rd stage : 83% of the maximum frequency

When "Variable" is selected in the "5. DHW capacity" setting, the tank heat-up process will be delayed until a much lower tank water temperature is reached, which improves the efficiency of the heating process. To ensure sufficient hot water, select either "Comfort" in this setting or "Standard" in the "5. DHW capacity" setting.

It is a function for Heating + Tank operation.

System setup	12:00 pm, Mon
Defrost signal	
Pump flowrate	
DHW Defrost	
Heating control	
◀ Select	[↵] Confirm

Select Efficiency.
Capacity



24. External meter

Initial setting: [Heat-cool meter : No]
[Tank meter : No] *only available when
Heat-cool meter select Yes
[Elec. meter HP : No]
[Elec. meter 1 (PV meter) : No]
[Elec. meter 2 (Building) : No]
[Elec. meter 3 (Reserve) : No]

System setup	12:00 pm, Mon
Pump flowrate	
DHW Defrost	
Heating control	
External meter	
◀ Select	[↵] Confirm

There are two systems for generation meter connection : one generation meter system

(Heat-cool meter) or two generation meter system (Heat-cool meter and Tank meter)

Both systems can provide all generation data of heating, cooling and DHW directly from external meter.

If Heat-cool meter is set to Yes, it will read from external meter for heat pump's energy generation data during heating, cooling and DHW operation¹.

If Heat-cool meter is set to No, it will base on unit's calculation for heat pump's energy generation data during heating, cooling and DHW operation.

If Tank meter is set to Yes, it will read from external meter for heat pump's energy generation data during DHW operation¹.

If Elec. meter HP is set to Yes, it will read from external meter for heat pump's energy consumption data.

If Elec. meter HP is set to No, it will base on unit's calculation for heat pump's energy consumption data.

If Elec. meter 1 (PV meter) is set to Yes, it will read from external meter for energy generation data of solar system and display it on Cloud system.

If Elec. meter 2 (Building) is set to Yes, it will read from external meter for energy consumption data of the building and display it on Cloud system.

If Elec. meter 3 (Reserve) is set to Yes, it will read from external meter for energy consumption data obtained from reserved electricity meter and display it on Cloud system.

¹ Set Heat-cool meter to Yes and set Tank meter to No when 1 generation meter system is installed.

Set Heat-cool meter to Yes and set Tank meter to Yes when 2 generation meter system is installed.

Remark : Elec. meter HP refers to Electricity meter that measures Heat Pump unit's consumption.

Elec. meter 1 / 2 / 3 refers to Electricity meter no. 1 / no. 2 / no. 3

25. Electrical anode

Initial setting: WH-ADC0316M9E81: NO
 WH-ADC0916M3E51: NO
 WH-ADC0316M9E8AN1: YES
 WH-ADC0916M3E5AN1: YES

When Electrical anode set to YES, anode will be turned on.
 When Electrical anode set to NO, anode will not be turned on.

System setup	12:00 pm, Mon
DHW Defrost	
Heating control	
External meter	
Electrical anode	
◀ Select	[↵] Confirm

26. Extra pump

Initial setting: Heat

Selects whether the extra pump is used in the circulation circuit for heating or in the circulation circuit for DHW, or it is not used.
 If select for DHW, make choices such as the pump ON/OFF time and whether comfort or economy is a priority.

Select DHW

- Pump ON time 8:00
- Pump OFF time 20:00

Select Comfort (Exit extra pump settings)


Select Efficiency

- ON time 0:15 (0:05 ~ 1:00)
- OFF time 0:15 (0:05 ~ 1:00)

System setup	12:00 pm, Mon
Heating control	
External meter	
Electrical anode	
Extra pump	
◀ Select	[↵] Confirm


Select DHW

Select Comfort



Select DHW

Select Efficiency

**27. Static pressure**

Initial setting: No

If set to No, the outdoor fan motor operates at a normal speed.
 If set to YES, the outdoor fan motor operates at a higher speed than normal in response to high static pressure.

System setup	12:00 pm, Mon
External meter	
Electrical anode	
Extra pump	
Static pressure	
◀ Select	[↵] Confirm

28. Cooling capacity

Initial setting: Efficiency

Select the cooling capacity.

If set to "Efficiency", the unit performs cooling operation efficiently at rated capacity.
 If set to "Comfort", the cooling operation is performed at maximum capacity.

System setup	12:00 pm, Mon
Electrical anode	
Extra pump	
Static pressure	
Cooling capacity	
▲ Select	[↵] Confirm

12.2.3.4 Operation Setup

Heat

29. Water temp. for heating ON


Initial setting: compensation curve

Set target water temperature to operate heating operation.

Compensation curve: Target water temperature change in conjunction with outdoor ambient temperature change.

Direct: Set direct circulation water temperature.

In 2 zone system, zone 1 and zone 2 water temperature can be set separately.



30. Outdoor temp. for heating OFF

If the operation of the outdoor unit is frequently switched on and off depending on the outdoor air temperature, the following settings can be used to reduce the frequency.

a. Outdoor temp. for heating OFF

Initial setting: 24°C

Set outdoor temp. to stop heating.
Setting range is 6°C~35°C

b. Outdoor temp. for heating ON


Initial setting: 23°C

Set outdoor temp. to start heating.
Setting range is 5°C~X°C (X is heating OFF temp. -1)

c. Heating ON delay time

Initial setting: 0:30min

Set delay time from heating OFF to heating ON.




31. ΔT for heating ON

Initial setting: 5°C

Set temp difference between out temp & return temp of circulating water of Heating operation.

When temp gap is enlarged, it is energy saving but less comfort. When the gap gets smaller, energy saving effect gets worse but it is more comfortable.
Setting range is 1°C ~ 15°C



32. Heater ON/OFF

a. Outdoor temp. for heater ON

Initial setting: 0°C

Set outdoor temp when back-up heater starts to operate.
Setting range is -20°C ~ 15°C

User shall set whether to use or not to use heater.

b. Heater ON delay time

Initial setting: 30 minutes

Set delay time from compressor ON for heater to turn ON if not achieve water set temperature.
Setting range is 10 minutes ~ 60 minutes

c. Heater ON: ΔT of target Temp




Initial setting: -4°C

Set water temperature for heater to turn on at heat mode.
Setting range is -10°C ~ -2°C

d. Heater OFF: ΔT of target Temp

Initial setting: -2°C

Set water temperature for heater to turn off at heat mode.
Setting range is -3°C ~ 0°C




Cool

33. Water temp. for cooling ON

Initial setting: compensation curve

Set target water temperature to operate cooling operation.
 Compensation curve: Target water temperature change in conjunction with outdoor ambient temperature change.
 Direct: Set direct circulation water temperature.


In 2 zone system, zone 1 and zone 2 water temperature can be set separately.



34. ΔT for cooling ON

Initial setting: 5°C

Set temp difference between out temp & return temp of circulating water of Cooling operation.
 When temp gap is enlarged, it is energy saving but less comfort. When the gap gets smaller, energy saving effect gets worse but it is more comfortable.
 Setting range is 1°C ~ 15°C




Auto

35. Outdoor temp. for (Heat to Cool)

Initial setting: 15°C

Set outdoor temp that switches from heating to cooling by Auto setting.
 Setting range is 11°C ~ 25°C

Timing of judgement is every 1 hour




36. Outdoor temp. for (Cool to Heat)

Initial setting: 10°C

Set outdoor temp that switches from Cooling to Heating by Auto setting.
 Setting range is 5°C ~ 14°C

Timing of judgement is every 1 hour




Tank

37. Floor operation time (max)

Initial setting: 8h


Set max operating hours of heating.
When max operation time is shortened, it can boil the tank more frequently.
It is a function for Heating + Tank operation.



38. Tank heat up time (max)

Initial setting: 60min


Set max boiling hours of tank.
When max boiling hours are shortened, it immediately returns to Heating operation, but it may not fully boil the tank.



39. Tank re-heat temp.

Initial setting: -8°C

Set the temperature to re-boil the tank water.
Setting range is -12°C ~ -2°C




40. Sterilisation

Initial setting: 65°C 10 mins.

Set timer to perform sterilization.

- ① Set operating day & time. (Weekly timer format)
- ② Sterilization temperature (55~65°C)
- ③ Operation time (Time to run sterilization when it reached setting temperature. 5 ~ 60 minutes)

User shall set whether to use or not to use sterilization mode.



12.2.3.5 Service Setup

41. Pump maximum speed	Initial setting: Varies according to model	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="2">Service setup</td> <td style="text-align: right;">12:00 pm, Mon</td> </tr> <tr> <td style="width: 33%;">Flow rate</td> <td style="width: 33%;">Max Duty</td> <td style="width: 34%;">Operation</td> </tr> <tr> <td>45.6 L/min.</td> <td>0xCE</td> <td style="text-align: center;">▲ Air purge</td> </tr> <tr> <td colspan="3" style="text-align: left;">◀ Select</td> </tr> </table>	Service setup		12:00 pm, Mon	Flow rate	Max Duty	Operation	45.6 L/min.	0xCE	▲ Air purge	◀ Select		
Service setup		12:00 pm, Mon												
Flow rate	Max Duty	Operation												
45.6 L/min.	0xCE	▲ Air purge												
◀ Select														

Normally setting is not necessary.
Please adjust when needed to reduce the pump sound, etc.
Besides that, the unit has Air Purge function.

When the Pump flow setting is Max. Duty, this duty setting is the duty of fixed pump that runs during operation.

<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%; padding: 5px;">42. Dry concrete</td> </tr> </table> <p style="margin-top: 10px;">Operate concrete curing operation. Select Edit and set the temperature for every stage (1~99 1 is for 1 day). Setting range is 25~55°C</p> <p>When it is turned ON, dry concrete starts.</p> <p>In the case of 2 zones, it dries both zones.</p>	42. Dry concrete	
42. Dry concrete		

<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%; padding: 5px;">43. Service contact</td> </tr> </table> <p style="margin-top: 10px;">Able to set the name & telephone no. of contact person when there is breakdown etc. or client has trouble. (2 items)</p>	43. Service contact	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="2">Service setup</td> <td style="text-align: right;">12:00 pm, Mon</td> </tr> <tr> <td colspan="3">Service contact:</td> </tr> <tr> <td colspan="3" style="text-align: center;">Contact 1</td> </tr> <tr> <td colspan="3" style="text-align: center;">Contact 2</td> </tr> <tr> <td colspan="2" style="text-align: left;">▲ Select</td> <td style="text-align: right;">[↵] Confirm</td> </tr> </table>	Service setup		12:00 pm, Mon	Service contact:			Contact 1			Contact 2			▲ Select		[↵] Confirm	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="3">Contact - 1: Brian Adams</td> </tr> <tr> <td style="width: 33%; text-align: center;">ABC/ abc</td> <td style="width: 33%; text-align: center;">0-9/ Other</td> <td style="width: 34%;"></td> </tr> <tr> <td colspan="3">A B C D E F G H I J K L M N O P Q R</td> </tr> <tr> <td colspan="3">S T U V W X Y Z a b c d e f g h i</td> </tr> <tr> <td colspan="3">j k l m n o p q r s t u v w x y z</td> </tr> <tr> <td colspan="2" style="text-align: left;">▼ Select</td> <td style="text-align: right;">[↵] Confirm</td> </tr> </table>	Contact - 1: Brian Adams			ABC/ abc	0-9/ Other		A B C D E F G H I J K L M N O P Q R			S T U V W X Y Z a b c d e f g h i			j k l m n o p q r s t u v w x y z			▼ Select		[↵] Confirm
43. Service contact																																				
Service setup		12:00 pm, Mon																																		
Service contact:																																				
Contact 1																																				
Contact 2																																				
▲ Select		[↵] Confirm																																		
Contact - 1: Brian Adams																																				
ABC/ abc	0-9/ Other																																			
A B C D E F G H I J K L M N O P Q R																																				
S T U V W X Y Z a b c d e f g h i																																				
j k l m n o p q r s t u v w x y z																																				
▼ Select		[↵] Confirm																																		

12.2.3.6 Remote Control Setup

<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%; padding: 5px;">44. RC selection</td> </tr> </table> <p style="margin-top: 10px;">If there is only one remote controller, set to "Single". If two remote controllers are installed, set to "Dual".</p> <p>For details on the Dual setting, refer to the instruction manual of the optional remote controller.</p>	44. RC selection	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="2">Initial setting : Single</td> </tr> </table>	Initial setting : Single		<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="2">RC selection</td> <td style="text-align: right;">12:00 pm, Mon</td> </tr> <tr> <td colspan="3" style="text-align: center;"> <div style="border: 1px solid black; padding: 2px; display: inline-block;">Single</div> ▼ </td> </tr> <tr> <td colspan="3" style="text-align: center;">Dual</td> </tr> <tr> <td colspan="2" style="text-align: left;">▼ Select</td> <td style="text-align: right;">[↵] Confirm</td> </tr> </table>	RC selection		12:00 pm, Mon	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Single</div> ▼			Dual			▼ Select		[↵] Confirm
44. RC selection																	
Initial setting : Single																	
RC selection		12:00 pm, Mon															
<div style="border: 1px solid black; padding: 2px; display: inline-block;">Single</div> ▼																	
Dual																	
▼ Select		[↵] Confirm															

12.3 Service and Maintenance

If forget Password and cannot operate remote controller

↶ + ↵ + ↷ Press for 5 seconds.

Password unlock screen appears, press Confirm and it shall reset.

Password will become 0000. Please reset it again.

(Note) This is displayed only when the remote controller is password-locked.

12.3.1 Maintenance Menu

How to set up the Maintenance menu

Maintenance menu	12:00 pm, Mon
Actuator check	
Test mode	
Sensor setup	
Reset password	
▼ Select	[↵] Confirm

↶ + ↵ + ↷ Press for 5 seconds.

Items that can be set

- ① Actuator check (Manual ON/OFF all functional parts)
(NOTE) As there is no protection action, please be careful not to cause any error when operating each part (do not turn on pump when there is no water etc.)
- ② Test mode (Test run)
Normally it is not used.
- ③ Sensor setup (offset gap of detected temp of each sensor can be set within -3~3°C range)
(NOTE) Please use only when sensor is deviated. It affects temperature control.
- ④ Reset password (password reset)

12.3.2 Custom Menu

How to set up a Custom menu

Custom menu	12:00 pm, Mon
Cool mode	
Back-up heater	
Reset energy monitor	
Reset operation history	
▼ Select	[↵] Confirm

Custom menu	12:00 pm, Mon
Reset energy monitor	
Reset operation history	
Smart DHW	
Anti-stick mode	
▲ Select	[↵] Confirm





≡ + ∨ + < Press for 5 seconds.

Items that can be set

- ① Cool mode (Select Cooling function: Enable/Disable) Default setting is Disable.
(NOTE) As Enable/Disable Cool mode may affect electricity application, please be careful and do not simply change it.
In Cool mode, please be careful if piping is not insulated properly, dew may form on pipe and water may drip on the floor and damage the floor.
- ② Backup heaters (Select Cooling function: Enable/Disable)
(Note) Differs from the use/non-use of back-up heaters that is set by the customer. This setting disables the heater power on for freeze protection. (This setting should only be used if requested by the utility company.)
This setting may cause the heating setting temperature to be low, defrosting to fail and operation to stop (H75).
Installation must be carried out under the responsibility of the installation personnel. If the system stops frequently, the cause may be insufficient circulation flow or the heating set temperature is too low.
- ③ Reset energy monitor (delete memory of Energy monitor)
Please use this when moving house and handover the unit.
- ④ Reset operation history (delete memory of operation history)
Please use this when moving house and handover the unit.
- ⑤ Smart DHW (to set smart DHW mode parameters)
 - a) Start time: Tank re-boils above low ON temperature.
 - b) Stopping time: Tank re-boils above normal ON temperature.
 - c) ON Temperature: Tank re-boil temperature at smart DHW start-up
- ⑥ Anti-stick mode (select Anti-stick mode: Enable/Disable)
Default setting is Enable.
The actuator is regularly activated every Monday at 3:00 am to prevent the actuating parts from sticking together.
Select Disable if wish to stop the mode being activated periodically.
Parts and other components that may not operate if Disable is selected may stick if not operated for a long period of time.

12.4 Outdoor Unit

Attached accessories

No.	Accessories part	Qty.
1	Drain Elbow 	1
2	Screw 	8
3	Rubber Cap 	3
4	Rubber Cap 	15
5	Discharge Grille (Left Top) 	1
6	Discharge Grille (Left Bottom) 	1
7	Discharge Grille (Right Top) 	1
8	Discharge Grille (Right Bottom) 	1

Optional Accessories

No.	Accessories part	Qty.
9	Remote Controller set (CZ-RTW2TAW1C) *Include Remote Controller + Network adapter with 10m cable	1
10	Remote Controller (CZ-RTW2)	1
11	Base Pan Heater CZ-NE4P	1

- When you purchase an indoor unit, the remote controller and network adapter are included.
- When the outdoor unit is used alone, either 9 or 10 is always required.
- If you need the 2nd remote controller, purchase 10 and set it up as the 2nd remote controller.
- When installing the outdoor units in cold climates, it is strongly recommended to install a base pan heater (optional). For installation details, refer to the installation manual of the base pan heater (optional).

Field Supply Accessories (Optional)

Part	3-way valve kit	
	Electromtoric Actuator	3-port Valve
Model	SFA 21/18	VXI 46/25
Specification	AC230V, 12VA	-
Supplier	Siemens	

12.4.1 Select the Best Location

- If an awning is placed over the unit to avoid direct sunlight or rain, be careful not to disturb the heat dissipation from the capacitor.
- Avoid installation where the ambient temperature may fall below -28°C.
- A protective zone is defined in the area close to the perimeter of the product. Refer to 12.4.2 Protective Zone section.
- Do not place obstacles that could short-circuit the discharge air.
- The lifespan of Outdoor Unit may be shorter if it is installed near the sea, in areas with high sulphur content or high oil content (e.g. machine oil).
- For maximum length and elevation between outdoor unit and indoor unit, refer to "Cooling/Heating Pipework" in 12.4.5 Piping Installation.

12.4.2 Protective Zone

This outdoor unit is filled with R290 (Extremely flammable gas, safety A3 group per ISO 817). Note that this refrigerant has a higher density than air. In case of a refrigerant leak, the leaked refrigerant may accumulate near the ground.

Prevent accumulation of refrigerant in any way that is potentially dangerous, explosive or risk suffocation. Prevent refrigerant from entering the building through building openings. Prevent accumulation of refrigerant in the drain grooves.


A protective zone is defined around this outdoor unit. There must be no building openings, windows, doors, light shafts, cellar entrances, escape hatches, flat-roof windows or ventilation openings in the protective zone.

There must be no ignition sources, such as heat above 360°C, sparks, open flame, plug sockets, light switches, lamps, electrical switches or other permanent ignitions sources, in the protective zone.


The protective zone must not extend to adjacent buildings or public traffic areas (boundaries of neighbors, the public road, neighbor's private roads, subsidence area, depressions, pump shafts, sewers intakes, waste water shafts and so on.).

In the protective zone, you are not permitted to make any subsequent structural alterations which infringe the stated rules for the protective zone.

- 1) Protective zone for ground installation (or flat-roof installation) at the open areas




- 2) Protective zone for ground installation in front of a building wall




A 2200 mm
B 3200 mm
C 300 mm
D 1000 mm

- 3) Protective zone for ground installation in a building corner



A 2200 mm
B 2700 mm
C 300 mm
D 500 mm
E 1000 mm
F 500 mm
G 1800 mm


- 4) Protective zone for wall installation in front of a building wall



A 2200 mm
B 3200 mm
C 300 mm
D 1000 mm

The protective zone under the product extends to the floor.

- 5) Protective zone for wall installation in a building corner




A 2200 mm
B 2700 mm
C 300 mm
D 500 mm
E 1000 mm
F 500 mm
G 1800 mm


The protective zone under the product extends to the floor.

12.4.3 Install Outdoor Unit


12.4.3.1 Dimension Diagram




Top view




Front view




Side view



Rear view




Bottom view




It is advisable to avoid more than 2 blockage directions. For better ventilation and multiple outdoor installations, consult an authorised dealer/expert.

12.4.3.2 Main Components Diagram




12.4.3.3 Install the Outdoor Unit

- After selecting the best location, start installation according to the Installation Diagram.
 - When installing at roof, please consider strong wind and earthquake. Please fasten the installation stand firmly with bolt or nails.
 - For mounting on concrete or solid surfaces, fix the unit using M10 or W 3/8 bolts and nuts. Make sure that the unit is installed vertically against the horizontal plane. (Install the unit using anchor bolt as shown right.)




12.4.3.4 Disposal of Outdoor Unit Drain Water

- When the Drain elbow [1] is used, please ensure to:
 - The unit must be mounted on a stand at least 50 mm high.
 - Seal the $\varnothing 32$ mm holes with Rubber caps [3]. (Refer to the diagram below and install from the outside)
 - If drain water leaks, attach rubber caps [4] when necessary. (Refer to the diagram below and install from the outside)
 - When disposing drain water from the outdoor unit, use a tray (field supply) if necessary.
- If the unit is used in an area where temperature falls below 0°C for 2 or 3 consecutive days, it is recommended not to use the Drain elbow [1] Rubber caps [3] and Rubber caps [4] since drain water will freeze up and obstruct fan rotation.



12.4.4 Install a Sleeve of Piping (Drill a Hole in the Wall)

1. Make a through hole. (Check pipe diameter and insulation thickness)
2. Insert the piping sleeve into the hole.
3. Fix the bushing to the sleeve.
4. Cut the sleeve until it extrudes about 15 mm from the wall.



CAUTION


When the wall is hollow, please be sure to use the sleeve for tube assembly to prevent dangers caused by mice biting the connection cable.

5. Finish by sealing the sleeve with putty or caulking compound at the final stage.


12.4.5 Piping Installation

12.4.5.1 Typical Piping Installation


When outdoor unit is used alone



When indoor unit (hydromodule + tank) is connected





When indoor unit (Bi-bloc) is connected



12.4.5.2 Water Piping Installation

- Please engage a licensed water circuit installer to install this water circuit.
- This water circuit must comply with relevant European and national regulations (including EN61770), and local building regulation codes.
- Ensure the components installed in the water circuit could withstand water pressure during operation.
- Do not use worn out tube or detachable hose set.
- Do not apply excessive force to the pipe. There is a risk of damage.
- Choose proper sealer which can withstand the pressures and temperatures of the system.
- Make sure to use two spanners to tighten the connection. Further tighten the nuts with torque wrench to the specified torque as stated in the table.
- Cover the pipe end to prevent dirt and dust when inserting it through a wall.
- If non-brass metallic piping is used for installation, make sure to insulate the pipes to prevent galvanic corrosion.
- Do not connect galvanised pipes. This may cause galvanic corrosion.
- Use correct nut for all Outdoor Unit tube connections and clean all tubes with tap water before installation.



Refer to the table below for tightening torques for the water inlet and outlet.

	Size	Torque
Water Inlet Port (a)	R 1¼"	117.6 N•m
Water Outlet Port (b)		



CAUTION

Do not overtighten, overtightening may cause water leakage.

- Make sure to insulate the water circuit pipes to prevent reduction of heating capacity.
- After installation, check the water leakage condition in connection area during test run.
- Failure to connect the tube appropriately might cause the Outdoor Unit malfunction.
- Protection from frost:
When water is left inside the system, freezing up is very likely to happen, which could damage the system.
Make sure the power supply is turned off before draining.

When outdoor unit is used alone

Install an expansion tank (set pressure: 1 bar) to the circulation circuit.

For capacity, refer to 12.4.11 Reconfirmation.

12.4.5.3 Space Cooling/Heating Pipework

- Failure to connect the tube appropriately might cause the Outdoor Unit malfunction.
- Refer to the table below for the rated flow rate of each particular Outdoor Unit.

Model	Rated flow rate (L/min)	
	Cooling	Heat
WH-WXG09ME8	25.8	25.8
WH-WXG12ME8	25.8	34.4
WH-WXG16ME8	25.8	45.9

When outdoor unit is used alone

- Connect Outdoor unit Zone 1 Water inlet (a) to outlet connector of Zone 1 Panel/Floor heater.
- Connect Outdoor unit Zone 1 Water outlet (b) to inlet connector of Zone 1 Panel/Floor heater.

When connected to indoor unit

Refer to the Indoor Unit Installation Manual.

* In the case of Control Module model, it is the same as outdoor unit alone case.

Pipe diameter and length

Model	Water piping between outdoor unit and indoor unit			
	Inner diameter	Maximum length	Insulator thickness	Maximum Elevation
WH-WXG09ME8	Ø 25 mm	30m	30 mm or more	30m
WH-WXG12ME8	Ø 32 mm			
WH-WXG16ME8				

* However, if the indoor unit is located more than 10 m below, the water pressure in the circulation circuit (outdoor unit section) shall be 0.5 to 1 bar.

If the outdoor unit is located below, install an extra pump on the outdoor side.

Refer to “12.4.5.4 Special Installation Patterns” in next page.


* WH-WXG16ME8 may require installation of an extra pump depending on piping length.

Model	Water piping (When outdoor unit is used alone)		
	Inner diameter	Insulation thickness	Maximum elevation between outdoor unit and Panel/Floor heater
WH-WXG09ME8	Ø 25 mm	30 mm or more	10m
WH-WXG12ME8	Ø 32 mm		
WH-WXG16ME8			

12.4.5.4 Special Installation Patterns


Special construction patterns mentioned here refer to the case where there is a substantial difference in elevation (e.g. more than 10 m) between the outdoor unit installation and the Panel/Floor heater (or indoor unit). In this case, attention must be paid since incorrect water filling during installation may prevent the system from operating correctly and may cause water leak.

① **When outdoor unit is located below and Panel/Floor heater is 30 m above it**



- Pressure checked by remote controller: 3.5 ~ 4 bar. (at an elevation difference of 30 m)
- When installing an extra pump, connect it to the water outlet of the outdoor unit. (If installed to the water inlet, the safety valve is activated and the water is drained)
- Indoor unit is required to install an extra pump.

② **When outdoor unit is located above and Panel/Floor heater is 30 m below it**



- Pressure checked by remote controller: 0.5 ~ 1 bar. (at an elevation difference of 30 m)
- When installing an extra pump, connect it to the water outlet of the indoor unit.
- Indoor unit is required to install an extra pump.

12.4.6 Connect the Cable to the Outdoor Unit

⚠ WARNING



This section is intended for licensed electricians. Work inside terminal board covers ③ fixed with work screws must be carried out by an installer or service personnel under the supervision of qualified personnel.

⚠ CAUTION

Make sure to install the discharge grille to the outdoor unit before powering ON to protect against a rotating fan.

(Refer to the unit wiring diagram for details)

- For safety, install the discharge grille (left side) ⑤ • ⑥ using screws ② before connecting the cables.



12.4.6.1 Fixing of Power Supply Cable and Connecting Cable

- An isolating device must be connected to the power supply cable.
 - Isolating device (disconnecting means) should have minimum 3.0 mm contact gap.
 - Use approved polychloroprene sheathed flexible cable of type designation 60245 IEC 57 or heavier. Connect the other end of the cable to isolating device (Disconnecting means). See table below for cable size requirements.
- Connecting cable must be an approved polychloroprene sheathed flexible cable (see table below), type designation 60245 IEC 57 or heavier. The sheath diameter of some connecting cables must be within specifications compatible with the cable gland.

Power Supply Cable

Model	WH-WXG09ME8 WH-WXG12ME8	WH-WXG16ME8
Cable specification	5 × min 1.5 mm ²	5 × min 2.5 mm ²
Cable Diameter	Ø 8.5 ~ 10.0 mm	Ø 12.0 ~ 14.0 mm
Cable gland to be used (see diagram in ② next page)	A	
Isolating Devices	20A	25A
Recommended RCD	30mA, 4P, typeA	

	connection between Indoor unit and outdoor unit	Tank temperature sensor	Remote controller
Cable Specifications	2 × min 0.75 mm ²	2 × min 0.3 mm ²	2 × min 0.3 mm ²

	3-Way Valve	Boiler
Cable Specifications	3 × min 1.5 mm ²	2 × min 0.5 mm ²
Cable Diameter	Ø 8.5 ~ 10.0 mm	Ø 4.0 ~ 7.0 mm
Cable gland to be used (see diagram in ② next page)	B	C

- Earth wire shall be longer than the other wires as shown in the figure ③ for the electrical safety in case of the slipping out of the cord from the Holder (Clamper).



3. Route the cables as follows.
- Do not damage the cables by sharp edges.

- 1** Remove the front plate ① and pull the power cable (cabtyre cable *1) and connection cable through into the rear bushing. Be sure to use the bushing and do not lose it.
- 2** Remove the terminal board cover ③ and cable gland cap and insert the cables into the cable gland on the bottom of the electrical control unit box.
- 3** Connect to 3-phase RCCB/ELCB ④ and optional terminal board ⑤.
- 4** Fix the cable gland by referring to [Figure 2]*2
- 5** Set the terminal board cover ③ by referring to [Figure 2]*2

*1 Locally procure the specified cabtyre cable.



*2 Screws of cable gland and terminal board cover ③ must be tightened to the specified tightening torque to prevent ingress of gas.

1





Pull the power supply cable and connecting cable through the Connecting Cable Hole ⑬ as shown in the illustration.

2




	Cable gland	Nut
Cable gland A	1.8 ~ 2.5 N•m (18.4 ~ 25.5 kgf•cm)	2.2 ~ 3.0 N•m (22.4 ~ 30.6 kgf•cm)
Cable gland B, C	1.2 ~ 1.8 N•m (12.2 ~ 18.4 kgf•cm)	1.5 ~ 2.2 N•m (15.3 ~ 22.4 kgf•cm)

Overall view



★ next page



Route the cables as shown in the diagram above.



3

WARNING

This equipment must be properly earthed.


• OUTPUT

3-way valve	AC230V C : Close O : Open N : Neutral
Boiler contact	Dry contact (System setup necessary)



refer to
WIRE STRIPPING AND CONNECTING REQUIREMENT


in next page



Need to connect when using an optional DHW tank

Need to connect when connecting and using a boiler.

Earth wire must be longer than other cables for safety reasons.




(Refer to the overall diagram on previous page)




12.4.6.2 Connection Between Indoor Unit and Outdoor Unit


When outdoor unit is used alone, leave the short-circuit wires "C2" and "C3" attached as shown in the diagram below.



When connecting to an indoor unit, remove the short-circuit wires "C2" and "C3" and connect as shown in the diagram below.



12.4.6.3 Wire Stripping and Connecting Requirement



Terminal screw	Tightening torque cN•m {kgf•cm}
M4	157 ~ 196 {16 ~ 20}
M5	196 ~ 245 {20 ~ 25}

12.4.6.4 Connection Requirement

For model WH-WXG09ME8, WH-WXG12ME8

- The equipment's Power Supply complies with IEC/EN 61000-3-2.
- The equipment's Power Supply complies with IEC/EN 61000-3-3 and can be connected to current supply network.

For model WH-WXG16ME8

- The equipment's Power Supply complies with IEC/EN 61000-3-12.
- The equipment's Power Supply complies with IEC/EN 61000-3-3 and can be connected to current supply network.

12.4.7 Install Remote Controller

- **Remote controller is an optional item.**

Be sure to purchase it if the outdoor unit is used alone.


If you have purchased an indoor unit, it is included.

When relocating the remote controller, install in accordance with its Installation Manual.

12.4.7.1 Installation Location

- When using as Room Thermostat, install at the height of 1 to 1.5 m from the floor (Location where average room temperature can be detected).
- Install vertically against the wall.
- Avoid the following locations for installation.
 1. By the window, etc. where is exposed to direct sunlight or direct air
 2. In the shadow or backside of objects deviated from the room airflow
 3. Location where condensation occurs (Remote Controller is not moisture proof or drip proof)
 4. Location near heat source
 5. Uneven surface
 6. Outdoors
- Keep distance of 1 m or more from the TV, radio and PC.
(Cause of fuzzy image or noise)


12.4.7.2 Remote Controller Wiring (If the Outdoor Unit is Used Alone)




- Remote Controller cable shall be (2 × min 0.3 mm²) of double insulation PVC-sheathed or rubber sheathed cable. Total cable length shall be 50 m or less.
(UV protection should be provided for the portion exposed to the outdoors)
- Be careful not to connect cables to other terminals of Outdoor Unit (e.g. power source wiring terminal). Malfunction may occur.
- Do not bundle together with the power source wiring or store in the same metal tube. Operation error may occur.
- When using the 2nd Remote Controller (optional), connect it to the terminal by tightening it together.

12.4.8 Network Adaptor Installation


1. Insert a flat head screwdriver into the slot on the top of the adaptor and remove the cover. Connect the CN-CNT cable to the connector inside the adaptor.



2. Pull the CN-CNT cable through the hole at the bottom of the adaptor and reattach the cover.



3. Connect the CN-CNT cable to the CN-CNT connector on the outdoor unit.




For details, refer to the instructions supplied with the network adaptor. For installation location, refer to "Installation location" in 12.4.7 Install Remote Controller.

12.4.9 Piping Insulation

- Carry out insulation of pipe connections according to "Space Cooling/Heating Pipework" in 12.4.5 Piping Installation. Wrap the pipes end-to-end with insulation to prevent condensation.

12.4.10 Charging the Water

- Make sure all the piping installations are properly done before carrying out the steps below.
1. Start filling water to the Space Heating /Cooling circuit via Zone 1 Water inlet (a) (with pressure more than 1 bar (0.1MPa))
 2. Stop filling water if the free water flow through Drain pipe of Pressure Relief Valve (12). (Check the Outdoor Unit)
 3. Turn ON the Outdoor Unit.
 4. Remote control menu → Installer setup → Service setup → Pump maximum speed → Turn on the pump.
 5. Make sure Water Pump (7) is running.
 6. Check and make sure no water leaking at the tube connecting points.




12.4.11 Reconfirmation

 WARNING
Be sure to switch off all power supply before performing each of the below checks.

12.4.11.1 Check Water Pressure

* (0.50 bar = 0.05 MPa)

Water pressure should not be lower than 0.5 bar. (Check the water pressure by the remote controller) If necessary, add water into Space Heating /Cooling pipes (through the Zone 1 water inlet (a)).



12.4.11.2 Check Pressure Relief Valve

1. Pull the lever in the horizontal direction and confirm that the pressure relief valve works properly.
2. Release the lever when water comes out of the drain pipe of the pressure relief valve. (While the air continues to come out of the drain pipe, keep raising the lever to completely discharge the air)
3. Confirm that the water from the drain pipe stops.
4. If water is leaking, pull the lever several times and return it to make sure the water stops.
5. If water keeps coming out of the drain, drain water. Turn off the system and contact your local authorized dealer.

12.4.11.3 Check Air Accumulation

- Open the air vent plugs on the heating panel, fan convactor, etc., and remove the air accumulated in the equipment and piping.
- If the outdoor unit and the indoor unit are installed on different floors, open the air vent plug on the water plug of the outdoor unit and the air vent plug on the heater bottle inside the indoor unit to remove the air. (Be careful, water will come out)

12.4.11.4 Expansion Vessel Volume and Set Pressure

- This outdoor unit does not have a built-in expansion tank.
- Capacity of expansion vessel should be calculated using the formula below:
- Install an expansion vessel (set pressure: 1 bar) to the circulation circuit.

See formula below for capacity:

$$V = \frac{\epsilon \times V_o}{1 - \frac{98 + P_1}{98 + P_2}}$$

V : Required gas amount <expansion vessel volume: L>

Vo : System total water volume <L>

ε : Water expansion rate 5 x 80°C = 0.0219

P1 : Expansion tank charging pressure P1 = 100 kPa

P2 : Maximum system pressure P2 = 400 kPa

○ It is recommended to calculate the required volume of vessel with a margin of approximately 10%.

Water expansion rate table

Water temperature (°C)	Water expansion rate ε
10	0.0003
20	0.0019
30	0.0044
40	0.0078
50	0.0121
60	0.0171
70	0.0228
80	0.0291
90	0.0360

[When an indoor unit is introduced and it is installed more than 7m lower than the outdoor unit]

Increase the initial pressure in the expansion tank as per the calculations below.

$$P_g = (H \times 10 + 30) \text{ kPa}$$

Pg : Initial pressure of expansion tank (kPa)

H : Difference in elevation (m)

12.4.11.5 Check RCCB/ELCB

- Ensure the RCCB/ELCB is set to "ON" condition before checking RCCB/ELCB.
- Turn on the power supply to the outdoor unit. This testing can only be done when power is supplied to the outdoor unit.


 WARNING
Be careful not to touch parts other than the TEST button of RCCB/ELCB when the power is supplied to Outdoor Unit. Else, electrical shock may happen. Before obtaining access to terminals, all supply circuits must be disconnected.

- Press the "TEST" button on the RCCB/ELCB. The lever would turn down if it functions normal.
- Contact authorized dealer if the RCCB/ELCB malfunction.
- If the RCCB/ELCB operates correctly, set the lever to 'ON' again after the test.


12.4.12 Install Discharge Grille

- 1 Install the front plate ①
- 2 Remove the 4 screws securing the cabinet front plate ①.
- 3 Insert the 4 claws of the discharge grille (right side) ⑦ and ⑧, and tighten the 4 screws.


1



2



3



12.4.13 Test Run

1. Before test run, make sure below items have been checked: -
 - a) Pipework are properly done.
 - b) Electric cable connecting work are properly done.
 - c) The Space Heating/Cooling circuit is filled up with water and trapped air is released.
2. Switch ON the power supply of the Outdoor Unit. Set the Outdoor Unit RCCB /ELCB to "ON" condition. Then, please refer to the Operation Instruction for operation of Remote Controller.

Note:

During winter, turn on the power supply and standby the unit for at least 15 minutes before test run. Allow sufficient time to warm up refrigerant and prevent wrong error code judgement.

3. For normal operation, the water pressure reading should be in between 0.5 bar and 4 bar (0.05 MPa and 0.4 MPa). If necessary, adjust the speed of the water pump ⑦ accordingly to obtain normal water pressure operating range. If adjusting the speed of the water pump ⑦ does not solve the problem, contact a local authorized dealer.
4. After test run, please clean the magnetic water filter ⑧. Reinstall it after the cleaning is finished. (Refer to 12.4.14 Maintenance)

12.4.13.1 Check Water Flow of Water Circuit

Select Installer setup → Service setup → Pump maximum speed → Air purge.

Confirm the rated flow rate has been reached. If don't reach, change max duty or install the extra pump.

*Water flow can be check in Service setup (Pump maximum speed)

[Heating operation at low water temperature with lower water flow may trigger "H75" during defrost process.]


*If there is no flow or H62 is displayed, stop operating the pump and release the air. (See "CHECK AIR ACCUMULATION" in 12.4.11 Reconfirmation)

12.4.14 Maintenance

- In order to ensure safety and optimal performance of the Outdoor Unit, seasonal inspections, functional check of RCCB/ELCB, field wiring and piping have to be carried out at regular intervals. This maintenance and scheduled inspection should be carried out by authorized dealer.

12.4.14.1 Maintenance for Magnetic Water Filter ⑧

1. Turn OFF the power supply.
2. Place a container below Magnetic Water Filter ⑧.
3. Turn to remove the Magnet Bar at bottom of Magnetic Water Filter ⑧.
4. Remove the Cap of Discharge Port with Allen key (8mm).
5. Open the Service Valve with Allen key (4mm) to release the dirty water from the Discharge Port into a container. Close the service valve when the container is full to avoid spillage in the outdoor unit. Dispose the dirty water.
6. Reinstall the Cap of Discharge Port and Magnet Bar.
7. Re-charge the water to Space Heating / Cooling circuit if necessary.
(For details, refer to 12.4.10 Charging the Water)
8. Turn ON the power supply.



CAUTION

Do not clean the outdoor unit with hydrocarbon solvents when Outdoor Unit needs to be cleaned during installation or servicing.

12.5 Appendix

12.5.1 Variation of System



This section introduces variation of various systems using Air-To-Water Heatpump and actual setting method.

(NOTE) : This model does not have a built-in expansion vessel to prevent the pressure in the water circuit from rising in the event of temperature rise. Be sure to purchase in the market and install it.

12.5.1.1 Introduce Applications Related to Temperature Setting



12.5.1.1.1 Temperature Setting Variation for Heating

1. Remote Controller



Connect floor heating or radiator directly to the Outdoor Unit.
Install remote controller on the wall of the room.
This is the basic form of the simplest system.



2. Room Thermostat




Connect floor heating or radiator directly to the Outdoor Unit.
Install the remote controller in the room where floor heating is installed.
This is an application that uses remote controller as Room Thermostat.

12.5.1.2 Examples of Installations

1. DHW (Domestic Hot Water) Tank connection



2. Boiler connection



This is an application that connects the boiler to the Outdoor Unit, to compensate for insufficient capacity by operate boiler when outdoor temperature drops & heat pump capacity is insufficient.

Boiler is connected parallel with heat pump and used as heating circuit.

Besides that, an application that connects to the DHW tank's circuit to heat up tank 's hot water is also possible.

Boiler output can be control by either SG ready input from Control Module unit or Auto control by 3 modes selection pattern.

(Operation setting of boiler shall be responsible by installer.)

Depending on the settings of the boiler, it is recommended to install buffer tank as temperature of circulating water may get higher. (It must connect to buffer tank especially when select Advanced Parallel setting) However, buffer tank connection requires Control Module unit.

Note: Buffer tank thermistor must be connected to Control Module unit PCB.

WARNING

Panasonic is NOT responsible for incorrect or unsafe situation of the boiler system.

CAUTION

Make sure the boiler and its integration in the system complies with applicable legislation.
 Make sure the return water temperature from the heating circuit to the Outdoor Unit does NOT exceed 70°C.
 Boiler is turned off by safety control when the water temperature of the heating circuit exceed 85°C.

If you wish to use optional features other than connecting DHW tank or boiler, purchase an optional indoor unit or Control Module unit.


Functions that become available by purchasing an indoor unit, etc. include:

- Buffer tank connection
 - 2-zone control
 - Solar connection
 - SG Ready
 - Demand control
 - and others
- } Optional PCB is required

12.5.2 System Installation


12.5.2.1 Remote Controller Outline

The LCD display as shown in this manual are for instructional purpose only, and may differ from the actual unit.



- A: Main screen ———— Display information
- B: Menu ———— Open/Close main menu
- C: Triangle (Move) ———— Select or change item
- D: Operate ———— Start/Stop operation
- E: Back ———— Back to previous item
- F: Quick Menu ———— Open/Close Quick menu
- G: Enter ———— Confirm

LCD Display (Actual - Dark background with white icons)



1 Function icon ———— Displays the set functions/status.

- | | |
|-----------------------------------|----------------|
| Holiday mode | Demand control |
| Weekly timer | Room heater |
| Quiet mode | Tank heater |
| Remote controller room thermostat | Solar |
| Powerful mode | Boiler |

2 Water pressure (circulation circuit) ———— [bar]

3 Mode ———— Display set mode / current status of mode.

- | | | | |
|---------------------|------------------|--------------|--------------|
| Heating | Cooling | | |
| Auto | Hot water supply | Auto heating | Auto cooling |
| Heat pump operating | | | |

4 Temp setting ———— Set room temp Compensation curve Set direct water temp Set pool temp

5 Display Heat temp ———— Displays current heating temperature (it is set temperature when enclosed by line)

6 Outdoor temp ———— Displays outdoor temperature

7 Display tank temp ———— Displays current tank temperature (it is set temperature when enclosed by line)

First time of power ON (Start of installation)

Initialization	12:00 pm, Mon
Initializing	

When the power is ON, firstly the initialization screen appears (10 sec)



	12:00 pm, Mon
[⏻] Start	

When the initialization screen ends, it turns to normal screen.



Language	12:00 pm, Mon
ENGLISH	
FRANÇAIS	
DEUTSCH	
ITALIANO	
▼ Select	[↵] Confirm

When any button is pressed, language setting screen appears.
(NOTE) If initial setting is not performed, it does not go into menu.

When there are two remote controllers installed from the beginning, the first remote controller which set language will be recognised as the main remote controller.

↓ Set language & confirm

Clock format	12:00 pm, Mon
24h	
▼	
am/pm	
▼ Select	[↵] Confirm

When language is set, setting screen of time display appears (24h/am/pm)

↓ Set time display & confirm

Date & time	12:00 pm, Mon
Year/Month/Day	Hour : Min
2024 / 01 / 01	12 : 00 pm
⬅️ Select	[↵] Confirm

YY/MM/DD/Time setup screen appears

↓ Set YY/MM/DD/Time & confirm

Front grille	12:00 pm, Mon
Is O/D front grille fixed?	
No	
Yes	
▼ Select	[↵] Confirm

If set to No & confirm, a caution message will be displayed to ensure outdoor front grille is installed before proceeding to operate the unit.



Caution	
To prevent injury, fix front grille before ope.	
[↵] Close	

↓ Set Yes & confirm if outdoor front grille has been installed

	12:00 pm, Mon
[⏻] Start	

Back to initial screen


↓ Press Menu and select Installer setup

Main menu	12:00 pm, Mon
System check	
Personal setup	
Service contact	
Installer setup	
▲ Select	[←] Confirm


↓ Confirm to go into Installer setup

12.5.3 Setup

12.5.3.1 Installer Setup



※ The above description is for outdoor unit alone case.
For indoor units, please refer to the installation manual supplied with the indoor unit.



※ The above description is for outdoor unit alone case.
 For indoor units, please refer to the installation manual supplied with the indoor unit.

12.5.3.2 System Setup

<div style="border: 1px solid black; padding: 2px; display: inline-block;">1. Zone & Sensor</div>	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Initial setting: Water temp.</div>	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="padding: 2px;">System setup</td> <td style="text-align: right; padding: 2px;">12:00am, Mon</td> </tr> <tr> <td colspan="2" style="background-color: #f0f0f0; padding: 2px;">Zone & Sensor</td> </tr> <tr> <td colspan="2" style="padding: 2px;">Anti freezing</td> </tr> <tr> <td colspan="2" style="padding: 2px;">Tank connection</td> </tr> <tr> <td colspan="2" style="padding: 2px;">DHW capacity</td> </tr> <tr> <td style="padding: 2px;">▼ Select</td> <td style="text-align: right; padding: 2px;">[↵] Confirm</td> </tr> </table>	System setup	12:00am, Mon	Zone & Sensor		Anti freezing		Tank connection		DHW capacity		▼ Select	[↵] Confirm
System setup	12:00am, Mon													
Zone & Sensor														
Anti freezing														
Tank connection														
DHW capacity														
▼ Select	[↵] Confirm													

Select sensor of room temperature control from the following 2 items:

- ① Water temperature (circulation water temperature)
- ② Room thermostat (Internal)

<div style="border: 1px solid black; padding: 2px; display: inline-block;">2. Anti freezing</div>	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Initial setting: Yes</div>	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="padding: 2px;">System setup</td> <td style="text-align: right; padding: 2px;">12:00am, Mon</td> </tr> <tr> <td colspan="2" style="background-color: #f0f0f0; padding: 2px;">Zone & Sensor</td> </tr> <tr> <td colspan="2" style="padding: 2px;">Anti freezing</td> </tr> <tr> <td colspan="2" style="padding: 2px;">Tank connection</td> </tr> <tr> <td colspan="2" style="padding: 2px;">DHW capacity</td> </tr> <tr> <td style="padding: 2px;">▲ Select</td> <td style="text-align: right; padding: 2px;">[↵] Confirm</td> </tr> </table>	System setup	12:00am, Mon	Zone & Sensor		Anti freezing		Tank connection		DHW capacity		▲ Select	[↵] Confirm
System setup	12:00am, Mon													
Zone & Sensor														
Anti freezing														
Tank connection														
DHW capacity														
▲ Select	[↵] Confirm													

Operate anti-freezing of water circulation circuit.
If select "Yes", when the water temperature is reaching its freezing temperature, the circulation pump will start up. If the water temperature does not reach the pump stop temperature, heat pump will be activated.

(NOTE) If set to "No", when the water temperature is reaching its freezing temperature or below 0°C, the water circulation circuit may freeze and cause malfunction.

<div style="border: 1px solid black; padding: 2px; display: inline-block;">3. Tank connection</div>	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Initial setting: No</div>	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="padding: 2px;">System setup</td> <td style="text-align: right; padding: 2px;">12:00am, Mon</td> </tr> <tr> <td colspan="2" style="background-color: #f0f0f0; padding: 2px;">Zone & Sensor</td> </tr> <tr> <td colspan="2" style="padding: 2px;">Anti freezing</td> </tr> <tr> <td colspan="2" style="padding: 2px;">Tank connection</td> </tr> <tr> <td colspan="2" style="padding: 2px;">DHW capacity</td> </tr> <tr> <td style="padding: 2px;">▲ Select</td> <td style="text-align: right; padding: 2px;">[↵] Confirm</td> </tr> </table>	System setup	12:00am, Mon	Zone & Sensor		Anti freezing		Tank connection		DHW capacity		▲ Select	[↵] Confirm
System setup	12:00am, Mon													
Zone & Sensor														
Anti freezing														
Tank connection														
DHW capacity														
▲ Select	[↵] Confirm													

Select whether a hot water storage tank is connected or not.
If set to "Yes", the water heating function is set to be used.
The tank water temperature can be set from the main screen.

<div style="border: 1px solid black; padding: 2px; display: inline-block;">4. DHW capacity</div>	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Initial setting: Variable</div>	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="padding: 2px;">System setup</td> <td style="text-align: right; padding: 2px;">12:00am, Mon</td> </tr> <tr> <td colspan="2" style="background-color: #f0f0f0; padding: 2px;">Zone & Sensor</td> </tr> <tr> <td colspan="2" style="padding: 2px;">Anti freezing</td> </tr> <tr> <td colspan="2" style="padding: 2px;">Tank connection</td> </tr> <tr> <td colspan="2" style="padding: 2px;">DHW capacity</td> </tr> <tr> <td style="padding: 2px;">▲ Select</td> <td style="text-align: right; padding: 2px;">[↵] Confirm</td> </tr> </table>	System setup	12:00am, Mon	Zone & Sensor		Anti freezing		Tank connection		DHW capacity		▲ Select	[↵] Confirm
System setup	12:00am, Mon													
Zone & Sensor														
Anti freezing														
Tank connection														
DHW capacity														
▲ Select	[↵] Confirm													

Variable DHW capacity setting normally runs with efficient boiling which is energy saving heating. But while hot water usage is high and tank water temperature is low, variable DHW mode will run with fast heat up which heat up the tank with high heating capacity.
If standard DHW capacity setting is selected, heat pump runs with heating rated capacity at tank heat up operation.

※ Only when "Yes" is selected for tank connection

<div style="border: 1px solid black; padding: 2px; display: inline-block;">5. Base pan heater</div>	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Initial setting: No</div>	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="padding: 2px;">System setup</td> <td style="text-align: right; padding: 2px;">12:00am, Mon</td> </tr> <tr> <td colspan="2" style="padding: 2px;">Anti freezing</td> </tr> <tr> <td colspan="2" style="padding: 2px;">Tank connection</td> </tr> <tr> <td colspan="2" style="padding: 2px;">DHW capacity</td> </tr> <tr> <td colspan="2" style="padding: 2px;">Base pan heater</td> </tr> <tr> <td style="padding: 2px;">▲ Select</td> <td style="text-align: right; padding: 2px;">[↵] Confirm</td> </tr> </table>	System setup	12:00am, Mon	Anti freezing		Tank connection		DHW capacity		Base pan heater		▲ Select	[↵] Confirm
System setup	12:00am, Mon													
Anti freezing														
Tank connection														
DHW capacity														
Base pan heater														
▲ Select	[↵] Confirm													

Select whether Base pan heater is installed or not.
If set to "Yes", select to use either heater A or B.

A: Turn on Heater when heating with defrost operation only
B: Turn on Heater during heating operation when outside temperature is below 5 °C .

※ The above description is for outdoor unit alone case.
For indoor units, please refer to the installation manual supplied with the indoor unit.

6. Bivalent connection

Initial setting: No

System setup	12:00am, Mon
Tank connection	
DHW capacity	
Base pan heater	
Bivalent connection	
▲ Select	[←→] Confirm

Set if heat pump is linked with boiler operation.
 Connect the start signal of the boiler to the boiler contact terminal (main PCB).
 Set Bivalent connection to "Yes".
 Then, begin setting according to remote controller instruction.
 Boiler icon will be displayed on remote controller top screen.

• Auto

There are 3 different modes in the boiler auto pattern operation. Movement of each mode is as shown below:

- ① Alternative (switch to boiler operation when drops below setting temperature)
- ② Parallel (allow boiler operation when drops below setting temperature)
- ③ Advanced Parallel (able to slightly delay boiler operation time of parallel operation)


When the boiler operation is "ON", "boiler contact" is "ON", "_(underscore)" will be displayed below the boiler icon.

Please set target temperature of boiler to be the same as heat pump temperature.


When boiler temperature is higher than heat pump temperature, zone temperature cannot be achieved if mixing valve is not installed.

This product only allows one signal to control the boiler operation. Operation setting of boiler shall be responsible by installer.

Alternative mode




Parallel mode






Advanced Parallel mode

For heating



For DHW tank



In Advanced Parallel mode, setting for both Heat and Tank can be made simultaneously. During operation of "Heat/Tank" mode, when each time the mode is switched, the boiler output will be reset to OFF. Please have good understanding on the boiler control characteristic in order to select the optimal setting for the system.

• Smart


There are Energy price (both electricity and boiler) and Schedule to be set on remote controller.

Operation setting of Energy price and Schedule shall be responsible by installer.

Based on these settings, system will calculate the final price for both electricity and boiler.

When final price of Electricity is lower than Boiler's, heat pump will operate.

When final price of Electricity is higher than Boiler's, boiler will operate.



※ The above description is for outdoor unit alone case.

For indoor units, please refer to the installation manual supplied with the indoor unit.

7. Circulation Liquid	Initial setting: Water	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 70%;">System setup</td> <td style="width: 30%;">12:00am, Mon</td> </tr> <tr> <td colspan="2">DHW capacity</td> </tr> <tr> <td colspan="2">Base pan heater</td> </tr> <tr> <td colspan="2">Bivalent connection</td> </tr> <tr> <td colspan="2" style="background-color: #333; color: white;">Circulation Liquid</td> </tr> <tr> <td>◀ Select</td> <td>[↵] Confirm</td> </tr> </table>	System setup	12:00am, Mon	DHW capacity		Base pan heater		Bivalent connection		Circulation Liquid		◀ Select	[↵] Confirm
System setup	12:00am, Mon													
DHW capacity														
Base pan heater														
Bivalent connection														
Circulation Liquid														
◀ Select	[↵] Confirm													

Set circulation of heating water.

There are 2 types of settings: water and glycol.

(NOTE) Please set glycol when using anti-freeze liquid. It may cause error if setting is wrong.

8. Force Defrost	Initial setting: Manual	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 70%;">System setup</td> <td style="width: 30%;">12:00am, Mon</td> </tr> <tr> <td colspan="2">Base pan heater</td> </tr> <tr> <td colspan="2">Bivalent connection</td> </tr> <tr> <td colspan="2">Circulation Liquid</td> </tr> <tr> <td colspan="2" style="background-color: #333; color: white;">Force Defrost</td> </tr> <tr> <td>◀ Select</td> <td>[↵] Confirm</td> </tr> </table>	System setup	12:00am, Mon	Base pan heater		Bivalent connection		Circulation Liquid		Force Defrost		◀ Select	[↵] Confirm
System setup	12:00am, Mon													
Base pan heater														
Bivalent connection														
Circulation Liquid														
Force Defrost														
◀ Select	[↵] Confirm													

Under manual code, user can turn on force defrost through quick menu.

If 'Auto' is selected, the outdoor unit will run defrost operation once if heat pump have long hour of heating without any defrost operation at low ambient condition. (Even when Auto is selected, user still can turn on force defrost through quick menu)

9. Pump flowrate	Initial setting: ΔT	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 70%;">System setup</td> <td style="width: 30%;">12:00am, Mon</td> </tr> <tr> <td colspan="2">Bivalent connection</td> </tr> <tr> <td colspan="2">Circulation Liquid</td> </tr> <tr> <td colspan="2">Force Defrost</td> </tr> <tr> <td colspan="2" style="background-color: #333; color: white;">Pump flowrate</td> </tr> <tr> <td>◀ Select</td> <td>[↵] Confirm</td> </tr> </table>	System setup	12:00am, Mon	Bivalent connection		Circulation Liquid		Force Defrost		Pump flowrate		◀ Select	[↵] Confirm
System setup	12:00am, Mon													
Bivalent connection														
Circulation Liquid														
Force Defrost														
Pump flowrate														
◀ Select	[↵] Confirm													

If pump flowrate setting is *ΔT, the unit adjusts pump duty to use different water inlet and outlet based on the setting of *ΔT for heating ON and *ΔT for cooling ON in operation setup menu during indoor operation.

If pump flowrate setting is set to Max. duty, the unit will set the pump duty at *Pump maximum speed in the service setup menu during room side operation.

*1

10. DHW Defrost	Initial setting: Yes	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 70%;">System setup</td> <td style="width: 30%;">12:00am, Mon</td> </tr> <tr> <td colspan="2">Circulation Liquid</td> </tr> <tr> <td colspan="2">Force Defrost</td> </tr> <tr> <td colspan="2">Pump flowrate</td> </tr> <tr> <td colspan="2" style="background-color: #333; color: white;">DHW Defrost</td> </tr> <tr> <td>◀ Select</td> <td>[↵] Confirm</td> </tr> </table>	System setup	12:00am, Mon	Circulation Liquid		Force Defrost		Pump flowrate		DHW Defrost		◀ Select	[↵] Confirm
System setup	12:00am, Mon													
Circulation Liquid														
Force Defrost														
Pump flowrate														
DHW Defrost														
◀ Select	[↵] Confirm													

When DHW defrost set to "YES", hot water of domestic hot water tank will be used during defrost cycle.

When DHW defrost set to "NO", hot water of floor heating circuit will be used during defrost cycle.

11. Heating control	Initial setting: Comfort	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 70%;">System setup</td> <td style="width: 30%;">12:00am, Mon</td> </tr> <tr> <td colspan="2">Force Defrost</td> </tr> <tr> <td colspan="2">Pump flowrate</td> </tr> <tr> <td colspan="2">DHW Defrost</td> </tr> <tr> <td colspan="2" style="background-color: #333; color: white;">Heating control</td> </tr> <tr> <td>◀ Select</td> <td>[↵] Confirm</td> </tr> </table>	System setup	12:00am, Mon	Force Defrost		Pump flowrate		DHW Defrost		Heating control		◀ Select	[↵] Confirm
System setup	12:00am, Mon													
Force Defrost														
Pump flowrate														
DHW Defrost														
Heating control														
◀ Select	[↵] Confirm													

There are two modes to select for compressor frequency control: "Comfort" or "Efficiency".

When set to Comfort mode, the compressor will run at the zone limit maximum frequency to reach the set temperature faster.

When set to Efficiency mode, the compressor will run at part load frequency at initial stage for energy saving.

When "Efficiency" is selected, the time setting will transition to 1st, 2nd, and 3rd stage. Increasing the time will slowly increase the capacity.

*1 Only when the selection for Tank connection is Yes

✘ The above description is for outdoor unit alone case.

For indoor units, please refer to the installation manual supplied with the indoor unit.

12. External meter

Initial setting: [Heat-cool meter : No]
 [Tank meter : No] *only available
 when Heat-cool meter select Yes
 [Elec. meter HP : No]
 [Elec. meter 1 (PV meter) : No]
 [Elec. meter 2 (Total building) : No]
 [Elec. meter 3 (Reserve) : No]

System setup	12:00am, Mon
Pump flowrate	
DHW Defrost	
Heating control	
External meter	
⬆ Select	[↵] Confirm

There are two systems for generation meter connection: single generation meter system (Heat-cool meter) or two generation meter system (Heat-cool meter and Tank meter)
 Both systems can provide all generation data of heating, cooling and DHW directly from external meter.
 If Heat-cool meter is set to "Yes", it will read from external meter for heat pump's energy generation data during heating, cooling and DHW operation¹.
 If Heat-cool meter is set to "No", it will base on unit's calculation for heat pump's energy generation data during heating, cooling and DHW operation.
 If Heat-cool meter is set to "Yes", it will read from external meter for heat pump's energy generation data during heating, cooling and DHW operation¹.
 If Elec. meter HP is set to "Yes", it will read from external meter for heat pump's energy consumption data.
 If Elec. meter HP is set to "No", it will base on unit's calculation for heat pump's energy consumption data.
 If Elec. meter 1 (PV meter) is set to "Yes", it will read from external meter for energy generation data of solar system and display it on Cloud system.
 If Elec. meter 2 (Building) is set to "Yes", it will read from external meter for energy consumption data of the building and display it on Cloud system.
 If Elec. meter 3 (Reserve) is set to "Yes", it will read from external meter for energy consumption data obtained from reserved electricity meter and display it on Cloud system.
¹ Set Heat-cool meter to Yes and set Tank meter to No when 1 generation meter system is installed.
 Set Heat-cool meter to Yes and set Tank meter to Yes when 2 generation meter system is installed.
 Remarks: Elec. meter HP refers to the electricity meter that measures Heat Pump unit's consumption.
 Elec. meter 1 / 2 / 3 refers to the Electricity meter No. 1 / No. 2 / No. 3.

13. Static pressure

Initial setting: No

If set to "No", the outdoor fan motor operates at a normal speed.
 If set to "YES", the outdoor fan motor operates at a higher speed in response to high static pressure.

System setup	12:00am, Mon
DHW Defrost	
Heating control	
External meter	
Static pressure	
⬆ Select	[↵] Confirm

14. Cooling Capacity

Initial setting: Efficiency

Select the cooling capacity.
 If set to "Efficiency", the unit performs cooling operation efficiently at rated capacity.
 If set to "Comfort", the cooling operation is performed at maximum capacity.

System setup	12:00am, Mon
Heating control	
External meter	
Static pressure	
Cooling capacity	
⬆ Select	[↵] Confirm

※ The above description is for outdoor unit alone case.
 For indoor units, please refer to the installation manual supplied with the indoor unit.

12.5.3.3 Operation Setup

Heat

15. Water temp. for heating ON Initial setting: compensation curve

Set the target water temperature to perform heating operation.
 Compensation curve: Target water temperature change in conjunction with outdoor temperature change.
 Direct: Set the circulation water temperature directly.

16. Outdoor temp. for heating OFF

If the operation of the outdoor unit is frequently switched on and off depending on the outdoor air temperature, the following settings can be used to reduce the frequency.

a. Outdoor temp. for heating OFF Initial setting: 24°C

Set outdoor temp. to stop heating
 Setting range is 6°C~35°C

b. Outdoor temp. for heating ON Initial setting: 23°C

Set outdoor temp. to start heating.
 Setting range is 5°C~X°C (X is heating OFF temp. -1)

c. Heating ON delay time Initial setting: 0:30min

Set delay time from heating OFF to heating ON.

17. ΔT for heating ON Initial setting: 5°C

Set temp difference between out temperature and return temperature of circulating water during Heating operation.
 When the temperature gap is enlarged, it is energy saving but less comfort. When the gap gets smaller, energy saving effect gets worse but it is more comfortable.
 Setting range is 1°C ~ 15°C

※ The above description is for outdoor unit alone case.
 For indoor units, please refer to the installation manual supplied with the indoor unit.

Cool ※ Cooling model only

<div style="border: 1px solid black; padding: 2px; display: inline-block; margin-bottom: 5px;">18. Water temp. for cooling ON</div>	<div style="border: 1px solid black; padding: 2px; display: inline-block; margin-bottom: 5px;">Initial setting: compensation curve</div>	
<p>Set target water temperature to perform cooling operation. Compensation curve: Target water temperature change in conjunction with outdoor ambient temperature change. Direct: Set the circulation water temperature directly.</p>		

<div style="border: 1px solid black; padding: 2px; display: inline-block; margin-bottom: 5px;">19. ΔT for cooling ON</div>	<div style="border: 1px solid black; padding: 2px; display: inline-block; margin-bottom: 5px;">Initial setting: 5°C</div>	
<p>Set temp difference between out temperature and return temperature of circulating water during Cooling operation. When the temperature gap is enlarged, it is energy saving but less comfort. When the gap gets smaller, energy saving effect gets worse but it is more comfortable. Setting range is 1°C ~ 15°C</p>		

Auto ※ Cooling model only

<div style="border: 1px solid black; padding: 2px; display: inline-block; margin-bottom: 5px;">20. Outdoor temp. for (Heat to Cool)</div>	<div style="border: 1px solid black; padding: 2px; display: inline-block; margin-bottom: 5px;">Initial setting: 15°C</div>	
<p>Set outdoor temp that switches from Heating to Cooling by Auto setting. Setting range is 11°C ~ 25°C Timing of judgement is every 1 hour</p>		

<div style="border: 1px solid black; padding: 2px; display: inline-block; margin-bottom: 5px;">21. Outdoor temp. for (Cool to Heat)</div>	<div style="border: 1px solid black; padding: 2px; display: inline-block; margin-bottom: 5px;">Initial setting: 10°C</div>	
<p>Set outdoor temp that switches from Cooling to Heating by Auto setting. Setting range is 5°C ~ 14°C Timing of judgement is every 1 hour</p>		

※ The above description is for outdoor unit alone case.
 For indoor units, please refer to the installation manual supplied with the indoor unit.


Tank ※ Only when the selection for Tank connection is Yes

22. Floor operation time (max.)

Initial setting: 8h

Set the max. operating hours of heating.
When max. operation time is shortened, it can boil the tank more frequently.


It is a function for Heating + Tank operation.



23. Tank heat up time (max.)

Initial setting: 1h


Set the max. boiling hours of tank.
When the max. boiling hours are shortened, it immediately returns to Heating operation, but it may not fully boil the tank.



24. Tank re-heat temp.

Initial setting: -8°C

Set the temperature to re-boil the tank water.
Setting range is -12°C ~ -2°C



25. Sterilization


Initial setting: 65°C 10min.

Set timer to perform sterilization.

- ① Set operating day & time. (Weekly timer format)
- ② Sterilization temperature (* 55 ~ 65°C)
- ③ Operation time (Time to run sterilization when it reached setting temperature. (5 ~ 60 minutes))

* When the outdoor air temperature is below -15°C
The Tank temperature may only rise to about 55°C.
(Turn on the external heater to perform sterilization. Need Indoor unit).
Sterilization temperature varies depending on the model.

The use/non-use of the sterilization mode must be set.



※ The above description is for outdoor unit alone case.
For indoor units, please refer to the installation manual supplied with the indoor unit.

12.5.3.4 Service Setup

26. Pump maximum speed	Initial setting: Depend on model	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="2">Service setup</td> <td style="text-align: right;">12:00am, Mon</td> </tr> <tr> <td style="width: 33%;">Flow rate</td> <td style="width: 33%;">Max. Duty</td> <td style="width: 34%;">Operation</td> </tr> <tr> <td>34.4 L/min</td> <td>0xCE</td> <td style="text-align: center;">▲ Air Purge</td> </tr> <tr> <td colspan="3" style="padding-top: 5px;">◀ Select</td> </tr> </table>	Service setup		12:00am, Mon	Flow rate	Max. Duty	Operation	34.4 L/min	0xCE	▲ Air Purge	◀ Select		
Service setup		12:00am, Mon												
Flow rate	Max. Duty	Operation												
34.4 L/min	0xCE	▲ Air Purge												
◀ Select														

Normally setting is not necessary.
Please adjust when needed to reduce the pump sound, etc.
Besides that, the unit has Air Purge function.

When the Pump flow setting is Max. Duty, this duty setting is the duty of fixed pump that runs during room-side operation.

<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="padding: 5px;">27. Dry concrete</td> </tr> </table> <p style="margin-top: 10px;">Operate concrete curing operation. Select Edit and set the temperature for every stage (1~99 1 is for 1 day). Setting range is 25~55°C</p> <p>When it is turned ON, dry concrete starts.</p>	27. Dry concrete	
27. Dry concrete		

<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="padding: 5px;">28. Service contact</td> </tr> </table> <p style="margin-top: 10px;">Able to set the name & tel. no. of contact person when there is breakdown etc. or client has trouble. (2 items)</p>	28. Service contact	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="2">Service setup</td> <td style="text-align: right;">12:00am, Mon</td> </tr> <tr> <td colspan="3">Service contact:</td> </tr> <tr> <td colspan="3" style="text-align: center;">Contact 1</td> </tr> <tr> <td colspan="3" style="text-align: center;">Contact 2</td> </tr> <tr> <td colspan="2" style="padding-top: 5px;">▲ Select</td> <td style="padding-top: 5px;">[↵] Confirm</td> </tr> </table>	Service setup		12:00am, Mon	Service contact:			Contact 1			Contact 2			▲ Select		[↵] Confirm	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="2">Contact-1: Bryan Adams</td> </tr> <tr> <td style="width: 60%;">ABC/ abc</td> <td style="width: 40%;">0-9/ Other</td> </tr> <tr> <td colspan="2">A B C D E F G H I J K L M N O P Q R</td> </tr> <tr> <td colspan="2">S T U V W X Y Z a b c d e f g h i</td> </tr> <tr> <td colspan="2">j k l m n o p q r s t u v w x y z</td> </tr> <tr> <td colspan="2" style="padding-top: 5px;">▼ Select</td> </tr> <tr> <td colspan="2" style="padding-top: 5px;">[↵] Enter</td> </tr> </table>	Contact-1: Bryan Adams		ABC/ abc	0-9/ Other	A B C D E F G H I J K L M N O P Q R		S T U V W X Y Z a b c d e f g h i		j k l m n o p q r s t u v w x y z		▼ Select		[↵] Enter	
28. Service contact																																
Service setup		12:00am, Mon																														
Service contact:																																
Contact 1																																
Contact 2																																
▲ Select		[↵] Confirm																														
Contact-1: Bryan Adams																																
ABC/ abc	0-9/ Other																															
A B C D E F G H I J K L M N O P Q R																																
S T U V W X Y Z a b c d e f g h i																																
j k l m n o p q r s t u v w x y z																																
▼ Select																																
[↵] Enter																																

12.5.3.5 Remote Control Setup

<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="padding: 5px;">29. RC selection</td> </tr> </table> <p style="margin-top: 10px;">Set to "Single" when only one remote controller is installed. Set to "Dual" when two remote controllers are installed.</p>	29. RC selection	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="2">Initial setting : Single</td> </tr> </table>	Initial setting : Single		<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="2">RC selection</td> <td style="text-align: right;">12:00am, Mon</td> </tr> <tr> <td colspan="3" style="text-align: center;"> <div style="border: 1px solid black; padding: 2px; display: inline-block; margin-bottom: 5px;">Single</div> ▼ </td> </tr> <tr> <td colspan="3" style="text-align: center;">Dual</td> </tr> <tr> <td colspan="2" style="padding-top: 5px;">▼ Select</td> <td style="padding-top: 5px;">[↵] Confirm</td> </tr> </table>	RC selection		12:00am, Mon	<div style="border: 1px solid black; padding: 2px; display: inline-block; margin-bottom: 5px;">Single</div> ▼			Dual			▼ Select		[↵] Confirm
29. RC selection																	
Initial setting : Single																	
RC selection		12:00am, Mon															
<div style="border: 1px solid black; padding: 2px; display: inline-block; margin-bottom: 5px;">Single</div> ▼																	
Dual																	
▼ Select		[↵] Confirm															

※ The above description is for outdoor unit alone case.
For indoor units, please refer to the installation manual supplied with the indoor unit.

12.6 Service and Maintenance

If forget Password and cannot operate remote controller

↶ + ↵ + > Press for 5 seconds.

Password unlock screen appears, press Confirm and it shall reset. Password will become 0000. Please reset it again.

(NOTE) This is displayed only when the remote controller is password-locked.

12.6.1 Maintenance Menu

Setting method of Maintenance menu

Maintenance menu	12:00am, Mon
Actuator check	
Test mode	
Sensor setup	
Reset password	
▼ Select	[↵] Confirm

↶ + ↵ + > Press for 5 seconds.

Items that can be set

- ① Actuator check (Manual ON/OFF all functional parts)
(NOTE) As there is no protection action, please be careful not to cause any error when operating each part (do not turn on pump when there is no water etc.)
- ② Test mode (Test run)
Normally it is not used.
- ③ Sensor setup (offset gap of detected temp of each sensor can be set within -3~3°C range)
(NOTE) Please use only when sensor is deviated. It affects temperature control.
- ④ Reset password (password reset)

12.6.2 Custom Menu

Setting method of Custom menu

Custom menu	12:00am, Mon
Cool mode	
Reset energy monitor	
Reset operation history	
Anti-stick mode	
▼ Select	[↵] Confirm

≡ + ∨ + < Press for 5 seconds.

Items that can be set

- ① Cool mode (Set With/Without Cooling function) Default is without
(NOTE) As with/without Cool mode may affect electricity application, please be careful and do not simply change it.
In Cool mode, please be careful if piping is not insulated properly, dew may form on pipe and water may drip on the floor and damage the floor.
- ② Reset energy monitor (delete memory of Energy monitor)
Please use this when moving house and handover the unit.
- ③ Reset operation history (delete memory of operation history)
Please use this when moving house and handover the unit.
- ④ Anti-stick mode (select Anti-stick mode Enable/Disable)
Default is Anti-stick mode /Enable Every Monday at 3:00 AM the actuator is activated periodically to prevent sticking of the operating parts.
Select Disable if you wish to stop the part being activated periodically.
Parts and other components that may not operate if Disable is selected may stick if not operated for a long period of time.

※ The above description is for outdoor unit alone case.

For indoor units, please refer to the installation manual supplied with the indoor unit.

13. Installation and Servicing Air-to-Water using R290

 WARNING	This symbol shows that this equipment uses a flammable refrigerant with safety A3 group per ISO 817. If the refrigerant is leaked, together with an external ignition source, there is a possibility of fire / explosion.
--	---

13.1 About R290 Refrigerant

Hydrocarbon is a class of organic chemical made up only with the element Carbon (C) and Hydrogen (H). R290 is the type of Hydrocarbon refrigerant which is environmentally good-natured and odorless refrigerant. Under Kigali Amendment to the Montreal Protocol, 80% reduction of greenhouse gas emission by next 30 years is required, and due to this requirement, further reduction in the emission of high greenhouse effect gas is required. Therefore, the conversion of air-conditioning refrigerant into one which has no greenhouse effect, even if it is dissipated into the atmosphere became our responsibility.

Nevertheless, in case of air-conditioning refrigerant, it would be the best if there is a refrigerant which has no impact on global warming but ensures good energy efficiency and performance, and is safe; however, there is no such refrigerant which satisfies all these conditions. As a result, we have been considering the practical usage, within the safety frame-work, of R290 refrigerant which has no effect of global warming but highly flammable.

13.2 Characteristics of R290 Refrigerant

1. Chemical Characteristics

R290 (Propane) is refrigerant grade propane, which is natural, non toxic, and chemically stable compound formed by hydrogen.

R290 is one of natural refrigerant, therefore it has almost zero greenhouse gas effect. R-290 is a single-component hydrocarbon substance and the most hydrocarbon properties as it is highly flammable.

Chemical Characteristic Table of R290 and R32

	R290	R32
Chemical Formula	C3H8	CH2F2
Composition	Single Composition	Single Composition
Boiling point (°C)	-42.1	-51.7
50°C vapor pressure (MPa)	1.71	3.14
Ozone Depletion Potential	0	0
Global Warming Potential (GWP)	3	675
Inflammability	Highly Inflammable (A3)	Slightly Inflammable (A2L)
Toxicity	None	None

2. Characteristic of Pressure

As shown in Table 2, R290 has half the vapor pressure of R32 at the same refrigerant temperature.

As such, it can be installed and maintained with the same high-pressure tools and components as the R32.

Table 2. Saturated vapor pressure comparison table

(Unit: MPaG)

Temperature (°C)	Refrigerant	
	R290	R32
-20	0.14	0.30
0	0.37	0.71
20	0.74	1.37
40	1.27	2.38
60	2.03	3.84
65	2.23	4.29

Reference : Thermal properties table of Japan Society of Refrigerating and Air Conditioning Engineers (60, 65°C)
NIST REFPROP V8.0 (-20 ~ 40°C)

3. Flammable characteristic

As shown in below table, R290 is highly flammable and explosive when heated. The installation must be equipped with ATEX (Atmospheres Explosible) certified equipment and must always turn on the combustible gas detector during servicing and when entering the service area. Service must also be performed in a well-ventilated area, especially if the refrigerant system is being accessed.

3.1 Safety class

SAFETY GROUP			
Increasing Flammability ↑	Higher Flammability	A3	B3
	Lower Flammability	A2	B2
		A2L	B2L
	No Flame Propagation	A1	B1
		Lower Toxicity	Higher Toxicity
		Increasing Toxicity →	


Refrigerant	Burning Speed cm/s
R32	6.7
R290	38.7

3.2 Concentration control for R290

Because R290 is highly flammable, it can burn or explode if there is enough product concentrated in one space and the refrigerant comes in contact with an ignition source.

Control measurement;

Descriptions	Specifications
Lower flammability limit (LFL) [kg/m ³]	0.038
Lower flammability limit (LFL) [%]	2.1
Practical limit (PL) [kg/m ³]	0.008
Density of vapour [kg/m ³]	1.83



The concentration of R290 between the lower flammable limit (2%) and upper flammable limits (10%) is enough to ignite fire.

Note:
 LFL – Lower flammable limit whereby the concentration of flammable gas, vapour or mist in the air below which an explosive gas atmosphere will not be formed.
 UFL – Upper flammable limit whereby the concentration of flammable gas, vapour or mist in the air below which an explosive gas atmosphere will not be formed.
 PL – Defined as concentration used for simplified calculation to determine the maximum acceptable amount of refrigerant in an occupied space (20% of LFL)

3.3 Material classification and Hazard statement

H280	Contain gas under pressure; may explode if heated
CGA-HG01	May cause frostbite

13.3 Refrigerant piping installation • Tools used in services

13.3.1 Required Tools

R290 refrigerant air conditioners must use ATEX (Atmosphere Explosible) certified equipment. The common parts as R32 air conditioners for two-way valves and three-way valves (diameters of service ports); thus, they maintain commonality in the maintenance of the compressive strength, the size of pipe flaring, and the size of flare nuts as R32. However refrigerant pipe installation and services must use tools certified for highly flammable gas.

However, mixing of refrigerants is not allowed, so that you have to separate the cylinders for the recovery of refrigerants.

Tools used for installation • relocation • replacement of air conditioning units

Works	R290	R32
Connecting of refrigerant pipes	Not applicable for Monobloc	
	Not applicable for Monobloc	
Manifold gauge charging hose	HC Manifold gauge to avoid refrigerant contamination	R32 & R410A Common
Air purging	Vacuum pump complied with ATEX (Atmosphere Explosible)	Vacuum pump + Reducer / expander
Gas leakage test	Combustible gas detector	Detection liquid or soup water, HFC detector

For other installation, you can use general tools such as screw drivers (+, -), metal saws, long-nose pliers, hole core drills, linen tape, levels, temperature gauges, clamp meters, electric knives, nippers, pipe cutters, reamers or scrapers, spring benders, monkey wrenches, fixing wrenches, feeler gauges, hexagon wrenches (4 mm), testers, megohm testers, etc.

Tools used for services.

Works	R290	R32
Insertion of refrigerant	Digital scale for refrigerant charging, refrigerant cylinders, cylinder adopters and packing *a	
Recovery of refrigerant	Refrigerant recovery devices, refrigerant cylinders, manifold gauges, charging hoses *b	

*a. Use cylinder for each refrigerant, cylinder adopter and packing.

*b. Use refrigerant recovery cylinder separately for each refrigerant (**no mixture of refrigerant allowed**).

13.3.2 Tools for R290

1. Manifold gauges

R32 gauge can be used for R290 pressure.

Each port of manifold has different shapes in order to prevent inserting wrong refrigerant.

*However, the port shape for R290 and R32 is the same; therefore, attention need to be paid not to insert wrong refrigerant.

Differences in high/low pressure gauges

	R290 (common R32)
High pressure gauges (red)	-0.1 ~ 5.3 MPa -76 cmHg ~ 53 kgf / cm ²
Low pressure gauges (blue)	-0.1 ~ 3.8 MPa -76 cmHg ~ 38 kgf / cm ²

Difference in manifold port sizes

	R290 (common R32)
Port sizes	1/2 UNF20

2. Charging hoses

The material is changed to HC resistant, and the size of each manifold adopter is common, as the R32 port size of manifold gauge.

Further, some hoses are with anti-gas pressure backflow valves placed near the adopters. (hoses with the valves recommended)

Manifold gauges / Charging hoses



Differences in charging hoses

		R290 (common R32)
Pressure Resistance	Normal operation pressure	5.1 MPa (52 kgf / cm ²)
	Burst pressure	27.4 MPa (280 kgf / cm ²)
Material		HNBR rubber Internal nylon coating

3. Vacuum pump and isolator.

When using a vacuum pump, it is compulsory to use an ATEX certified vacuum pump.


When connecting service equipment (such as vacuum pumps) to a power source, the connection should be made in outside the Temporary Danger Zone.

It is recommended to use an ATEX Isolator switch to facilitate a safe shutdown in the danger zone.

It is necessary to set a solenoid valve in order to prevent backflow of vacuum pump oil into the charge hoses and use a vacuum pump with oil backflow prevention function.

If vacuum pump oil (mineral oil-based) mixes with R290, it may cause damage to the machine.

Vacuum pump



Isolator



4. Leak Detector

HC refrigerant Electric gas leakage tester is used for R290. The usage of existing HFC detectors cannot be used as they can produce spark. We recommend to use detectors specifically designed for combustible gas.


Combustible gas leak detector



5. Digital scale for refrigerant charging

R290 has lower pressure level and the evaporates speed is slow. Thus, the digital scale for refrigerant charging can be used in common with R32. The charging port for R32 is (1/2 UNF20), common with R290

Digital scale for refrigerant charging



6. Refrigerant cylinders

Refrigerant cylinders for R290 are painted in other colors that might subject to change according to the international standards. R290 is a single refrigerant, so that both liquid and gas insertion are possible. Additional charging is also possible.


Refrigerant cylinders



7. Connection ports of refrigerant cylinders and packing

Charging ports which fit to the charging hose connection port size (1/2 UNF20) is needed. At the same time, the packing has to be of HC resistant materials.

Connection ports and packing



8. Tools used for refrigerant piping installations and services

	Common tools	R290	R32
1.	Pipe cutters, reamers or scrapers	Not applicable for Monobloc	Not applicable for Monobloc
2.	Flare tools (clutch type)	Not applicable for Monobloc	Not applicable for Monobloc
3.	Torque wrench (1/4, 3/8)	Not applicable for Monobloc	Not applicable for Monobloc
4.	Torque wrench (1/2, 5/8)	Not applicable for Monobloc	Not applicable for Monobloc
5.	Manifold gauges, charging hose	○	○
6.	Vacuum pump, vacuum pump isolator *2	Connection 5/16 [ATEX certified] *1	
7.	Electric gas leakage detectors	Combustible gas detector	HFC detector
8.	Digital scale for refrigerant charging	○	○
9.	Recovery devices (connection port 5/16) *2	ATEX certified	HFC recovery devices
10.	Refrigerant cylinder color	Other (colors that might subject to change according to the international standards)	Other (colors that might subject to change according to the international standards)
11.	Refrigerant cylinder connection port and packing	x	○
12.	Allen wrench (4mm) Electric knives	x	○
*1	Those testers only for HC only cannot be for common use with HFC		
*2	Recovery devices which are certified by Atmosphere Explosible (ATEX)		
	<p>[Knowledge for the common usage of tools for R290 & R32] R290 and R32 machines use different compressor oils.</p> <ul style="list-style-type: none"> If unregulated compressor oil gets mixed into, it may cause damage to the machine function. 		
	<p>[Inserting wrong refrigerant]</p> <ul style="list-style-type: none"> It may cause "not cooling" and "not heating" customer claims because each component (expansion valve, compressor, PCB) of the refrigerant cycle is specially adjusted for R290. At the same time, it is not subject to product warranty, if wrong refrigerant was inserted into system. 		


Reference:-

- ASHRAE Standard 34-2016
- ISO Standard ISO 5149
- ISO 817:2014

13.4 New installation, and Repairing of Refrigerant Cycle System Procedures

Personnels working on A3 systems may be subject to applicable occupational hazard or regulations required by local or national law.

For safe servicing and disposal, technicians must have detailed knowledge and skills in handling of flammable refrigerants, prevention of refrigerant leaks, leak detection, personal protective equipment, cylinder handling and loading. A dry powder or CO₂ fire extinguisher must be available at the place of service.




13.5 Servicing

13.5.1 Recover R290 refrigerant with refrigerant recovery machine


CAUTION!

- Always turn ON the combustible leak detector.
- Keep all ignition sources, hot surface, and open flames 3 meter away from the product.
- Ensure the servicing area is well ventilated.
- Ensure the product is service by certified serviceman.
- Ensure to always have the approved fire extinguisher.



CAUTION!

All equipment and material must be ATEX certified to be allowed to operate within Atmosphere Explosible zone.




CAUTION!

Do not refill R290 refrigerant more that 50% of recovery cylinder capacity to avoid overpressure. (Safety risk)

Refrigerant Type	Recovery Cylinder Capacity
R32	80% of the weight
R290	50% of the weight

2. Connect the Low side charging hose of the manifold gauge to the service valve (2-way valve) in the outdoor unit.
3. Connect the center hose of the manifold gauge to the recovery machine.
4. Attached the manifold gauge correctly and tightly. Ensure both valve (Low side and High side) is in close position.
5. Connect the hose from recovery machine to the recovery cylinder.
6. Turn ON the recovery machine, turn the low side valve, service valve and recovery valve to open position.

13.5.2 Purging by using Nitrogen Gas Before Servicing and Disposal



1. Connect nitrogen cylinder to the high side at the manifold gauge. Ensure nitrogen cylinder is connected to pressure regulator.
2. Close air release valve and open service valve.
3. Open High side valve and nitrogen release valve. (Set the pressure regulator to 200psi).
4. Charge nitrogen gas up to 0.7MPa (101psi) or charge 400 grams of nitrogen into the unit.
5. Close high side valve and open air release valve (half open) to release remaining propane to the atmosphere. Air release valve must be directed 1 meter from the floor to enable the propane gas to spread properly in the atmosphere. [Beware not to fully open the air release valve to avoid high pressure and compressor oil discharge].
6. When gauge 1 pressure reach near atmospheric (15psi) point the combustible leak detector to air release valve to detect the presence of propane. If presence of propane can still be detected, repeat procedure 2 to 5 until presence of propane cannot be detected.
[Then refrigerant circuit repairment or unit decommissioning should be done].
7. Before charging new refrigerant, vacuum the system until it reaches to 500micron (67Pa) to remove foreign gas in the system and hold for 15 minutes.

14. Operation and Control

14.1 Basic Function

Inverter control, which equipped with a microcomputer in determining the most suitable operating mode as time passes, automatically adjusts output power for maximum comfort always. In order to achieve the suitable operating mode, the microcomputer maintains the set temperature by measuring the temperature of the environment and performing temperature shifting. The compressor at outdoor unit is operating following the frequency instructed by the microcomputer at indoor unit that judging the condition according to internal water setting temperature and water outlet temperature.

14.1.1 Internal Water Setting Temperature

Once the operation starts, control panel setting temperature will be taken as base value for temperature shifting processes. These shifting processes are depending on the Air-to-Water Heat pump settings and the operation environment. The final shifted value will be used as internal water setting temperature and it is updated continuously whenever the electrical power is supplied to the unit.

14.1.2 Heating Operation

14.1.2.1 Thermostat Control

- Compressor is OFF when Water Outlet Temperature – Internal Water Setting Temperature $> 3^{\circ}\text{C}$ for continuously 3 minutes.
- Compressor is ON after waiting for 3 minutes, if the Water Outlet Temperature – Water Inlet Temperature (temperature at thermostat OFF is triggered) $< -3^{\circ}\text{C}$.

14.1.2.2 Thermostat Control (Outdoor Ambient Temperature)

Stops provide heating to room side during high outdoor ambient condition.

Control content:

- Heating operation and water pump will turn OFF when outdoor ambient temperature $>$ outdoor thermo off temperature $+ 3^{\circ}\text{C}$.
(Outdoor thermo off set temperature is set by control panel. Thermo off set temperature is between $5^{\circ}\text{C} \sim 35^{\circ}\text{C}$)
- Heating operation will resume when Outdoor ambient temperature $<$ Outdoor thermo OFF set temperature $+ 1^{\circ}\text{C}$.

14.1.2.3 Heat Mode Operation

Operation of heat pump provide heating capacity to room side by hot water through heating panel, floor heating or fan coil unit.

- 1 3 ways valve control:
 - 3 ways valve switch and fix to heating side.
- 2 Heat pump operates follow normal heating operation.
- 3 Back up heater operate follow normal operation.
- 4 2 ways valve control:
 - 2 ways valve opens.

14.1.3 Cooling Operation

14.1.3.1 Thermostat Control

- Compressor is OFF when Water Outlet Temperature – Internal Water Setting Temperature $> -1.5^{\circ}\text{C}$ for continuously 3 minutes.
- Compressor is ON after waiting for 3 minutes, if the Water Outlet Temperature – Water Inlet Temperature (temperature at thermostat OFF is triggered) $> 3^{\circ}\text{C}$.

14.1.3.2 Cool Mode Operation

- 1 3 ways valve control:
 - 3 ways valve switch and fix to cooling side.
- 2 Heat pump operates follow normal cooling operation.
- 3 Room heater DOES NOT operate during cool mode.
- 4 2 ways valve control:
 - 2 ways valve is closed.

14.1.3.3 Cooling Capacity Control

The cooling capacity can be set to either Efficiency or Comfort priority. (However, this is only available for WH-WXG12ME8 and WH-WXG16ME8.)

Remocon setting : Cooling capacity = Efficiency (default)

Prioritize efficiency and operate the cooling with reduced capacity

Remocon setting : Cooling capacity = Comfort

Prioritize comfort and operate the cooling at maximum capacity.

14.1.4 Target Water Temperature Setting

14.1.4.1 Target Water Temperature Control of Standard System (Optional PCB not Connected)

There are 2 types of temperature control selection which are Compensation and Direct.

- Temperature control type selection by installer:
 - 1 Compensation : WLo, WHi, ODL0, ODH1 can be set at installer menu.
 - 2 Direct : Direct Water Temperature Set
- Remote control setting by user:
 - 1 Compensation : Shift value $\pm 5^{\circ}\text{C}$ from the compensation curve
 - 2 Direct : Direct water temperature set change

*This setting only able to set when room sensor select as Water Temperature.

*Instead of water temperature, user will set target room temperature when room sensor select as Room Thermistor OR Internal Room Thermostat.

- Target water temperature is calculated as below condition.
 - Target water temperature = A (Base temperature) + B (shift temperature)

A (Base Temperature)	Compensation	Direct
		Value from the curve + User shift value set

- B (shift temperature) value is depend on the room sensor selection at remote controller as below table:

B (Shift Temp.)	B shift value depend on the room sensor selection at remocon as table below
Sensor selection	
Water temperature	B = 0
External Room thermostat	B = 0
Internal Room thermostat & Room Thermistor	Cool Mode: B = 0 ; when Zone OFF or Zone Room Thermo OFF B = B = 1* (room set temp (R/C) – actual room temp) Max/Min Regulation of B: (Max = 5 ; Min = -5)
	Heat Mode: B = 0 ; when Zone OFF or Zone Room Thermo OFF B = follow Heating Room Temperature PI control logic


- Maximum/minimum regulation of Target Water Temperature

	Heating	Cooling
MAX	55°C (Below Ambient -25°C) * 75°C (Above Ambient -15°C) *	20°C
MIN	25°C	5°C

* Between outdoor ambient -15°C and -25°C, max target decreases gradually from 75°C to 55°C.

Compensation Type: (Operation under Heat Mode and Cool Mode)

- The set temperature defines the parameters for the ambient (Outdoor temperature) dependent operation of the unit. The water temperature is determined automatically depending on the outdoor temperature. Default setting is the colder outdoor temperature will result in warmer water and vice versa. The user has the possibility to shift up and shift down the target water by remote control setting.




- Outdoor ambient is updated every 30 minutes when operation ON.
- Setting water outlet temperature always follow $W_{(LO)}$ or $W_{(HI)}$ whenever is higher if outdoor ambient sensor or indoor communication error happen.

However, when powerful mode is requested by remote control during heating mode, the higher value of HLo or Whi will be used for A calculation.

* There are 2 compensation curves (for heating and cooling). During heating mode, the heating curve is used and during cooling mode, the cooling curve is use.

- Compensation curve set shift value:



14.1.5 Target Water Temperature at Extension System (Optional PCB is Connected, Excluding when Operating in Standalone)

Target water temperature is calculated as below.

- Heat Mode:
 - When buffer tank selection is "YES:"
Target water temperature = Target buffer tank temperature + [2°C]
 - When buffer tank selection is "NO"
 - If both zone 1 and zone 2 is active
Target Water Temperature = Higher zone target water temperature of Zone 1 and Zone 2.
 - If only one zone is active
Target Water Temperature = Zone target water temperature of active zone.

- Cool mode:
- When buffer tank selection is “YES”
 - If both zone 1 and zone 2 active
Target Water Temperature = Lower Zone Target Water Temperature of Zone 1 and Zone 2
 - If only one zone is active
Target Water Temperature = Zone Target Water Temperature of active zone
- When buffer tank selection is “NO”
 - If both zone 1 and zone 2 active
Target Water Temperature = Lower Zone Target Water Temperature of Zone 1 and Zone 2
 - If only one zone is active
Target Water Temperature = Zone Target Water Temperature of active zone

14.1.6 Target Zone Water Temperature Control

Purpose:- To control zone mixing and zone pump according to the zone sensor temperature

14.1.6.1 Target Zone 1 Water Temperature Setting Control

- Start condition
 - Heating zone 1 is ON by remote control or Timer or Auto Mode **OR**
 - Cooling zone 1 is ON by remote control or Timer or Auto Mode.
- Cancel condition
 - Heating zone 1 is OFF by remote control or Timer or Auto mode **AND**
 - Cooling zone 1 is OFF by remote control or Timer or Auto mode.
- Target Zone 1 water temperature is calculated as below condition.
 - Target Zone 1 water temperature = A (Base temperature) + B (shift temperature)

A (Base Temperature)	Compensation	Direct
	Value from the curve + User shift value set	Direct value from user setting

* During heat mode and compensation select, if powerful mode is activated, higher value of WLo or WHi will be use as curve value.

- B (shift temperature) value is depend on the room sensor selection at remote controller as below table:

B (Shift Temp.)	B shift value depend on the room sensor selection at remocon as table below
Sensor selection	
Water temperature	B = 0
External Room thermostat	B = 0
Internal Room thermostat & Room Thermistor	Cool Mode: B = 0 ; when Zone OFF or Zone Room Thermo OFF B = B = 1* (room set temp (R/C) – actual room temp) Max/Min Regulation of B: (Max = 5 ; Min = -5)
	Heat Mode: B = 0 ; when Zone OFF or Zone Room Thermo OFF B = follow Heating Room Temperature PI control logic
Pool Function Selected	B = Delta value setting from remocon

* B = 0 regardless of which sensor selection, if SHP control bit is enable except Pool function select (maintain Pool “B” value)

** Pool function also can be select at Zone 1 when optional PCB is connected and Zone 1 system is select.

- Maximum/minimum regulation of Target Water Temperature.

	Heating	Cooling
MAX	55°C (Below Ambient -25°C) * 75°C (Above Ambient -15°C) *	20°C
MIN	25°C	5°C

* Between outdoor ambient -15°C and -25°C, max target decreases gradually from 75°C to 55°C.

- Target Zone 1 Water Temperature (Heat mode only) during SG ready control
 - If buffer tank selection is “NO” then following shift is carried out.
 - While digital input is “10” or “11” then,
Final Target Zone 1 water temperature
= Target Zone 1 water temperature* (SG ready % setting (remote control menu))%
 - If buffer tank selection is “YES”
 - No shift of Target Zone 1 Water Temperature. Target Buffer Tank Temperature will change accordingly.
* Refer to “Buffer tank temperature control”

14.1.6.2 Target Zone 2 Water Temperature Setting Control (Excluding when Operating in Standalone)

- Start condition
 - Heating zone 2 is ON by remote control or Timer or Auto Mode **OR**
 - Cooling zone 2 is ON by remote control or Timer or Auto Mode.
- Cancel condition
 - Heating zone 2 is OFF by remote control or Timer or Auto mode **AND**
 - Cooling zone 2 is OFF by remote control or Timer or Auto mode.
- Target Zone 2 water temperature is calculated as below condition.
 - Target Zone 2 water temperature = A (Base temperature) + B (shift temperature)

A (Base Temperature)	Compensation	Direct
	Value from the curve + User shift value set	Direct value from user setting

* During heat mode and compensation select, if powerful mode is activated, higher value of WLo or WHi will be use as curve value.

- B (shift temperature) value is depend on the room sensor selection at remote controller as below table:

B (Shift Temp.)	B shift value depend on the room sensor selection at remocon as table below
Sensor selection	
Water temperature	B = 0
External Room thermostat	B = 0
Internal Room thermostat & Room Thermistor	Cool Mode: B = 0 ; when Zone OFF or Zone Room Thermo OFF B = B = 1* (room set temp (R/C) – actual room temp) Max/Min Regulation of B: (Max = 5 ; Min = -5)
	Heat Mode: B = 0 ; when Zone OFF or Zone Room Thermo OFF B = follow Heating Room Temperature PI control logic
Pool Function Selected	B = Delta value setting from remocon

* B = 0 regardless of which sensor selection, if SHP control bit is enable except Pool function select (maintain Pool “B” value)

** Pool function also can be select at Zone 2 when optional PCB is connected and Zone 2 system is select.

- Maximum/minimum regulation of Target Water Temperature.

	Heating	Cooling
MAX	55°C (Below Ambient -25°C) * 75°C (Above Ambient -15°C) *	20°C
MIN	25°C	5°C

* Between outdoor ambient -15°C and -25°C, max target decreases gradually from 75°C to 55°C.

- Target Zone 2 Water Temperature (Heat mode only) during SG ready control
 - If buffer tank selection is "NO" then following shift is carried out.
 - While digital input is "10" or "11" then,
Final Target Zone 2 water temperature
= Target Zone 1 water temperature* (SG ready % setting (remote control menu))%
 - If buffer tank selection is "YES"
 - No shift of Target Zone 2 Water Temperature. Target Buffer Tank Temperature will change accordingly.
* Refer to "Buffer tank temperature control"

14.1.6.3 Zone Temperature Control Contents

- During Standard System (Optional PCB not connected)
 - Only 1 zone temperature control is available
 - This zone room temperature is control by either one of the 4 room sensor (Room Th, Int/Ext Room Thermostat, Water temperature)
 - Target Zone Water Temperature is calculated based on selected temperature control type (Compensation or Direct) and selected room sensor. Target Water Temperature will set same as Target Zone Water Temperature
 - Target Water Temperature is the temperature for heat pump to operate refer to indoor water outlet sensor.
 - Heat pump and water pump OFF when ROOM Thermo OFF (Zone thermo OFF by Room Th or Room Thermostat).

* There will be no zone sensor connected to zone 1 (No zone sensor error), mixing valve and zone pump will not operate.

- During Extension System (Optional PCB connected)

* There will be no zone sensor connected to zone 1 (No zone sensor error), mixing valve and zone pump will not operate.


- During Extension System (Optional PCB connected)
 - Buffer Tank connection select "NO" &
 - One zone system is select
 - This zone room temperature control by either one of the 4 room sensor (Room Th, Int/Ext Room Thermostat, Water temp.)
 - Target Zone Water Temperature calculate base on selected temperature control type (Compensation or Direct) and selected room sensor.
 - Target Water Temperature will set same as Target Zone Water Temperature
 - Target Water Temperature is a temperature for heat pump to operate refer to indoor water outlet sensor.
 - Heat pump and water pump OFF when ROOM Thermo OFF (Zone thermo OFF by Room Th or Room Thermostat).

* There will be no zone sensor connected to zone 1 (No zone sensor error), mixing valve and zone pump will not operate.

- 2 zone system select
 - Each zone room temperature is control by each sensor which select from either one of the 4 room sensor
 - Target Zone 1 & 2 Water Temperature is calculated based on selected temperature control type (Compensation or Direct) and selected room sensor.
* Zone Mixing Valve & Zone pump will operate to achieve Target Zone Water Temperature which refer to zone sensor.
* Zone Sensor will detect if zone sensor is open or short.
 - Target Water Temperature will set same as the active & higher zone water temperature setting. (When cooling mode, lower zone water temp setting)
 - Target Water Temperature is the temperature for heat pump to operate refer to indoor water outlet sensor.


- Heat pump and water pump OFF when ROOM Thermo OFF (Both Zone thermo OFF by Room Th or Room Thermostat).
- Buffer Tank Connection select "YES" &
 - 1 zone system or 2 zone system select
 - Each zone control by each sensor which select from either one of the 4 room sensor
 - Target Zone 1 & 2 Water Temperature calculate base on selected temperature control type (Compensation or Direct) and selected room sensor. Each zone have their own Target Zone Water Temperature.
 - * Zone Mixing Valve & Zone pump will operate to achieve each Target Zone Water Temperature which refer to zone sensor
 - * Zone Sensor will detect if zone sensor is open or short.
 - Target Buffer Tank Temperature will be set as active & higher zone water temperature setting + Buffer Delta T. (Heating) Target Buffer Tank Temperature will be set as active & lower zone water temperature setting (Cooling).
 - Target Water Temperature will set as Target Buffer Tank Temperature + [2°C] (Heating) Target Water Temperature will set as Lower or Active Target Zone Water Temp. + [-3°C] (Cooling)
 - Target Water Temperature is a temperature for heat pump to operate refer to indoor water outlet sensor.
 - Heat pump and water pump OFF when ROOM thermo OFF
 - Heat mode: ROOM thermo OFF (Buffer Tank Temperature > Target Buffer Tank + [0°C]
 - Cool mode: ROOM Thermo OFF (Both Zone thermo OFF by Room Th or Room Thermostat)

14.1.7 Auto Mode Operation



- Control details:
 - To enable the unit to operate either heat or cool mode automatically, heat to cool set temperature and cool to heat set temperature can be set by control panel.
 - Automatic operation is judged based on control panel setting temperature and outdoor ambient temperature.
 - * Minimum setting of heat to cool set temperature is 1°C higher than cool to heat set temperature.
- Judgement control:
 - If outdoor ambient temperature < Heat to Cool Set Temperature, unit will operate in Heat Mode or else the unit will operate in Cool Mode.
 - If current operation is Cool mode, outdoor ambient temperature > Cool to Heat Temperature, unit will maintain Cool mode operation or else the unit will operate Heat mode.
 - If current operation is Heat mode, outdoor ambient temperature >Heat to Cool Temperature, unit will maintain Heat mode operation or else the unit will operate Cool mode.
 - Every 60 minutes the outdoor ambient temperature is judged.
 - When Auto + Tank mode is selected, operation mode switching is judged by both outdoor ambient temperature and indoor air temperature.

14.1.8 Auto Cooling Mode Operation Limit



- Auto Mode Cooling Only operation will start once the outdoor ambient temperature reaches 19°C and compressor will continue to run until the outdoor ambient temperature drops to 16°C.
- Due to this limitation, If Heat to Cool temperature is set lower than 19°C, the compressor will not operate until the outdoor ambient temperature reaches 19°C or higher.

14.1.9 Tank Mode Operation

- 3 ways valve direction
 - 3 ways valve switch to tank side during Tank Thermo ON condition. Switch 3 ways valve to room side when tank achieve Tank Thermo OFF temperature.
- Tank Thermo ON/OFF Characteristic
 - Tank Thermo OFF

Case 1: Internal Tank Heater is select and Tank Heater ON

- Tank temperature > Tank Set Temperature continuously for 15 seconds.
- Water outlet >75°C

- Case 2: Tank Heater OFF OR External Heater is select

- When heat pump OFF due to water thermos & Tank temperature > Tank water set temperature for continuously 20 seconds. **OR**
- Tank temperature > Tank set temperature + 1°C for continuously 20 seconds.

- Tank Thermo ON

Case 1: Tank Heater ON (Internal Tank Heater)

- Tank temperature < Tank set temperature + R/C (Tank re-heat temperature)

Case 2: Tank Heater OFF (Internal Tank Heater)

- Tank temperature < Tank water set temperature + R/C (Tank re-heat temperature)

* When tank thermo ON, water pump will ON for 3 minutes then only heat pump turn ON.

* Tank water set temperature = tank set temperature or 65°C whichever lower.

- 2 ways valve close
- Heat pump Thermostat Characteristic
 - Heat pump Water Outlet set temperature is set to below table:

Outdoor ambient temperature	Heat pump water outlet temperature
< -20°C	55°C
> -20°C	65°C
> -15°C	75°C

Characteristic of heat pump thermos ON/OFF under tank mode condition:

Water Outlet Thermo Condition

- Heat pump thermos OFF temperature:
 - 1 Heat pump thermo OFF temperature = Target Water outlet temperature + (3°C)
 - 2 Water outlet temperature > heat pump thermo OFF temperature for continuously 3 minutes, heat pump OFF but water pump continue ON.

- Heat pump thermo ON temperature
 - Heat pump thermo ON temperature = water inlet during thermo OFF time + [-3°C]
 - When water outlet temperature < heat pump thermo ON temperature, heat pump ON.

Water inlet thermo protection condition

- Heat pump thermo OFF temperature:
 - Water inlet temperature > [75°C/55°C] for continuously 30 seconds, heat pump OFF, water pump continue ON.
- Heat pump thermo ON temperature:
 - Heat pump thermos ON temp = water inlet temperature < [75°C/55°C].

Outdoor ambient temperature	Water inlet temperature
< -20°C	55°C
> -20°C	75°C

Thermo ON/OFF for Heat Pump in Tank Operation:

When tank temperature achieve heat pump OFF condition, refer below condition:

Conditon 1 : Tank Heater ON (Internal Tank Heater)

- Heat pump will turn OFF, water pump continue ON and room heater will continue ON if tank temperature below tank heater thermo ON condition. 3 ways valve will only switch to room side after tank temperature reach tank heater thermo OFF condition.

Conditon 2 : Tank Heater OFF (Internal Tank Heater)

- If tank temperature achieve tank thermo OFF, heat pump turn OFF, water pump turn OFF, room heater OFF and 3 ways valve switch to room side.

When tank temperature achieve heat pump ON condition, water pump ON, heat pump ON and room heater turn OFF.

Heat pump OFF condition at Tank Mode

- Tank temperature > tank water set temperature continuously for 20 seconds after heat pump thermos OFF due to water thermo. (Heat pump turn OFF but water pump continue ON and room heater turn ON to achieve tank set temperature) **OR**
- Tank temperature > tank set temperature + [1°C] for continuously 20 seconds. (Heat pump OFF, water pump OFF, room heater OFF and 3 ways valve switch to room side)

Heat pump ON condition at Tank Mode

- Tank temperature < tank water set temperature + R/C setting (Tank re-heat temp) (Water pump turn ON OR continue ON, heat pump ON and 3 ways valve switch to tank side or maintain at tank side)

Tank heater control

- Internal heater only operates to tank side if Tank heater ON and backup heater is enable.

Internal heater turn ON condition:

- Tank temperature < tank set temperature **AND**
- Heat pump thermos OFF **AND**
- 20 minutes from previous heater off **AND**
- Internal tank heater selects USE from control panel.

Internal heater turn OFF condition:

- Tank temperature > tank set temperature for continuously 15 seconds **OR**
- Heat pump thermo ON **OR**
- Mode change or operation is off by control panel.

14.1.10 Heat + Tank Mode Operation

- 1 3 ways valve control:
 - 3 ways valve switch to room side during room heat-up interval and switch to tank side during tank heat-up interval. Both modes will switch alternately. Tank mode is the initial running mode of Heat + Tank mode.

- 2 Heat pump operation control:
 - During room heat-up interval
 - Follow normal heating operation.
Switching to tank side depends to below cases:
Case 1:
[Previous switch from tank interval to room interval due to thermo OFF]
 - Switch to tank heat-up interval when Tank temp < Tank thermos ON temp (Room heat-up interval ends)
Case 2:
[If heating operation at room side is less than 30 minutes and switch to tank side 3 times consecutively]
 - Maintain at room heat-up interval regardless of the tank temperature. Switch to tank heat-up interval only when (Room Interval Timer is complete **OR** Room heat pump thermo OFF) **AND** Tank temperature < Tank thermo ON temperature.
Case 3:
[Previous switch from tank interval to room interval due to tank interval timer is complete]
 - Maintain at room heat-up interval regardless of the tank temperature. Switch to tank heat-up interval only when (Room Interval Timer is complete **OR** Room heat pump thermo OFF) **AND** tank temperature < Tank thermo ON temperature.
 - During Tank heat-up interval
 - Tank interval is the first mode running when heat + tank mode is select.
 - Switch to room interval only when tank achieve tank thermo OFF **OR** tank heat-up interval timer is complete.
 - Heat pump operates according to normal tank mode operation.

- 3 Room heater control:
 - During heating heat-up interval
 - Follow normal room heater control operation.

- 4 Tank heater control:
 - During heating heat-up interval
 - Internal tank heater will not function under heating heat-up interval.
 - During tank heat-up interval
 - Internal tank heater will turn ON after heat pump thermo off to boil tank temperature to tank set temperature.
 - 2 ways valve control is open
 - Water pump control:
 - Water pump always turn ON if room heat pump thermo ON **OR** Tank thermo ON.

14.1.11 Cool + Tank Mode Operation

- 1 3 ways valve control:
 - 3 ways valve switch to room side during room cooling interval and switch to tank side during tank heat-up interval. Both mode will switch alternately. Tank mode is the initial mode of cool + tank mode.

- 2 Heat pump operation control:
 - During room heat-up interval
 - Follow normal cooling operation.
Switching to tank side depends to below cases:
Case 1:
[Previous switch from tank interval to room interval due to thermo OFF]
 - Switch to tank heat-up interval when Tank temperature < Tank Thermo ON temperature (Room interval will ends)
Case 2:
[If cooling operation at room side is less than 30 minutes and switch to tank side for 3 times consecutively]

- Maintain at room cooling interval regardless of the tank temperature. Switch to tank heat-up interval only when (Room Interval Timer is complete **OR** Room heat pump thermo OFF) **AND** Tank temperature < Tank thermo ON temperature.

Case 3:

[Previous switch from tank interval to room interval is due to tank interval timer is complete]

- Maintain at room cooling interval regardless of the tank temperature. Switch to tank heat-up interval only when (Room Interval Timer is complete **OR** Room heat pump thermo OFF) **AND** tank temperature < Tank thermo ON temperature.


*Tank Thermo ON temperature:

Internal Tank Heater select USE	<Tank set temperature + R/C setting (Tank re-heat temperature)
Others	<Tank water set temperature + R/C setting (Tank re-heat temperature)

- During Tank heat-up interval
 - Tank interval is the first mode running when the cool + tank mode is select.
 - Switch to room interval only when tank achieve tank thermo OFF **OR** tank heat-up interval timer is complete.
 - Heat pump operates according to normal tank mode operation.
- 3 Room heater control:
- During room cooling interval
 - Room heater is OFF and not operates.
- 4 Tank heater control:
- During room cooling interval
 - Internal tank heater will not function under room cooling interval.
 - During tank heat-up interval
 - Internal tank heater will turn ON after heat pump thermos off to boil tank temperature to tank set temperature.
- 5 2 ways valve is close.
- 6 Water pump control:
- Water pump always turn ON if room heat pump thermo ON **OR** Tank thermo ON.

14.1.12 Outdoor Fan Motor Operation

Outdoor fan motor is adjusted according to operation condition. It starts when compressor starts operation and it stops 30 seconds after compressor stops operation.



The reason the outdoor fan stops 60 seconds after the compressor stops is to exhaust heat.


The reason why the compressor starts operating 30 seconds before it starts is to accurately detect the outside temperature.

14.2 Water Pump

The system will start checking on the water flow level after operation start for 30 seconds. If water pressure level is detected low or high continuously 300 seconds, the water pump and the compressor will be OFF permanently and OFF/ON control panel LED will blink (H21 error occurs).

14.2.1 Water Pump Control

- Once the indoor unit is ON, the water pump will be ON immediately and no error judgment for 30 seconds. However, during this 30 seconds operation, if there is any abnormality cause at outdoor or malfunction, the compressor should be OFF immediately and restart delay after 3 minutes.
- The system will start checking on the water flow level after operation start for 30 seconds. If water flow level is detected low continuously 140 seconds, the water pump and the compressor will be OFF permanently and OFF/ON control panel LED will blink (H62 error occurs).
- When error happens, the power has to be reset to clear the error.
- If there is no error indication, the water pump shall be continuously running.
- The water pump will remain ON when compressor OFF due to thermostat OFF setting is reached.
- Water pump will OFF when room thermo **OR** tank thermo **OR** buffer tank thermo OFF.
- Water pump will delay 30 seconds to turn OFF when request to OFF except during anti-freeze deice activate or air purge mode.



Maximum pump speed setting on remote control


- Standard pump speed is automatically controlled to get the designed water temperature different between water inlet and outlet (ΔT). Instead of setting the standard pump speed, maximum pump speed is manually adjusted by the installer according to water circuit pressure drop.

However, the following sequences do not follow maximum pump duty setting by remote control.


- Pump down mode
- Air purge mode
- Normal deice

1) P-Q graph for different pump HEX duty


- Standalone (WH-WXG09ME8, WH-WXG12ME8)




- Standalone (WH-WXG16ME8)



- Connection AiO (WH-WXG09ME8, WH-WXG12ME8)



- Connection AiO (WH-WXG16ME8)




※ This condition is under connecting ODU and connecting 5m piping (inner diameter $\Phi 25$) between ODU and IDU (AiO).

14.2.2 Zone Water Pump Control

Purpose:

- Water pump install at each zone to circulate the water inside each zone during buffer tank connection selected "YES" or 2 zone systems.



Content:

- AC type water pump install for this zone water pump control. When optional PCB connected, 230V output will drive this zone pump.
 - There are three pump can be connected through Optional PCB. (Zone 1 Pump, Zone 2 Pump, & Pool Pump)
 - * Zone 1 pump [P1] use to circulate zone 1 water circuit & Zone 1 mixing valve [M1] adjust to control the Zone 1 target water temperature.
 - * Zone 2 pump [P2] use to circulate zone 2 water circuit & Zone 2 mixing valve [M2] adjust to control the Zone 2 target water temperature.
 - * When Pool Function select as Zone 2 circuit, [P2] use to circulate water to heat exchanger which use to transfer heat to pool water.
 - * Pool pump [P3] circulates the pool water through the heat exchanger to get warm water.
 - Zone 1 and Zone 2 water pump start condition:
 - Zone room request ON
(eg. Zone 1 thermo ON, only zone 1 pump will turn ON)
 - Zone 1 and Zone 2 water pump stop condition:
 - Zone room request OFF
 - Pool water pump start condition:
 - Pool Zone request ON **AND**
 - Pool function is selected
 - Pool water pump stop condition
 - Pool zone: Zone room request OFF **OR**
 - Pool function is cancel
- * Zone 1 & Zone 2 water pump need to turn OFF when antifreeze deice pump stop control activate and turn ON back after the antifreeze deice pump stop control end under setting of "NO" buffer tank connection.

Zone Pump Prohibit ON control:

- Start condition:
 - Zone 1 water temperature $\geq 85^{\circ}\text{C}$ continuously for 5 minutes
 - *stop zone water pump operates if the zone water fulfilled.
- Cancel condition:
 - After 30 minutes from start condition fulfilled.
 - *zone water pump operates according to normal condition.

Zone Pump Control during Anti-Freeze

Zone pump control during Zone Anti-Freeze Control:

- When Zone Anti-Freeze Flag=1, Zone Pump Turn ON.
- When Zone Anti-Freeze Flag=0, Zone Pump Turn OFF.

Zone pump control during Indoor Anti-Freeze Control:

- Zone pump only ON/OFF if the Extension PCB connected and Buffer Tank select "NO" condition


When Indoor Anti-Freeze flag=1, Zone Pump Turn ON

When Indoor Anti-Freeze flag=0, Zone Pump Turn OFF

* Pool Water Pump will not be affected by both Indoor anti-freeze control or zone anti-freeze control.

14.2.3 Water Pump Speed Feedback Error

- Basically pump speed feedback is controlled by micon.
- When pump speed is below low limit or over high limit for a few seconds, micon detects pump error and the system is stopped.
- Error detection conditions:
 - Detect abnormal water pump speed for continuous 10 seconds.
 - Current pump speed < 300 rpm or
 - Current pump speed > 6000 rpm for 10 seconds.
- Control contents:
 - When error occurs, water pump, heating and heater are stopped for 30 seconds then restart again (Retry control).
 - When micon detects error again, the system is stopped and error code [H20] is displayed at the control panel.



14.3 Extra Pump Function (Optional)

There are three different controls for the external pump, Heat (default), DHW or NO.

Remocon setting : Extra pump = Heat (default)

This is the conventional setting for adding an external water pump when the flow rate is insufficient due to water pressure loss, etc.

Start conditions:

- 1) Outdoor Water Pump Turn ON
- 2) 3 ways valve switch at room side
- 3) External Pump control for Bivalent ON. (Alternative or SG ready mode or Smart mode)
- 4) Heat Pump OFF AND Boiler turn ON under Bivalent control
- 5) When Optional PCB Connectivity select No AND Buffer Tank Connection select Yes
- 6) Not Tank only mode AND Zone room thermo ON

When [(1) AND (2)] OR [(3) AND (4)] OR [(5) AND (6)] fulfill, turn ON extra pump.

*Output 230V to the external pump when fulfill start condition.

Cancel conditions:

- 1) Outdoor water pump turn OFF
- 2) 3 ways valve switch to tank side
- 3) Heat pump OFF and Boiler OFF under Bivalent Control
- 4) When Optional PCB Connectivity select No AND Buffer Tank Connection select Yes
- 5) Tank Only mode
- 6) Zone room thermo OFF

When [(1) OR (2)] AND (3) } OR { (4) AND [(5) AND (6)] } fulfill, turn OFF extra pump.

*Stop output 230V to external pump when either one stop condition fulfill.

Remocon setting : Extra pump = DHW

This is the setting when using DHW circulation operation.

DHW circulation start conditions

All of the following holds

- 1) Extra pump = "DHW"
- 2) DHW circulation is effective time.
- 3) Tank mode is "ON"

DHW circulation start conditions

Which of the following holds

- 1) Extra pump = "No" or "Heat"
- 2) DHW circulation isn't effective time.
- 3) Tank mode is "OFF"

DHW circulation operation

Operation is 2 type, Comfort or Efficiency

DHW circulation operation (Comfort)


Prioritize comfort over power consumption

- 1) When DHW circulation request is received, pump port is supply 230V
- 2) During this operation, 230V is always supply
- 3) When operation is "OFF", 230V is stopped

DHW circulation operation (Efficiency)

Pump operate intermittent (ON/OFF)

- 1) When DHW circulation request is received, pump port is supply 230V.
- 2) Pump operate intermittent (ON/OFF)
ON time and OFF time is decided by Remocon.
- 3) When operation is "OFF", 230V is stopped




Remocon setting : Extra pump = No

The extra pump does not work.

14.4 Water Circuit Part Safety

14.4.1 Water Circuit Part Safety Control

- 1 When water pump is ON, the system will start checking flow switch status (ON/OFF).
- 2 If the flow switch ON for 10 seconds, the system will check on the water inlet temperature for 10 seconds. If the water inlet temperature not exceeds 80°C, the water pump shall be continuously running with normal mode.
If the water inlet temperature exceeds 80°C for continuously 10 seconds, the water pump will be OFF immediately.
- 3 After water pump OFF for more than 10 minutes, it will be ON back and the indoor unit safety control checking is restarted.



14.5 Auto Restart Control

- 1 When the power supply is cut off during the operation of Air-to-Water Heatpump, the compressor will reoperate after power supply resumes.

14.6 Indication Panel

LED	Operation
Color	Green
Light ON	Operation ON
Light OFF	Operation OFF

Note:

- If Operation LED is blinking, there is an abnormality operation occurs.

14.7 Indoor Back-Up Heater Control (Excluding when Operating in Standalone)

14.7.1 Indoor Electric Heater Control

- 1 Normal Heating Mode
 - Heater On condition:
 - a. Heater switch is ON
 - b. After Heatpump thermo ON for [30] mins
 - c. After water pump operate [9] mins
 - d. Outdoor air temperature < Outdoor set temperature for heater
 - e. When water outlet temperature < Water set temperature + [-4°C]
 - f. [20] minutes since previous Backup heater Off
 - * When heatpump cannot operate due to error happens during normal operation, heater will go into force mode automatic
 - * Heater need to operate during deice operation
 - g. Current water flowrate is higher than min. flowrate
 - Heater Stop Condition:
 - a. When outdoor set temperature > outdoor set temperature + [+2°C] for continuous 15 secs OR
 - b. When water out temp > water set temperature + [-2°C] for continuous 15 secs OR
 - c. Heater switch is Off OR
 - d. Heatpump thermo-off or OFF condition
 - 2 Force Heater Mode
 - Heater On condition:
 - a. After water pump operate [9] mins
 - b. When water outlet temperature < water set temperature + [-4°C]
 - c. [20] minutes since previous Backup heater Off
 - d. Current water flowrate is higher than min. flowrate
 - Heater Stop condition
 - a. Force mode off **OR**
 - b. When water outlet temperature > water set temperature + [-2°C] for continuous 15 secs
- * Do not operate heater at the following situation
- 1 Water outlet temperature sensor, and water inlet sensor abnormal
 - 2 Flow switch abnormal
 - 3 Circulation pump stop condition

14.7.2 Room Heater Operation during Deice

Purpose:

- To protect the indoor Heat Exchanger from ice forming and prevent heat exchanger plate breakage.

Control content:

- This Heater protection control will activate only if the backup heater is enable at custom setup by remote controller. Once fulfil the start condition, room heater will turn ON together (base on max heater capacity selection) and stop together if stop condition is fulfilled.
 - * If the heater is request to turn ON OLP feedback will be detected.

Starting conditions:


- During normal deice operation 4~9
- Water outlet temperature < 7°C or
Water inlet temperature < 7°C

Heater operates when 1 ~2 fulfilled.

Stop condition:

- When normal deice end or
- Water outlet temperature > 45°C

However, room heater keeps ON if indoor electric heater control activate.




14.8 Tank Heater Control (Excluding when Operating in Standalone)

14.8.1 Internal Heater Control at Tank Mode

- Internal heater turn ON condition:
 - 1 Internal Heater select for Tank heater by remote controller
 - 2 Tank Heater select ON by user.
 - 3 Backup Heater Enable
 - 4 Tank Temperature < Tank Set Temperature
 - 5 Heat Pump Thermo OFF
 - 6 20 minutes from previous heater off.
- Room heater turn OFF condition:
 - 1 Tank Temperature > Tank Set Temperature + [0°C] for continuous 15 seconds. **OR**
 - 2 Heat Pump Thermo ON **OR**
 - 3 Mode Change or Operation OFF by remote controller **OR**

* Backup Heater Turn ON/OFF all together according to the selected heater capacity.



14.9 Base Pan Heater Control (Optional)

- To enable the base pan heater function, control panel initial setting has to be manually adjusted by activating Base Pan Heater menu.
- There are 2 optional start condition can be selected, Type A or Type B.
- Control details:

1 Type A: (Default Auto Mode)

Start conditions:

- When outdoor air temperature $\leq 3^{\circ}\text{C}$ during heating and deice operation is ON.

Control contents:

- Base pan heater is ON during deice operation and continues ON for 10 minutes after deice operation ends.

Cancel condition:

- When outdoor temperature $> 6^{\circ}\text{C}$ after deice end or
- When operation is not at heating mode or
- Base pan heater ON timer count is completed.

2 Type B: (ON Mode)

Start conditions:

- When outdoor air temperature is $\leq 5^{\circ}\text{C}$ and operates in heating mode, base pan heater is ON.

Cancel conditions:

- When outdoor air temperature is $> 7^{\circ}\text{C}$ or
- When operation is not at heating mode.

14.10 Force Heater Mode

Purpose of Force Heater Mode:

- As a backup heat source when heat pump error. Force heater Mode only control backup heater to heat up the room circuit, and turn ON back up heater or booster heater to boil up tank water base on the tank heater selection (internal or external).

Force Heater Control start condition:

- Force heater request ON by user during error OR auto turn ON by remote controller during error **AND** (Force Heater mode can be operate regardless of mode selection, remocon will send the latest mode selection force bit by bit to indoor. Indoor will judge to turn ON heater to room side if it is heat mode selected, and turn ON heater to heat tank water base on tank heater selection)
- During Error Happen (exclude the error list below)

Error List which not allow Force Heater operation

H12	Capacity Mismatch	H90	Abnormal ID/OD communication
H20	Abnormal Water Pump	H95	Abnormal Voltage Connection
H21	Abnormal Water Pressure	F30	Abnormal water outlet 2 sensor
H62	Abnormal Water Flow	F37	Abnormal Water Inlet sensor
H70	Abnormal Back-up Heater OLP	F45	Abnormal Water Outlet sensor
H74	PCB Communication Error	F50	Abnormal Water Inlet 2 sensor
H76	Indoor-Remote Controller Communication Error		
[When tank mode operate with external heater selected & tank heater select ON]			
H22	Abnormal tank 2 sensor	H91	Abnormal tank heater OLP
H72	Abnormal tank 1 sensor		

Force Heater Control Stop Condition:

- Force Heater request OFF **OR**
- Operation OFF request **OR**
- Power reset **OR**
- Error of above list happens during force heater operation.

Control contents:

- After fulfill start condition, indoor will operate the force heater operation according to below mode condition
Heat mode Only: Turn ON backup heater to achieve room heat pump target water temperature.
Heat + Tank mode: Turn ON backup heater to heat up room **OR** Turn ON Heater to Boil up tank water.
Cool mode Only: Water pump and backup heater will OFF in force heater mode.
Cool + Tank mode: Operate pump and internal Heater **OR** External heater to Boil up tank water.
Tank mode Only: Operate pump and internal Heater **OR** External heater to Boil up tank water.
* For heat mode condition, backup heater will only turn ON if the backup heater is enable regardless of Room Heater Selection.
* For tank mode condition, If internal heater selected backup heater will turn ON to boil up tank water.
If external heater selected , booster heater will turn ON to boil up tank water regardless of tank heater selection.

Room Side: (Heat Mode):

- When force heater mode start condition fulfilled, turn ON water pump and turn ON backup heater follow below control.
- Operate the 3 ways valve at room side only and turn ON 2 ways valve as heat mode operation.
- Turn ON the zone pump and mixing valve if system select 2 zone system or Buffer tank connect YES, control according to normal zone pump and mixing valve control.
- When Force heater mode stop condition fulfilled, turn OFF heater as below condition and turn OFF water pump after pump delay time.

Backup Heater On Condition:

- When Force Heater Control start condition fulfill **AND**
- After water pump operate 2 minutes **AND**
- When water outlet temperature < water set temperature + [-4°C] **AND**
- 20 minutes since previous Backup heater Off **AND**
- Backup Heater Enable

Backup Heater Stop condition:

- Force mode off **OR**
- Operation off **OR**
- When water outlet temperature > water set temperature + [-2°C] for continuous 15 secs **OR**
* ON/OFF follow normal heater sequence.

Tank side (Tank mode):

- When tank mode select and force heater bit received, turn ON backup heater (INTERNAL) or Booster Heater (External) depend on the tank heater selection.
- If tank heater selection is INTERNAL, follow normal thermo judgement to switch 3 ways valve to tank side and room side.
- If tank heater selection is EXTERNAL, only turn ON booster heater according to tank thermo.

Tank Heater selection is INTERNAL:

Backup Heater ON Condition:

- After water pump operate 2 mins **AND**
- When tank temperature < Tank set temperature - [Remocon Set Tank Re-heat Temp] **AND**
- 20 minutes since previous Backup heater OFF **AND**
- Backup Heater Enable

Backup Heater OFF condition:

- Force mode off **OR**
- When tank temperature > Tank set temperature for continuous 15 secs **OR**
- Tank Operation OFF

Tank Heater selection is EXTERNAL:

Booster Heater ON condition:

- Force Heater mode ON **AND**
- Tank temperature < tank set temperature + [Remocon Set Tank Re-heat Temp] - 1°C, **AND**
- 20 minutes since previous heater off.

Booster Heater OFF condition:

- Tank temperature > tank set temperature for continuous 15 secs.
- Force mode OFF
- Tank Mode Operation OFF
(During tank interval or tank mode condition, water pump and 3 ways valve will OFF)

14.11 Powerful Operation

Powerful mode is use to increase the capacity of heat pump to achieve higher target temperature. Powerful mode is applicable when heat mode is operating.

Remote control setting:

On quick menu of remote control, there is 4 options of powerful mode can be select.

- OFF : Cancel powerful mode
- 30 minutes : Set powerful for 30 minutes
- 60 minutes : Set powerful for 60 minutes
- 90 minutes : Set powerful for 90 minutes

Control contents:

During the time set by remote control, powerful will activate according to 2 shift up controls. However, this function is applicable only for heating. Remote control will transmit the signal to indoor unit once this function is select then transmit OFF signal to indoor when the timer is complete. Indoor will transmit signal to outdoor for frequency control.

Indoor setting temperature shift

- If system is standard system (Optional PCB is not connected)
 - Target water temperature will shift up to Wlo or Whi whichever higher.
- If system is extension system (Optional PCB is connected)
 - Target water Zone 1 and Zone 2 temperature will shift up to Wlo or Whi whichever higher.

* If "Direct Type" temperature control is select, this powerful shift up setting is not effective.

- **Start condition**
 - Powerful function is select by remote control.
- **End Condition**
 - OFF/ON button is pressed.
 - Powerful function is OFF by remote control.

14.12 Quiet Operation

Quiet mode is use to reduce the noise of outdoor unit by reducing the frequency or fan speed.

Quiet level

There are 3 level (Level 1, Level 2, Level 3) to set by quick menu function on remote control.

Control content

Once the quiet function is select, the remote control will transmit the signal to indoor and outdoor unit.

Quiet priority

Set whether to prioritize "Sound" or "Capacity"

In case of "Sound" is set for "Quiet priority" in the function setup of the remote control

Start condition

- Quiet mode is set on remote control.
- Quiet mode is request ON by weekly timer.

Stop condition

- OFF/ON button is pressed.
- Quiet mode is OFF by remote control.
- Quiet mode is request OFF by weekly timer.

In case of “Capacity” is set for “Quiet priority” in the function setup of the remote control

Start condition

- 1) Quiet mode is set on remote control.
- 2) Quiet mode is request ON by weekly timer.
- 3) During heating : Water outlet temperature > Target Water Temperature - 3°C
- 4) During Cooling : Water outlet temperature < Target Water Temperature + 3°C
- 5) During operation mode when 3 way valve is at tank direction : Tank temperature > Tank set Temperature - 3°C

When condition {{(1) or (2)}} and {{(3) or (4) or (5)}} is fulfilled, after the quiet mode start by user or timer.

Stop condition

- 1) Quiet mode is OFF by remote control.
- 2) OFF/ON button is pressed.
- 3) Quiet mode is request OFF by weekly timer.
- 4) During heating : Water outlet temperature \leq Target Water Temperature - 5°C for continues 30 minutes
- 5) During Cooling : Water outlet temperature \geq Target Water Temperature + 5°C for continues 30 minutes
- 6) During operation mode when 3 way valve is at tank direction : Tank temperature \leq Tank set temperature - 5°C for continues 30 minutes

When any of above mentioned condition is achieved, this control is cancelled.

14.13 Sterilization Mode

- Purpose:
 - To sterilize water tank by setting the required boiling temperature.
- Remote control setting
 - Days for sterilization function to start can be select.
 - Time of selected day to start sterilization function.
 - Boiling temperature (Internal heater is 55°C ~ 65°C)
 - Maximum operation time is 5 minutes to 1 hour.
- Start condition
 - Tank connection set to “YES” by remote control
 - Sterilization function selects “YES”.
 - Sterilization signal received from remote controller by timer.
 - Tank mode request ON.
- Stop condition
 - When boiling timer is completed. Boiling timer (Remote control set maximum operation time) start counting once tank achieve boiling set temperature **OR**
 - After 8 hours of operation since sterilization start.
 - Tank mode request OFF.
- Control content:
 - During sterilization function activation time, target tank set temperature will internally change to boiling set temperature.
 - During sterilization activates, heat pump and heater (external or internal) will operate as normal tank mode to achieve the boiling set temperature.
 - Sterilization operation will end when stop condition is fulfill.
 - After sterilization is complete, tank set temperature will resume to normal operation.

* Tank temperature may not achieve boiling set temperature if tank heater is select OFF **OR** external compressor switch.

14.14 DHW Circulation Pipe Sterilization Operation

Purpose:

This control is designed to prevent legionella for DHW circulation pipe.

DHW circulation pipe sterilization mode start conditions

All of the following holds

- 1) Remocon setting : Extra pump = DHW
- 2) Tank sterilization operation is finished.
- 3) Tank sterilization is completed within 490 minutes since sterilization function start

DHW circulation pipe sterilization mode stop conditions

Which of the following holds

- 1) After 490 minutes of operation since DHW circulation pipe sterilization start
- 2) Circulation pump operated 30 minutes
- 3) Tank mode Request OFF
- 4) Remocon setting : Extra pump = Heat or NO

DHW circulation pipe sterilization mode control contents


It works in the following order.

- 1) Tank sterilization mode is ON
- 2) Tank boiling start Target temp. is RC setting
- 3) Tank sterilization mode finish or stop.
- 4) DHW circulation pump operate during 30 minutes
- 5) Back to normal operation

14.15 Outdoor Ambient Thermo OFF Control

Purpose:

Stop provides heating to room side during high outdoor ambient condition.



Control content:

- Heating outdoor ambient thermo OFF control only applicable when heat pump operate in heat mode. (This control will not activate when running in tank side)
- Heat pump and water pump will turn OFF when outdoor ambient is higher than outdoor thermo OFF set temperature.
- Heat pump will thermo ON back when outdoor ambient < Outdoor thermo ON set temperature and RC delay time has passed after Heating thermo-ON temperature is reached.

14.16 Alternative Outdoor Ambient Sensor Control

Purpose of the Alternative Outdoor Ambient Sensor:

- It is some possibility that the air to water heat pump unit will install at a location where the original ambient sensor is expose to direct sunlight. Therefore, another optional ambient sensor can be connect to indoor PCB and locate at new and better reading location to improve the heat pump performance.

Control Detail:

- Remocon can select either the extra outdoor ambient sensor is connected or not. (YES/NO)
- The alternative outdoor ambient sensor will connect to indoor unit main PCB terminal.

- when alternative sensor select NO
 - Original Outdoor temperature sensor will use for Indoor & Outdoor heat pump operation reference sensor.
 - Data communication direction : OUTDOOR send outdoor temperature reading to INDOOR.
 - Error judge : OUTDOOR will judge the original outdoor sensor error (F36 display if error detect). No judge error on alternative outdoor sensor
- when alternative sensor select YES
 - Alternative Outdoor temperature sensor will use for Indoor & Outdoor heat pump operation reference sensor.
 - Data communication direction : INDOOR send outdoor temperature reading to OUTDOOR.
 - Error judge : INDOOR will judge the Extra outdoor sensor error only after operation ON request received from remocon.
(F36 display if error detect). No judge error on original outdoor sensor.

14.17 Force DHW mode

Purpose:

When user want to use hot water now, user can press this force DWH mode under the quick menu to operate tank only mode to boil up the tank temperature.

Remocon setting:

Force DHW function can be activate under quick menu.

Control Content:

- when press the Force DHW function during operation OFF condition:
 - When receive this Force DHW bit from remocon, indoor will run tank only mode regardless of the mode selection.
 - After tank temperature achieve tank thermo off temperature, turn OFF force DHW bit and return to operation OFF with previous mode selection.
 - When press the Force DHW function during operation ON condition:
 - When receive this Force DHW bit from remocon, indoor will memories the running mode and run tank only mode regardless of the mode selection.
 - After tank temperature achieve tank thermo off temperature, turn OFF force DHW bit and return to previous memories running mode.
- * when operation OFF or mode change request from remocon during force DHW mode operation, End force DHW mode and follow the new request operation.
- * Once receive force DHW mode from remocon, indoor direct start tank mode and consider tank thermo ON. Thermo OFF only when achieve tank thermo OFF depend on the Tank System Setting.

14.18 SMART DHW mode

Panasonic All In One model provide the option to choose STANDARD DHW Mode or SMART DHW Mode for Tank Heat Up according to requirement. SMART DHW mode comparatively consume lower tank heat up power but longer re-heat time than STANDARD DHW Mode.

SMART DHW control

- During SMART DHW start time 20:00 (Default Setting) to SMART DHW stop time 05:00 (Default setting)
Heat pump re-heat the tank water only when tank temperature drop below 20°C (Default setting)
- Time between 05:00 to 20:00
Heat pump reheat the tank water when tank temperature as below condition

Condition 1: Tank Heater ON

Reheat when tank temperature below tank set temperature + R/C (Tank re-heat Temperature) - 3°C

Condition 2: Tank Heater OFF

Reheat when tank temperature below Tank set temperature or 51°C (Whichever lower) + R/C (Tank re-heat Temperature) -3°C

* SMART DHW start time, stop time and SMART ON Temperature can change in CUSTOM menu.

14.19 Efficiency Tank Mode Operation

Tank mode operation follows NEW control as below when conditions below are fulfilled:

Start conditions

- 1) All-in-One model selection : YES *AND*
- 2) DHW capacity = Variable *AND*
- 3) Heating control = Efficiency

Control Contents:

3-way valve direction change to tank side. When Thermo off, 3WV switch to room side.

Check TS1 (Tank top sensor) - TS2 (Tank centre sensor) always

When $[TS1 - TS2] < 2.5^{\circ}\text{C}$ for 40 hours, use TS2 as thermo ON and OFF judgement.

Cancel conditions:

Tank mode operation follows CURRENT (default -8°C)

control when ANY of the following is fulfilled:

- 1) All-in-One model selection : NO *OR*
- 2) DHW capacity = Standard *OR*
- 3) Heating control = Comfort

Tank Thermo ON conditions:

- 1) Internal Tank Heater Select *AND* Tank Heater ON:
Tank Temp $<$ Tank Set Temp + R/C (Tank reheat Temp)
- 2a) Tank Heater Select OFF *OR* External Heater Select *AND* $3^{\circ}\text{C} < [TS1 - TS2] < 12^{\circ}\text{C}$:
Tank Temp $< 30^{\circ}\text{C}$
- 2b) Tank Heater Select OFF *OR* External Heater Select *AND* $[TS1 - TS2] < 3^{\circ}\text{C}$:
Tank Temp $<$ Tank Water Set Temp. + R/C (Tank reheat Temp)
- 2c) Tank Heater Select OFF *OR* External Heater Select *AND* $[TS1 - TS2] > 12^{\circ}\text{C}$:
Tank Temp $< 36^{\circ}\text{C}$

Tank Thermo OFF conditions:


- 1) Internal Tank Heater Select *AND* Tank Heater ON:
 - a) Tank temperature $>$ Tank set temperature + 0°C for continuous 20 seconds after heat pump OFF due to water thermo OFF *OR*
 - b) Tank temperature $>$ Tank set temperature + 1°C for continuous 20 seconds *OR*
 - c) Water outlet temperature $> 75^{\circ}\text{C}$
- 2) Tank Heater Select OFF *OR* External Heater Select:
 - a) Tank temperature $>$ Tank Water set temperature + 0°C for continuous 20 seconds after heat pump OFF due to water thermo OFF *OR*
 - b) Tank temperature $>$ Tank set temperature + 1°C for continuous 20 seconds

14.20 Anti Freeze Control

- Anti freeze protection control menu can be set YES or NO by control panel.
- Heatpump system there are 2 types of anti freeze control:

1. Models with Back up heater (Excluding in Standalone and connection control module):

Outdoor air temp zone is defined as below :




- Water pump circulation anti freeze control
 - Water pump turns ON when **ALL** below conditions are fulfilled:
 - Heat pump OFF (Stand by) OR error occurs.
 - Water flowing flag is ON.
 - Water flow sensor is not abnormal.
 - Outdoor air temp zone is any of Zones 1 to 4 OR outdoor ambient temp. sensor is abnormal.
 - Water inlet/outlet temp. < [A°C]
 - After 5 minutes from previous water pump OFF.
 - Water pump turns OFF when **ANY** below conditions is fulfilled:
 - Outdoor air temp zone is Free Zone
 - Outdoor air temp zone is any of Zones 1 to 4.
 - After water pump ON for 4 minutes, and water inlet temp. ≥ [B°C]
 - Else, shift to back up heater anti freeze control.
 - However, if flow sensor is abnormal (H62), then water pump circulation anti freeze control will not activate.
- Back up heater anti freeze control
 - Back up heater turns ON when **ALL** below conditions are fulfilled:
 - Water inlet/outlet temp. < [B°C]
 - Water pump circulation anti freeze control activated and water pump ON for 4 minutes.
 - Back up heater turns OFF when **ANY** below conditions is fulfilled:
 - Outdoor air temp zone is Free Zone
 - Outdoor air temp zone is any of Zones 1 to 4.
 - Water inlet/outlet temp. ≥ [C°C]
 - However, if back up heater is abnormal (H70), then back up heater anti freeze control will not activate.

	A°C	B°C	C°C
Zone 1	6°C	8°C	13°C
Zone 2	10°C	15°C	20°C
Zone 3	16°C	21°C	28°C
Zone 4	25°C	33°C	33°C

Table : Threshold condition for Water temp when Models with Back up heater

2. Models without Back up heater (Standalone and connection control module):

Outdoor air temp zone is defined as below :



- Water pump circulation anti freeze control
 - Water pump turns ON when **ALL** below conditions are fulfilled:
 - Heat pump OFF (Stand by) OR error occurs.
 - Water flowing flag is ON.
 - Water flow sensor is not abnormal.
 - Outdoor air temp zone is any of Zones 1 to 4 OR outdoor ambient temp. sensor is abnormal.
 - Water inlet 2 / outlet 2 temp. < [A°C]
 - After 5 minutes from previous water pump OFF.
 - Water pump turns OFF when **ANY** below conditions is fulfilled:
 - Outdoor air temp zone is Free Zone
 - Outdoor air temp zone is any of Zones 1 to 4.
 - After water pump ON for 4 minutes, and water inlet temp. ≥ [B°C]
 - Else, shift to Heat pump unit operation anti freeze control.
 - However, if flow sensor is abnormal (H62), then water pump circulation anti freeze control will not activate.
- Heat pump unit operation anti freeze control
 - Heat pump unit operation turns ON when **ALL** below conditions are fulfilled:
 - Water pump circulation anti freeze control activated and water pump ON for 4 minutes.
 - Heat pump unit operation turns OFF when **ANY** below conditions is fulfilled:
 - Water inlet / Water inlet 2 temp. > [C°C] for 3 minutes.


	A°C	B°C	C°C
Zone 1	20°C	19°C	24°C
Zone 2	20°C	19°C	24°C
Zone 3	20°C	23°C	28°C
Zone 4	20°C	27°C	33°C

Table : Threshold condition for Water temp when Models without Back up heater

14.20.1 Zone Anti-Freeze Control

- If buffer tank selection is "NO" and Anti- Freeze function select "NO" from remote control, this control cannot activate.

Outdoor air temp zone is defined as below :



Start condition:

- After [5] min from previous Zone pump off. **AND**
- Outdoor air temp zone is any of Zones 1 to 4 **OR** outdoor ambient temp. sensor is abnormal. **AND**
- Zone water temperature < [A°C] **OR** Zone Sensor Short or Open

Cancel condition:

- After water Zone pump ON [4] min **AND**
 - Outdoor air temp zone is Free Zone **OR**
 - Outdoor air temp zone is any of Zones 1 to 4.
Zone water temperature sensor ≥ [B°C]
- *However, Zone water temperature sensor is Open or Short, cancel zone water temperature condition is ignored.

	A°C	B°C
Zone 1	6°C	8°C
Zone 2	10°C	15°C
Zone 3	16°C	21°C
Zone 4	25°C	33°C

Table : Threshold condition for Water temp when Models with Back up heater

	A°C	B°C
Zone 1	20°C	19°C
Zone 2	20°C	19°C
Zone 3	20°C	23°C
Zone 4	20°C	27°C

Table : Threshold condition for Water temp when Models without Back up heater


14.21 Solar Operation (Optional)

14.21.1 Solar Operation:

Solar function:

- This function allow user to control the solar pump to operate depend on the solar sensor reading compare to the tank installed. Solar pump will circulate the hot water energy store at solar panel to heat up the DHW Tank or Buffer Tank.

Solar Connection Diagram:



- Solar function can only enable when the Optional PCB is connected.
- Few part as below need to install to control the solar operation:
 - Solar Panel
 - Solar Pump
 - Solar Panel Sensor
 - Tank Sensor (Buffer tank sensor OR DHW Tank sensor depend on the connection direction)
 - * During Solar Connection to the system, installer need to alert on the high water temperature may flow to the zone circuit or DHW piping circuit. Therefore pipe which withstand higher water temperature need to be installed.
- Solar remote control setting
 - 1 Solar Setting can only be set when the optional PCB connection is select "YES"
 - 2 By remote controller, Setting as below list can be set for solar function operation (Installer Menu)
 - Solar Function ("YES" or "NO")
 - Tank Connection Direction ("DHW TANK" or "BUFFER TANK")
 - Delta T turns ON: Difference temperature setting between solar panel sensor and Tank to turn on solar pump. (Range :5 ~ 15°C)
 - Delta T turns OFF: Difference temperature setting between solar panel thermistor and Tank to turn off solar pump. (Range :2 ~ 10°C)
 - Outdoor temp for Anti-Freeze : Outdoor temp to start Anti-Freeze control for solar circuit. (Range : -20 ~ 10°C)
 - Tank Temperature HI Limit Set (Range : 70 ~ 90°C)

14.21.2 Solar Operation Control

- Solar function can only be activate if the solar function selection "YES" from remote control. To achieve hot water from solar panel, indoor need to control the solar pump and circulate hot water from solar panel.

Under normal case:

- Solar pump start condition:
 - Solar panel temperature > Delta T turn on setting temp (R/C) + Tank temperature (depend on selection, DHW or Buffer) **AND**
 - Tank temperature (DHW or Buffer) < Solar HI Limit Temp (R/C) **AND**
 - Operation ON with heat mode (apply to solar connect to "Buffer Tank" case)
- * Condition c) ignore if the solar system is connect to DHW tank (control active under operation OFF time for Tank connection case)
- Solar pump stop condition:
 - Solar panel temperature < Delta T turn OFF setting temp (R/C) + Tank temperature (depend on selection, DHW or Buffer) **OR**
 - Tank hot water temp >= Solar HI Limit Temp (R/C) + [2]°C

Under solar Anti-freeze protection control:

- Solar pump start condition:
 - Outdoor temp < Outdoor temp setting for Anti-Freeze (R/C)
- Solar pump stop condition:
 - Outdoor temp > Outdoor temp setting for Anti-Freeze + [2]°C

**However, During Cool mode this function cannot activate if Tank selection is "Buffer Tank".

**Solar pump can operate even if Heat pump is under error stop.

- Solar operation during error:
 - During Tank sensor (DHW or Buffer depend on selection) abnormal, Solar operation will not able to function.
 - During Solar Panel sensor detect OPEN (not include SHORT), Solar operation will not able to function too.

14.22 Boiler Bivalent Control

- Boiler is an additional or alternative heat source to heat up the room when necessary.
- Purpose of this control is to turn ON and turn OFF the Boiler output signal when boiler heating capacity needed in the system.
- Boiler is possible to connect to DHW Tank and Buffer Tank depends on the installer.
- Boiler operation parameter need to be set on Boiler itself, indoor do not control the boiler operation direction and operation.
- There are Alternative mode, Parallel mode, & Advance Parallel mode available to select by installer to fit to the total system.

Bivalent control selection by remote controller

Remote control setting value:

1 Outdoor Ambient Set = (Range: -15°C ~ 15°C)

- **Alternative Mode**
 - Only one heat source operates at one time, either heat pump or boiler depends on condition.

Control detail:

During Operation ON at Heat mode or Tank mode or Heat + Tank Mode

- Boiler signal turn ON and heat pump and water pump turn OFF when:
 - Outdoor ambient < Outdoor Ambient Set **AND**
 - Boiler prohibit flag = 0

** However water pump can operate when Anti-freeze control condition fulfilled.

- Boiler signal turn OFF and heat pump and water pump turn ON when:
 - Outdoor ambient > Outdoor Ambient Set + [2]°C **OR**
 - Boiler prohibit flag = 1

- **Parallel Mode**

- Parallel mode allows heat pump and boiler ON at the same time. Boiler operates as an additional heating capacity when low heat pump capacity at low ambient condition.

Control detail:

During operation ON at Heat mode or Tank mode or Heat + Tank mode

- Boiler signal turns ON when:
 - Outdoor ambient < Outdoor Ambient Set **AND**
 - Boiler prohibit flag = 0
- Boiler signal turns OFF when:
 - Outdoor ambient > Outdoor Ambient Set + [2°C] **OR**
 - Boiler prohibit flag = 1

- **Advance Parallel Mode**

- Advance parallel mode allow heat pump to operate and turn ON boiler only when ambient and temperature condition is fulfilled.

Remote control setting value:

- 1 Outdoor Ambient Set = (Range : -15°C ~ 15°C)
- 2 Selection of boiler connection direction. (Heat only, DHW only, Heat & DHW)
- 3 Setting data under Heat Direction
 - Start Temperature | START_TEMP |
 - Start Delay Timer | START_TIMER |
 - Stop Temperature | STOP_TEMP |
 - Stop Delay Timer | STOP_TIMER |
- 4 Setting data under DHW Direction
 - Delay Timer | DELAY_TIMER |

Control detail:

During operation ON at Heat Mode

- Boiler signal turns ON when
 - Outdoor ambient < Outdoor Ambient Set **AND**
 - Buffer tank temperature < Target Buffer Tank Temperature + [START_TEMP] for [START_TIMER] **AND**
 - Heat pump operate at room side **AND**
 - Connection of Boiler to Heating Select "YES" From installer menu **AND**
 - Buffer Tank connection select "YES" **AND**
 - Boiler prohibit flag = 0
- Boiler signal turns OFF when
 - Outdoor ambient > Outdoor Ambient Set + [-2°C] **OR**
 - Buffer Tank temperature > Target Buffer Tank temperature + [STOP_TEMP] for [STOP_TIMER] **OR**
 - Heat pump not at room side. **OR**
 - Boiler prohibit flag = 1

During operation ON at Tank Mode

- Boiler signal turns ON when
 - Outdoor ambient < Outdoor Ambient Set **AND**
 - Heat pump operate at tank side for continuous | DELAY_TIMER | **AND**
 - Connection of Boiler to DWH Tank select "YES" from installer menu. **AND**
 - Boiler prohibit flag = 0
- Boiler signal turns OFF when
 - Outdoor ambient > Outdoor Ambient Set + [2°C] **OR**
 - Heat pump not operates at tank side. **OR**
 - Boiler prohibit flag = 1

Boiler prohibit flag control

Purpose:

- For product safety. Boiler signal is OFF when water temperature is too high.

Start condition:

- Water outlet ≥ 85°C continues for 5 minutes.
- Water inlet ≥ 85°C continues for 5 minutes.
- Zone1 water temp ≥ 75°C continues for 5 minutes.
- Zone2 water temp ≥ 75°C continues for 5 minutes.

Contents:

- After start condition fulfilled, set boiler prohibit flag = 1

Cancel condition:

- After 30 minutes from start condition fulfilled.

Contents:

- Set boiler prohibit flag = 0

14.23 External Room Thermostat Control (Optional)

Purpose:


- 1 Better room temperature control to fulfill different temperature request by external room thermostat.
Recommended external room thermostat:

Maker	Characteristic
Siemen (REV200)	Touch panel
Siemen (RAA20)	Analog

Connection of external room thermostat:


Wire Connection and thermo characteristic of Siemen REV200:

Setting	L/L1 (H)	Heat Thermo	L/L2 (C)	Cool Thermo
Set Temp < Actual Temp	Open Circuit	OFF	Short Circuit	ON
Set Temp > Actual Temp	Short Circuit	ON	Open Circuit	OFF



Wire Connection and thermo characteristic of Siemen RAA20:

Setting	L/Y1 (H)	Heat Thermo	L/Y2 (C)	Cool Thermo
Set Temp < Actual Temp	Open Circuit	OFF	Short Circuit	ON
Set Temp > Actual Temp	Short Circuit	ON	Open Circuit	OFF



Control Content:

- External room thermostat control activate only when remote thermostat connection select YES by Indoor control panel.
- When indoor running heat mode, refer thermo On/Off from heating line feedback. And when indoor running cool mode, refer thermo On/Off from cooling line feedback.
- Heat pump Off immediately when receive thermo off feedback.


14.24 Three Ways Valve Control

Purpose:

- 3 ways valve is used to change flow direction of hot water from heat pump between heating side and tank side.

Control contents:

- 1 3 ways valve switch Off:
 - o During 3 ways valve switch Off time, the hot water will provide heat capacity to heating side.
- 2 3 ways valve switch On:
 - o During 3 ways valve switch On time, the hot water will provide heat capacity to tank side.
- 3 Stop condition:
 - o During stop mode, 3 ways valve will be in switch off position.



* During pump down and force mode, fix 3 ways valve in close condition.

* Recommended Parts : SFA 21/18 (Siemens)


14.25 Two Ways Valve Control

Functionality of 2 ways valve:

- Use to allow hot water to floor heating panel or block cold water to floor heating panel.

Control contents:

- 1 When indoor running in heat mode, OPEN the 2 ways valve.
- 2 When indoor running in cool mode, CLOSE the 2 ways valve.
- 3 Stop condition:
 - a. During stop mode, fix 2 ways valve in close condition.



* During pump down mode, fix 2 ways valve in close condition.

* During force mode, open 2 ways valve.

* Recommended Parts : SFA 21/18 (Siemens)

14.26 Anti-Stick Mode Operation

This mode is a control to prevent the water circuit actuator from locking up if not used for an extended period of time.

Start conditions

- 1) A.M 3:00 o'clock every Monday.
- 2) Anti-stick mode = Enable. (Anti-stick mode is selected in custom menu)

Control Contents:

It works in the following order.

- 1) If any mode operated, all operation is stopped.
- 2) Anti-stick mode operates
- 3) If Anti-stick mode finished, back to the last operation.


Cancel conditions:

Which of the following holds

- 1) Anti-stick mode is finished.
- 2) When the customer manually starts any mode operation. (include weekly timer, sterilization mode)


Anti-stick mode

If zone 2 or pool or solar are not connected, they are skipped



14.27 External OFF/ON Control


- Communication circuit between indoor unit and external controller is as per below.



- Maximum length of communication cable is 50 meter.
- Control content:

External Control Switch	Control Panel OFF/ON	Control Panel Power LED	System Status
ON	ON	ON	ON
ON	OFF	OFF	OFF
OFF	ON	ON	OFF
OFF	OFF	OFF	OFF

Remocon Screen Display and Control Detail:



When External SW connection select "YES" from remocon installer menu:

- Heating or Cooling system will operate normally if the External Switch signal is ON.
- Once the External Switch turn OFF, System Turn OFF (Heat pump, water pump, heater etc...)
- Remocon LED remain ON or OFF according to the current operation request.
- Pop up menu at remocon main screen as above screen to inform customer system stop by External Switch.
- It is possible to press cancel and return to main screen to do change of operation setting while waiting the External Switch turn ON back.
- Remocon LED will always follow the latest changes from remocon.
- If no action on remocon for continuous 5 minutes, the pop up screen will show again on the screen.
- But once the External Switch Turn ON back, pop up screen will disappear and system can operate normally according to the latest operation setting and request.

14.28 External Compressor Switch (Optional PCB)

External compressor switch port can have two purpose of control as below:

- Heat source ON/OFF function (Remocon select "Heat source")
- Heater ON/OFF function (Remocon select "Heater")

- Heat source ON/OFF function

Purpose:

- Heat pump ON/OFF function is use to turn OFF the high power consumption device (Heat pump, & Heater) when there is energy or electric current limitation. Other optional function still can be operate under heat pump and heater OFF condition.

Control Detail:

- This External Compressor Switch is possible to connect to Optional PCB only.
- Once the remocon select External Compressor Switch connection "YES", & select "Heat source" This heat pump ON/OFF function will activate
- The ON/OFF signal of this External Compressor Switch is same as External Switch.
- When the External Compressor Switch is ON:
 - Heat pump system operate normally
- When the External Compressor Switch is OFF:
 - Heat pump, Water pump & Heater (Booster heater & Backup Heater) need to turn OFF
 - Solar, Boiler and zone control can be operate follow normal control condition.
 - * pump delay OFF also included in this control

(There is NO pop up screen like External Switch when this External Compressor Switch is OFF.)

- Heater ON/OFF function

Purpose:

- Heater ON/OFF function is use to turn OFF the heater (backup heater & booster heater) when there is energy or electric current limitation. Heat pump and other optional function still can operate.

Control detail:

- This External Compressor Switch is possible to connect to Optional PCB only.
- Once the remocon select External Compressor Switch connection "YES", & select "Heater" This heater ON/OFF function will activate
- When the External Compressor Switch is ON:
 - Heat pump and heater operate normally
- When the External Compressor Switch is OFF:
 - Backup heater and booster heater cannot operate even heater request is ON.
 - Heat pump and option function (Solar, Boiler and zone control) can be operate follow normal control condition.

(There is NO pop up screen like External Switch when this External Compressor Switch is OFF.)

14.29 Heat/Cool Switch (Optional PCB)

Purpose:

- User can switch the running mode from heat to cool or cool to heat through external installed Heat/Cool switch. This kind of heat / cool switch may built in inside the field supply room remocon as well.

Control contents:

- Heat/Cool Switch can only be set when Cool Function is "enable" at custom menu setting, & Extension PCB select "YES" & Zone 1 not set "Pool" condition.
- This heat/cool switch control will be activate only when installer set the Heat/Cool Switch "USE" through remocon.
- Once the Heat/Cool Switch Set "USE", remocon will check indoor send Signal to judge the option of mode select.
 - When Heat/Cool Switch Contact Open : Remocon only can select Heat Mode, or Heat + Tank Mode, or Tank Mode
 - When Heat/Cool Switch Contact Close : Remocon only can select Cool Mode, or Cool + Tank Mode, or Tank Mode


- Operation ON/OFF will depend on remote control request.
- When Heat Mode is running with Contact Open, user change this setting to contact close, indoor will send this signal to remote control judge and change mode to cool and send back to indoor. And it is same as from cool mode change to heat mode.
 - * This switch has higher priority, remote control follows indoor send signal when control is activated.
 - * There is no effect to the operation when the mode running is only Tank Mode.

(Weekly Timer are ignored and cannot be set during Heat / Cool Switch is "Enable" Condition.)

14.30 SG Ready Control (Optional PCB)

Purpose:

- To set ON/OFF of heat pump and target temperature by digital input of third party device if necessary in field.



Remote control setting

For this function, following items need to be set on R/C (installer menu) –

- SG control = YES or NO
- Capacity up setting 1
 - Heating capacity [50 ~ 150 %]
 - DHW capacity [50 ~ 150 %]
 - Cooling capacity [-15 ~ 0 °C]
- Capacity up setting 2
 - Heating capacity [50 ~ 150 %]
 - DHW capacity [50 ~ 150 %]
 - Cooling capacity [-15 ~ 0 °C]
- HPU stop consumption [0.5 ~ 10.0 kW]
- Power consumption setting 1
 - Heating Power consumption [0.5 ~ 10.0 kW]
 - DHW Power consumption [0.5 ~ 10.0 kW]
 - Cooling Power consumption [0.5 ~ 10.0 kW]
- Power consumption setting 2
 - Heating Power consumption [0.5 ~ 10.0 kW]
 - DHW Power consumption [0.5 ~ 10.0 kW]
 - Cooling Power consumption [0.5 ~ 10.0 kW]

Control contents:

If SG control on remote control = "Yes", then following control only activate by digital input.

- **While Digital input is "00" (Normal operation)**
 - Normal operation. Once detect '00' system will operate back to normal condition.
(All the target set temperature for heating side and DHW side will return back to previous set temperature when digital signal change from "10" or "11" back to "00".)
- **While digital input is detected "01" (HP stop)**
 - Heat pump & room heater & tank heater cannot operate.
(Solar control and Boiler back up and 2 Zone control can activate.)

- **While digital input is detected " 10 " (Capacity 1)**
 - Target temperature for heating and DHW Tank is changed according to the percentage set by Remote control setting. However, which setting temperature is change depend on system setting.
 - Target temperature of cooling is change according to the adjustment value set by remocon setting.
- **While digital input is detected " 11 " (Capacity 2)**
 - Target temperature for heating and DHW Tank is changed according to the percentage set by Remote control setting. However, which setting temperature is change depend on system setting.
 - Target temperature of cooling is change according to the adjustment value set by remocon setting.
- **While digital input is detected " 10 " (Capacity 1)**
 - Setting temperature for heating and Tank is changed.
However, which setting temperature is change depend on system setting.

If Buffer selection is "YES"

Room side

New Target Buffer tank temperature = Current Target Buffer Tank Temperature * Remote Control setting (" capacity 1) %

* Max Min regulation is follow Target Buffer tank temperature control specification

** No change of Target zone water temperature, only set higher buffer tank temperature.

DHW Tank side

New Tank Set Temperature = Tank Set Temperature * Remote Control setting for DHW ("Capacity 1) % *
(Max regulation depend on the tank max setting limit)

If Buffer selection is "NO"

Room side

New Target Zone Water Temperature = Current Target Zone Water Temperature * Remote Control Setting (*Capacity 1) %

(Zone 1 and Zone 2 will change according to its own target zone water temperature.)

(Max regulation depend on the temperature control type select)

DHW Tank side

New Tank Set Temperature = Tank Set Temperature * Remote Control setting for DHW ("Capacity 1) %
* (Max regulation depends on the tank max setting limit)

Setting temperature for cooling is changed

New Target water temperature = target water temperature + R/C setting for cool (*Capacity 1)

* (Min/max regulation of cooling water set apply)

- **While digital input is detected " 11 " (Capacity 2)**

- Setting temperature for heating and Tank is changed.
However, which setting temperature is change depend on system setting.

If Buffer selection is "YES"

Room side

New Target Buffer tank temperature = Current Target Buffer Tank Temperature * Remote Control setting (" capacity 2) %

* Max Min regulation is follow Target Buffer tank temperature control specification

** No change of Target zone water temperature, only set higher buffer tank temperature.

DHW Tank side

New Tank Set Temperature = Tank Set Temperature * Remote Control setting for DHW ("Capacity 2) %
* (Max regulation depends on the tank max setting limit)

If Buffer selection is "NO"

Room side

New Target Zone Water Temperature = Current Target Zone Water Temperature * Remote Control Setting (*Capacity 2) %

(Zone 1 and Zone 2 will change according to it's own target zone water temperature.)

(Max regulation depend on the temperature control type select)

DHW Tank side

New Tank Set Temperature = Tank Set Temperature * Remote Control setting for DHW ("Capacity 2) %

* (Max regulation depends on the tank max setting limit)

** This function is not applicable for Cooling mode.

Setting temperature for cooling is changed

New Target water temperature = target water temperature + R/C setting for cool (*Capacity 2)

* (Min/max regulation of cooling water set apply)

HPU stop consumption

Operation will stop when the power consumption of the entire system exceeds (HPU stop consumption kW).

- **While digital input is detected " 10 " (Power consumption 1)**

Room side

Operate with the target of reducing power consumption to (Heating Power consumption 1) or less.

DHW Tank side

Operate with the target of reducing power consumption to (DHW Power consumption 1) or less.

Cool mode

Operate with the target of reducing power consumption to (Cooling Power consumption 1) or less.

- **While digital input is detected " 11 " (Power consumption 2)**

Room side

Operate with the target of reducing power consumption to (Heating Power consumption 2) or less.

DHW Tank side

Operate with the target of reducing power consumption to (DHW Power consumption 2) or less.

Cool mode

Operate with the target of reducing power consumption to (Cooling Power consumption 2) or less.

14.31 Demand Control (Optional PCB)

Remote control setting:

- When Optional PCB connection select "YES", Demand Control function can select "YES" or "NO".

Purpose:

- After the demand control select YES, below control will activated.
 - 0-10V Demand control

0-10V Demand control

- Demand control is use to reduce the current usage of heat pump unit by third party device.

Control start condition:

- Select "YES" at Demand control at installer menu.
- 0-10V input for this electrical current control is detected.

Control content:

- If start condition is fulfilled, indoor will receive the voltage signal from optional PCB. Indoor will send the rate value to outdoor unit.
- Outdoor will change the current limit according to the percentage receive from indoor unit.

14.32 Holiday Mode

- Purpose:
 - Promotes energy saving by allowing the user to stop the system during holiday and enables the system to resume at the preset temperature after holiday.
- Control details:
 - Indoor operate the unit according running mode request. Target temperature will follow holiday setting temperature.
 - If heat mode request is receive, Target Water Out Temperature will change according to holiday shift temperature set.
[If heat is set OFF at holiday, unit, water pump and zone control will OFF]
 - If tank mode request is receive, Target Tank Set Temperature will change according to the holiday tank shift temperature set.
[If tank is set OFF at holiday, heat pump and tank heater will OFF]
 - After days of holiday have been set, heat pump will stop and only resume operation at the end of holiday countdown.
- Start condition:
 - Holiday timer set and the holiday timer start
 - * The day holiday mode was set is counted as day 1.
- Stop condition:
 - OFF/ON button is pressed.
 - Holiday timer is reached.

14.33 Dry Concrete

- Purpose
 - Provide heat to floor heating panel and dry the wet concrete during installation.
- Setting condition:
 - Dry concrete parameter can be set through remote control under system setup.
 - Parameters are possible to set up to 99 days with different target set temperature
- Control details:
 - Dry concrete mode will be activates when select ON from service setup.
 - Once start dry concrete function, remote control will send step 1 setting temperature to indoor unit.
* This temperature is set at zone temperature. If system is 2 zones, both zone target temperature is set as same temperature.
 - Heat pump will start heat mode operation to room side with received target water outlet temperature.
* Heat pump will operate according to Heat pump Target Water Temperature.
 - After complete day 1 setup operation, day 2 data will be send to indoor at 12.00am on the second day.
 - Each preset data will be send every day until dry concrete mode is complete, unit will turns OFF and exit dry concrete function.
 - 3 ways valve and booster heater will turn OFF and 2 ways valve will turns ON.
- Cancel condition:
 - Dry concrete mode is complete and OFF signal is received.
 - OFF signal is received by pressing OFF/ON button.

14.34 Flow Sensor

- The water flow sensor serves as an overload protector that shuts down the unit when the water level is detected to be low.
- Abnormal flow detection:

Sequence	Abnormal flow	Normal flow
Normal case	Flow rate < 8 l/min or \geq 69 l/min	\geq 8 l/min
During status 2~6 on Anti-freeze deice	\geq 8 l/min	< 8 l/min

15. Protection Control

15.1 Protection Control for All Operations

15.1.1 Time Delay Safety Control

- 1 The compressor will not start for three minutes after stop of operation.

15.1.2 30 Seconds Forced Operation

- 1 Once the compressor starts operation, it will not stop its operation for 30 seconds.
- 2 However, it can be stopped using control panel at indoor unit.

15.1.3 Total Running Current Control

- 1 When the outdoor running current exceeds X value, the compressor frequency will decrease.
- 2 If the outdoor running current does not exceed X value, the compressor frequency will return to normal operating frequency.
- 3 If the outdoor running current continue to increase till exceed Y value, compressor will stop, and if this occurs 3 times within 20 minutes, system will stop operation and OFF/ON control panel LED will blink (F16 error occurs).


Operation Mode	WH-WXG09ME8		WH-WXG12ME8		WH-WXG16ME8	
	X (A)	Y (A)	X (A)	Y (A)	X (A)	Y (A)
Heating	11.8	14.8	13.8	16.8	18.0	21.0
Cooling	9.0	14.8	9.0	16.8	9.0	21.0

A. DC Peak Current Control

- 1 When the current to IPM exceeds set value of 60.5 A, compressor will stop. Compressor will restart after three minutes.
- 2 If the set value exceeds again for more than 30 seconds after the compressor restarts, operation will restart after two minutes.
- 3 If the set value exceeds again for within 30 seconds after the compressor restarts, operation will restart after one minute. If this condition repeats continuously for seven times, system will stop operation and OFF/ON control panel LED will blink (F23 error occurs).

15.1.4 Compressor Overheating Prevention Control

- The compressor operating frequency is regulated in accordance to discharge temperature as shown in below figures. When the discharge temperature exceeds 107°C, compressor will stop, and if this occurs 4 times within 30 minutes, system will stop operation and OFF/ON control panel LED will blink (F20 error occurs).




15.1.5 High Pressure Sensor Control


- Purpose:
 - To protect the system operation.
- Detection period:
 - After compressor on for 1 minute.
- Detection conditions:
 - When abnormal high voltage detection, 5 V or when open circuit detection 0V for 5 seconds continuously.
- After detection:
 - When abnormality is detected 4 times within 120 minutes, unit stop operation.
 - OFF/ON control panel LED will blink (H64 error occurs).

15.1.6 Outside Temperature Current Control

Heating



Cooling



15.1.7 Pre-Heat Control

- Purpose:
 - For compressor protection during low outdoor ambient operation (during heating low temperature operation).
- Control content:
 - a. Trigger Pre-Heat Control condition
 - When the outdoor air temperature is below than -10°C, and discharge temperature is -10°C or below.
 - b. Resetting Pre-Heat Control condition
 1. When the outdoor air temperature exceeds entry condition (3°C)
 2. When the discharge temperature exceeds entry condition (3°C)

15.2 Protection Control for Heating Operation

15.2.1 Outdoor Air Temperature Control


The maximum current value is regulated when the outdoor air temperature rises above 14°C in order to avoid compressor overloading.

15.2.2 Deice Operation


When outdoor pipe temperature and outdoor air temperature is low, deice operation start where outdoor fan motor stop.

- Deice judging condition

Outdoor Unit Deice Control



- Deice mode selection condition
 - There are 2 deice modes, according to water inlet temperature and outdoor ambient temperature the deice mode is decided.




Judgement details:


- 1 When water inlet temperature is more than 74°C, unit will operate deice mode 1.
- 2 When water inlet temperature is less than 19°C, unit will operate deice mode 2.
- 3 When water inlet temperature is less than 74°C and outdoor ambient temperature is less than -10°C, unit will operate deice mode 2.
- 4 When water outlet temperature sensor 2 detect temperature is less than 14°C, unit will operate deice mode 2.

- Deice operation time diagram

a. Deice mode 1 control:



b. Deice mode 2 control:



15.2.2.1 Ice Choke Detection Control

This control is only available on models equipped with [Deice mode 2].

Purpose

Ice choke detection and forced defrosting to melt the ice are performed to prevent abnormal rises in discharge port temperature.

Control Content

1. During heating operation (excluding deice control)

Start Conditions

- 1 During heating operation (excluding deice mode 2 control)
- 2 Outdoor temperature < 10°C
- 3 Compressor is ON
- 4 After Compressor starting control ends
- 5 High-pressure saturation temperature - Indoor piping temperature $\geq 40^{\circ}\text{C}$
- 6 EVA outlet temperature - Outdoor piping temperature $\geq 35^{\circ}\text{C}$
- 7 Outdoor piping temperature < -35°C
- 8 Outdoor temperature - EVA outlet temperature < -4°C

If all the above start conditions 1 to 7 are met continuously for 30 seconds, or if all the above start conditions 1 to 5 and 8 are met continuously for 30 seconds, deice mode 2 control will be executed.

※If the conditions are no longer met during the timer 30 seconds, the timer of 30 seconds count will be reset.

2. During normal deice (excluding antifreezing deice control)

Start Conditions


- 1 During normal deice (including 0Hz instruction sequence)
- 2 Outdoor temperature < 10°C
- 3 High-pressure saturation temperature - Indoor piping temperature $\geq 20^{\circ}\text{C}$
- 4 Indoor piping temperature < -25°C

If all the above start conditions 1 to 4 are met continuously for 30 seconds, forced antifreezing deice control will be executed.

15.3 Protection Control for Cooling Operation

15.3.1 Outdoor Air Temperature Control

- The Compressor operating frequency is regulated in accordance to the outdoor air temperature as shown in the diagram below.
- This control will begin 1 minute after the compressor starts.
- Compressor frequency will adjust base on outdoor air temperature.



15.3.2 Freeze Prevention Control 1


- 1 When refrigerant temperature is lower than 0°C continuously for 10 seconds, compressor will stop operating.
- 2 Compressor will resume its operation three minutes after the refrigerant heat exchanger is higher than 2°C.
- 3 Heat exchanger freeze prevention (H99) will memory in error history.

16. Servicing Guide

16.1 How to take out Front Plate

Open and Close Front Plate ⑭ (ID)

1. Remove the 2 mounting screws of Front Plate ⑭ (ID).
2. Slide it upwards to unhook the Front Plate ⑭ (ID) hook.
3. Reverse above steps 1~2 for close it.



⚠ CAUTION

Open and close the front plate carefully.
The front plate is heavy and may cause injury to fingers.

*The remote control cable is connected to the front panel, so take care when removing the panel.

16.2 Test Run

1. Before test run, ensure that the following items are checked.
 - a) Pipework are properly done.
 - b) Electric cable connecting work are properly done.
 - c) Tank Unit is filled up with water and trapped air is released.
 - d) Please turn on the power supply after filling the tank until full.
2. Switch ON the power supply of the Tank Unit. Set the Tank Unit RCCB/ELCB to "ON" condition. Then, please refer to the Operation Instruction for operation of Remote Controller ①.

Note:

During winter, turn on the power supply and standby the unit for at least 15 minutes before test run. Allow sufficient time to warm up refrigerant and prevent wrong error code judgement.


3. For normal operation, the water pressure reading should be in between 0.5 bar and 4 bar (0.05 MPa and 0.4 MPa). If necessary, adjust the speed of the water pump to bring it into the normal water pressure operating range. If adjusting the speed of the water pump does not solve the problem, contact a local authorized dealer.
4. For the WH-ADC0316M9E8AN1, WH-ADC0916M3E5AN1, make sure that the 'electric anode icon' on the remote controller ① is lit.
5. After test run, clean the magnetic water filter set with reference to "Maintenance for magnetic water filter" in the Installation Manual of the AIR-TO-WATER HEATPUMP OUTDOOR UNIT. Reinstall it after the cleaning is finished.

16.3 Expansion Vessel ⑪ Pre Pressure Checking

For Space heating/cooling

- The tank unit is equipped with an expansion vessel with the capacity of 12 L and the initial pressure of 1 bar.
 - The total volume of water in the system should not exceed 200 L.
(The volume in the pipe of the tank unit is approximately 5 L).
 - If the total water volume exceeds 200 L, add an expansion vessel.
(Field supply)
 - The installed height difference of the water circuit of the system should not exceed 30 m.
(Extra pump may be required).
- * However, in case of 30 m, set the pressure in the circulation circuit to 0.5~1.0 bar.
Higher than 1.0 bar may cause water leakage due to component breakage.


16.4 How To Adjust Pump Speed




NOTE:

1. Whenever at [Screen 5], if press SW to OFF, pump operation should be turned OFF.
2. Whenever at [Screen 6], if press SW to OFF, pump operation should be turned OFF.

16.5 How To Unlock Cool Mode




16.6 EEPROM Factory Default Data Setup Procedure




- EEPROM default data setup is only possible during initialization process.
- Press (▲, ▼, ◀, ▶) simultaneously for 5secs continuously, initialization process will stop & EEPROM default data setup process will start.


During EEPROM default data setup process, display should be as shown below.



- Once EEPROM default data setup process is complete, initialization process will re-start from beginning.



16.7 Dry Concrete Setup



- Press ▲ or ▼ button to select no. of stages.
 - Press ↵ button to store latest status.
 - Press ↶ button, display will return to [Screen 6].

- If suppose to select 10 stages, then setup will start from stage 1/10.
 - Press ▲ or ▼ button to select set temperature.
 - Press ↵ button to store latest status.

- Move to next stage 2/10
 - Repeat the same procedure

- Move to next stage 10/10
 - Repeat the same procedure.
 - Press ↵ to store latest status the the display will return to [Screen 4]
 - Press ↶ button to return to stage 9/10.

Service setup 3 17pm, Mon
 Dry concrete: Select No. of stages
 Range: (1~99)
 Steps: ±1
 10
 Select Confirm

Service setup 3 17pm, Mon
 Dry concrete: 1/10
 Range: (25°C~55°C)
 Steps: ±1°C
 25 °C
 Select Confirm

Service setup 3:17pm, Mon
 Dry concrete: 2/10
 Range: (25°C~55°C)
 Steps: ±1°C
 30 °C
 Select Confirm

Service setup 3 18pm, Mon
 Dry concrete: 10/10
 Range: (25°C~55°C)
 Steps: ±1°C
 30 °C
 Select Confirm

Return to [Screen 6]

17. Maintenance Guide


In order to ensure safety and optimal performance of the Tank Unit, seasonal inspections on the Tank Unit, functional check of RCCB/ELCB, field wiring and piping have to be carried out at regular intervals. This maintenance should be carried out by authorized dealer. Contact dealer for scheduled inspection.

1 Charging and Discharging the Water

Make sure all the piping installations are properly done before carry out below steps.


Charge the Water

- For Domestic Hot Water Tank
 - a. Set the Domestic Hot Water Tank Discharge (Drain Tap) ⑨ to “CLOSE”.



Domestic Hot Water Tank Discharge (Drain Tap) ⑨

- b. Set all Tap / Shower “OPEN”.
 - c. Start filling water to the Domestic Hot Water Tank via Tube Connector ③.
After 20~40min, water should flow out from Tap / Shower.
Else, please contact your local authorized dealer.
 - d. Check and make sure no water leaking at the tube connecting points.
 - e. Set the Domestic Hot Water Tank Discharge (Drain Tap) ⑨ to “OPEN” for 10 seconds to release air from this pipeline. Then set it “CLOSE”.
 - f. Turn the Safety Relief Valve ⑳ (ID) knob counterclockwise slightly and hold for 10 seconds to release air from this pipeline. Then recover the knob to original position.
 - g. Ensure Step 5 & 6 is carried out each time after charging water to Domestic Hot Water Tank.
 - h. To prevent back pressure from happening to the Safety Relief Valve ⑳ (ID), do turn the Safety Relief Valve ⑳ (ID) knob counterclockwise.
- For Space Heating / Cooling
 - a. Start filling water (with pressure more than 1 bar (0.1MPa)) to the Space Heating/Cooling circuit via Tube Connector ①.
 - b. Stop filling water if the free water flow through Pressure Relief Valve drain pipe. (Check the Outdoor Unit)
 - c. Turn ON the Tank Unit.
 - d. Remote control menu → Installer setup → Service setup → pump maximum speed → Turn on the pump.
 - e. Make sure Water Pump ⑦ (OD) is running.
 - f. Check and make sure no water leaking at the tube connecting points.
 - g. Reinstall the Cabinet front plate f by tightening the 2 mounting screws.



Discharge the Water

- For Domestic Hot Water Tank
 - a. Turn OFF power supply.
 - b. Set the Domestic Hot Water Tank Discharge (Drain Tap) ⑨ to “OPEN”.
 - c. Open Tap / Shower to allow air inlet.
 - d. Turn the Safety Relief Valve ⑫ (ID) knob counterclockwise slightly and hold it until all air is released from this pipeline. Then recover the knob to original position after ensured the pipeline is emptied.
 - e. After discharge, set Domestic Hot Water Tank Discharge (Drain Tap) ⑨ to “CLOSE”.


2 Check Water Pressure *(1 bar = 0.1 MPa)

Water pressure should not lower than 0.5 bar (with inspects the Water Pressure from Remote Controller). If necessary add water into Tank Unit (via Tube Connector ③).

3 Check Pressure Relief Valve

*Pressure Relief Valve is mounted in the Outdoor Unit.

- Confirm that the pressure relief valve is working properly, Pull the lever horizontal direction.
- Release the lever when water comes out of the drain pipe of the pressure relief valve.
(While the air continues to come out of the drain pipe, keep raising the lever to completely discharge the air.)
- Confirm that the water from the drain pipe stops.
- If water is leaking, pull the lever several times and return it to make sure the water stops.
- If water keeps coming out of the drain, drain water.
- Turn off the system and contact your local authorized dealer.



4 Check Air Accumulation


- Open the air vent plugs on the heating panel, fan convactor, etc., and remove the air accumulated in the equipment and piping.
- If the outdoor unit and the indoor unit are installed on different floors, open the air vent plug on the water plug of the outdoor unit and the air vent plug on the heater bottle inside the indoor unit to remove the air.
(be careful, water will come out)

- 5 Indoor Unit Control Board Area
Thorough visual inspection of the control board and look for defects, i.e. loose connection, melting of wire insulator and etc.
- 6 RCCB/ELCB
Ensure the RCCB/ELCB set to “ON” condition before check RCCB/ELCB.
Turn on the power supply to the Tank Unit.
This testing could only be done when power is supplied to the Tank Unit.


⚠ WARNING

Be careful not to touch parts other than RCCB/ELCB test button when the power is supplied to Tank Unit. Else, electrical shock may happen. Before obtaining access to terminals, all supply circuits must be disconnected.

- Push the “TEST” button on the RCCB/ELCB. The lever would turn down and indicate “0”, if it functions normal.
 - Contact authorized dealer if the RCCB/ELCB malfunction.
 - Turn off the power supply to the Tank Unit.
 - If RCCB/ELCB functions normal, set the lever to “ON” again after testing finish.
- 7 Reset Overload Protector ⑩
Overload protector ⑩ is a safety device to prevent water overheating. If the overload protector ⑩ is activated, reset it using the following procedure.
 - a. Remove the cover.
 - b. Reset the overload protector ⑩ by gently pressing the central button with the test pen.
 - c. Secure the cover in place as before.



- 8 Maintenance for Magnet Water Filter ⑧ (OD)
 - a. Turn OFF power supply.
 - b. Place a container below Magnet Water Filter ⑧ (OD).
 - c. Turn to remove the Magnet Bar at bottom of Magnet Water Filter ⑧ (OD).
 - d. By using Allen key (8mm), remove the Cap of Discharge Port.
 - e. By using Allen Key (4mm), open the Service Valve to release the dirty water from the Discharge Port into a container. Close the service valve when the container is full to avoid spillage in the tank unit. Dispose the dirty water.
 - f. Reinstall the Cap of Discharge Port and Magnet Bar.
 - g. Re-charging the water to Space Heating / Cooling circuit if necessary (refer Section 5 for details.)
 - h. Turn ON power supply.



- 9 Maintenance for Safety Relief Valve ⑳ (ID)
It is strongly recommended to operate the valve by turn the knob counter clockwise to ensure free water flow through discharge pipe at regular intervals to ensure it is not blocked and to remove lime deposit.

Stagnant water in Tank Unit should be drained if it is not going to be operated for more than 60 days.

17.1 Maintenance for Magnetic Water Filter Set

17.1.1 Service and Maintenance

If forget Password and cannot operate remote controller

↶ + ↵ + ↷ Press for 5 seconds.
 Password unlock screen appears, press Confirm and it shall reset.
 Password will become 0000. Please reset it again.
 (Note) This is displayed only when the remote controller is password-locked.

17.1.2 Maintenance Menu

How to set up the Maintenance menu

Maintenance menu	12:00 pm, Mon
Actuator check	
Test mode	
Sensor setup	
Reset password	
▼ Select	[↵] Confirm

↶ + ↵ + ↷ Press for 5 seconds.

Items that can be set:

- Actuator check (Manual ON/OFF of all functional parts)
 Note: As there is no protection action, be careful not to cause any errors when operating each part (e.g., do not turn ON the pump when there is no water).
- Test mode (Test run)
 This mode is generally not used.
- Sensor setup (Offset gap of detected temperature of each sensor, can be set within a range of -3°C to 3°C).
 Note: Use this setting only if the sensor is deviated as it affects temperature control.
- Reset password (Password reset)

17.1.3 Custom Menu

How to set up a Custom menu

Custom menu	12:00 pm, Mon
Cool mode	
Back-up heater	
Reset energy monitor	
Reset operation history	
▼ Select	[↵] Confirm

Custom menu	12:00 pm, Mon
Reset energy monitor	
Reset operation history	
Smart DHW	
Anti-stick mode	
▲ Select	[↵] Confirm

≡ + ∨ + < Press for 5 seconds.

Items that can be set:

- Cool mode (Select Cooling function: Enable/Disable)
 Default setting is Disable.
 Note: Enabling or disabling Cool Mode may affect electricity usage, be careful and do not simply change it.
 In Cool mode, ensure that piping is properly insulated; otherwise, condensation may occur, leading to water dripping on the floor and potentially causing damage.
- Back-up heaters (Select Back-up heaters: Enable/Disable)
 Note: This setting differs from the customer's choice to use or not use the back-up heater. It disables the heater power for freeze protection. (This setting should only be used if requested by the utility company.)
 This setting may result in a lower heating temperature, potential failure of defrosting, and system stoppages (H75 error).
 Installation must be performed by a qualified personnel. If the system stops frequently, the issue may be due to insufficient circulation flow or a heating set temperature that is too low.
- Reset energy monitor (Deletes the memory of the energy monitor)
 Use this function when moving house or handing over the unit.
- Reset operation history (Deletes the memory of the operation history)
 Use this function when moving house or handing over the unit.
- Smart DHW (Set Smart DHW mode Parameter)
 - Start time: Tank reboil at lower ON Temp. onward.
 - Stop time: Tank reboil at normal ON Temp. onward.
 - ON Temp.: Tank Reboil Temp when Smart DHW start.
- Anti-stick mode (select Anti-stick mode: Enable/Disable)
 Default setting is Enable.
 The actuator is automatically activated every Monday at 3:00 am to prevent the actuating parts from sticking together.
 If you wish to stop the periodic activation, select "Disable".
 Parts and other components that are not operated for an extended period may stick if Anti-stick mode is disabled.

17.1.4 Specifications

17.1.4.1 Specifications of fresh water as heat transfer medium in brazed heat exchanger

Parameter	Quality Limits for Tap Water on the Secondary Side
Temperature	Below 60°C
pH	7 to 9
Alkalinity	60mg/l $< \text{HCO}_3^- < 300\text{mg/l}$
Conductivity	$< 500\mu\text{S/cm}$
Hardness	$[\text{Ca}^+, \text{Mg}^+] / [\text{HCO}_3^-] > 0.5$
Chloride	$< 200\text{mg/l}$ at 60°C
Sulphate	$[\text{SO}_4^{2-}] > 100\text{mg/l}$ and $[\text{HCO}_3^-] / [\text{SO}_4^{2-}] > 1$
Nitrate	$\text{NO}_3^- < 100\text{mg/l}$
Chlorine	$< 0.5\text{mg/l}$

17.1.4.2 External filter

Solids in the water must be filtered.


Minimum filter mesh size required for the field supply external filter in the water inlet is 20 mesh.

18. Troubleshooting Guide

18.1 Refrigeration Cycle System

In order to diagnose malfunctions, make sure that there are no electrical problems before inspecting the refrigeration cycle.

Such problems include insufficient insulation, problem with the power source, malfunction of a compressor and a fan.



18.2 Relationship Between the Condition of the Air-to-Water Heatpump Indoor and Outdoor Units and Electric Current

Condition of the Air-to-Water Heatpump indoor and outdoor units	Heating Mode	Cooling Mode
	Electric current during operation	Electric current during operation
Water leakage or insufficient water flow rate in the system		
Excessive amount of refrigerant		
Inefficient compression		
Insufficient refrigerant (gas leakage)		
Outdoor heat exchange deficiency		
Clogged expansion valve or Strainer		


- Carry out the measurements of pressure, electric current, and temperature fifteen minutes after an operation is started.

18.3 Breakdown Self Diagnosis Function

18.3.1 Self Diagnosis Function (Three Digits Alphanumeric Code)

- When abnormality occur during operation, the system will stop operation, and OFF/ON control panel LED will blink and error code will display on the control panel.
- Even error code is reset by turning OFF power supply or by selecting ERROR RESET, if the system abnormality is still unrepaired, system will again stop operation, and OFF/ON control panel LED will again blinks and error code will be display.
- The error code will store in IC memory.
- **To check the error code**
 - 1 When an abnormality occurs, system will stop operation and OFF/ON control panel LED will blink.
 - 2 Error code of the abnormality will be display on the control panel.
 - 3 To determine the abnormality description, the error code table needs to be referred.

eg:



Press < > to select Close / Reset then press ↵

- **To display past/last error code**
 - 1 Turn ON power supply.
 - 2 Refer below procedure to retrieve the error code history.
- **To permanently delete error code from IC memory**
 - 1 Turn ON power supply.
 - 2 Refer below procedure to clear error history.



Press button and select "System Check"

Main menu 9:40am, Mon	
Function setup	
System check	
Personal setup	
Service contact	
Select	[+/-] Confirm

System check 9:40am, Mon	
Energy monitor	
System information	
Error history	
Compressor	
Select	[+/-] Confirm

[Screen 4] Press SW to select "Error history"

System check 9:40am, Mon	
Energy monitor	
System information	
Error history	
Compressor	
Select	[+/-] Confirm

Display last 4 error retrieved from EEPROM

Error history 9:40am, Mon	
1. H76 (2024/02/19)	
2. H15 (2024/02/18)	
3. H70 (2024/02/17)	
4. H76 (2024/02/16)	
[+/-] Clear history	

Do you want to clear error history?	
Yes	No

Do you want to clear error history?	
Yes	No

Error history 9:40am, Mon	
1. --	
2. --	
3. --	
4. --	
[+/-] Clear history	

18.4 Error Codes Table

Diagnosis display	Abnormality/Protection control	Abnormality judgement	Primary location to verify
H00	No abnormality detected	—	—
H12	Indoor/Outdoor capacity unmatched	10s after power supply	<ul style="list-style-type: none"> Indoor/outdoor connection wire Indoor/outdoor PCB Specification and combination table in catalogue
*H15	Outdoor compressor temperature sensor abnormality	Continue for 5 sec.	<ul style="list-style-type: none"> Compressor temperature sensor (defective or disconnected)
*H17	Zone 2 water pump abnormality	Continue for 10 sec.	<ul style="list-style-type: none"> Indoor PCB (main) Water pump (malfunction)
H20	Water pump abnormality	Continue for 10 sec.	<ul style="list-style-type: none"> Indoor PCB Water pump (malfunction)
H21	Abnormal water pressure	Continue for 300 sec.	<ul style="list-style-type: none"> Water pressure sensor
H22	Abnormal tank 2 sensor	Continue for 5 sec.	<ul style="list-style-type: none"> Tank 2 sensor
H23	Refrigerant liquid temperature sensor abnormality	Continue for 5 sec.	<ul style="list-style-type: none"> Refrigerant liquid temperature sensor (defective or disconnected)
*H27	Service valve error	Continue for 300 sec.	<ul style="list-style-type: none"> High pressure sensor (defective or disconnected)
H28	Abnormal solar sensor	Continue for 5 sec.	<ul style="list-style-type: none"> Solar temperature sensor (defective or disconnected)
H31	Abnormal swimming pool sensor	Continue for 5 sec.	<ul style="list-style-type: none"> Pool temperature sensor (defective or disconnected)
H36	Abnormal buffer tank sensor	Continue for 5 sec.	<ul style="list-style-type: none"> Buffer tank sensor (defective or disconnected)
H38	Brand code not match	When indoor and outdoor brand code not same	—
H42	Compressor low pressure abnormality	—	<ul style="list-style-type: none"> Outdoor pipe temperature sensor Clogged expansion valve or strainer Insufficient refrigerant Outdoor PCB (main) Compressor
H43	Abnormal Zone 1 sensor	Continue for 5 sec.	<ul style="list-style-type: none"> Water temperature Zone 1 sensor
H44	Abnormal Zone 2 sensor	Continue for 5 sec.	<ul style="list-style-type: none"> Water temperature Zone 2 sensor
H62	Water flow switch abnormality	Continue for 140 sec.	<ul style="list-style-type: none"> Water flow switch
H64	Refrigerant high pressure abnormality	4 times in 120 minutes	<ul style="list-style-type: none"> Outdoor high pressure sensor (defective or disconnected)
H65	Abnormal deice water circulation	Water flow > 8L/min continuously for 10 seconds during anti freeze deice	<ul style="list-style-type: none"> Water pump
H67	Abnormal External Thermistor 1	Continue for 5 sec.	<ul style="list-style-type: none"> Room temperature Zone 1 sensor
H68	Abnormal External Thermistor 2	Continue for 5 sec.	<ul style="list-style-type: none"> Room temperature Zone 2 sensor
H70	Back-up heater OLP abnormality	Continue for 60 sec.	<ul style="list-style-type: none"> Back-up heater OLP (Disconnection or activated)
H72	Tank sensor abnormal	Continue for 5 sec.	<ul style="list-style-type: none"> Tank sensor
H74	PCB communication error	Communication or transfer error	<ul style="list-style-type: none"> Indoor main PCB and Sub PCB
H75	Low water temperature control	Room heater disable and deice request to operate under low water temperature	<ul style="list-style-type: none"> Heater operation must enable to increase water temperature
H76	Communication error (RC-1 & Indoor or RC-1 & RC-2)	—	<ul style="list-style-type: none"> Indoor - control panel (defective or disconnected) control panel 1 - control panel 2 (defective or disconnected)
H90	Indoor/outdoor abnormal communication	> 15 sec. after starting operation	<ul style="list-style-type: none"> Internal/external cable connections Indoor/Outdoor PCB
H91	Tank heater OLP abnormality	Continue for 60 sec.	<ul style="list-style-type: none"> Tank heater OLP (Disconnection or activated)

Diagnosis display	Abnormality/Protection control	Abnormality judgement	Primary location to verify
H95	Indoor/Outdoor wrong connection	—	<ul style="list-style-type: none"> Indoor/Outdoor supply voltage
H98 / F95	Outdoor high pressure overload protection Cooling high pressure overload protection	—	<ul style="list-style-type: none"> Outdoor high pressure sensor Water pump or water leakage Clogged expansion valve or strainer Excess refrigerant Outdoor PCB (main)
H99	Indoor heat exchanger freeze prevention	—	<ul style="list-style-type: none"> Indoor heat exchanger Refrigerant shortage
F12	Pressure switch activate	4 times occurrence within 30 minutes	<ul style="list-style-type: none"> Pressure switch
F14	Outdoor compressor abnormal revolution	4 times occurrence within 20 minutes	<ul style="list-style-type: none"> Outdoor compressor
F15	Outdoor fan motor lock abnormality	2 times occurrence within 30 minutes	<ul style="list-style-type: none"> Outdoor PCB Outdoor fan motor
F16	Total running current protection	3 times occurrence within 20 minutes	<ul style="list-style-type: none"> Excess refrigerant Outdoor PCB
F20	Outdoor compressor overheating protection	4 times occurrence within 30 minutes	<ul style="list-style-type: none"> Compressor tank temperature sensor Clogged expansion valve or strainer Insufficient refrigerant Outdoor PCB (main) Compressor
F22	IPM (power transistor) overheating protection	3 times occurrence within 30 minutes	<ul style="list-style-type: none"> Improper heat exchange IPM (Power transistor)
F23	Outdoor Direct Current (DC) peak detection	7 times occurrence continuously	<ul style="list-style-type: none"> Outdoor PCB (main) Compressor
F24	Refrigeration cycle abnormality	2 times occurrence within 30 minutes	<ul style="list-style-type: none"> Insufficient refrigerant Outdoor PCB (main) Compressor low compression
F25	Cooling/Heating cycle changeover abnormality	4 times occurrence within 30 minutes	<ul style="list-style-type: none"> 4-way valve V-coil
F27	Pressure switch abnormality	Continue for 1 min.	<ul style="list-style-type: none"> Pressure switch
F30	Water outlet sensor 2 abnormality	Continue for 5 sec.	<ul style="list-style-type: none"> Water outlet sensor 2 (defective or disconnected)
F32	Abnormal Internal Thermostat	Continue for 5 sec.	<ul style="list-style-type: none"> Control panel PCB thermostat
F36	Outdoor air temperature sensor abnormality	Continue for 5 sec.	<ul style="list-style-type: none"> Outdoor air temperature sensor (defective or disconnected)
F37	Indoor water inlet temperature sensor abnormality	Continue for 5 sec.	<ul style="list-style-type: none"> Water inlet temperature sensor (defective or disconnected)
F40	Outdoor discharge pipe temperature sensor abnormality	Continue for 5 sec.	<ul style="list-style-type: none"> Outdoor discharge pipe temperature sensor (defective or disconnected)
F41	PFC control	4 times occurrence within 10 minutes	<ul style="list-style-type: none"> Voltage at PFC
F42	Outdoor heat exchanger temperature sensor abnormality	Continue for 5 sec.	<ul style="list-style-type: none"> Outdoor heat exchanger temperature sensor (defective or disconnected)
*F43	Outdoor defrost sensor abnormality	Continue for 5 sec.	<ul style="list-style-type: none"> Outdoor defrost sensor (defective or disconnected)
F45	Indoor water outlet temperature sensor abnormality	Continue for 5 sec.	<ul style="list-style-type: none"> Water outlet temperature sensor (defective or disconnected)
*F46	Outdoor Current Transformer open circuit	—	<ul style="list-style-type: none"> Insufficient refrigerant Outdoor PCB (main) Compressor low
F48	Outdoor EVA outlet temperature sensor abnormality	Continue for 5 sec.	<ul style="list-style-type: none"> Outdoor EVA outlet temperature sensor (defective or disconnected)
F49	Outdoor bypass outlet temperature sensor abnormality	Continue for 5 sec.	<ul style="list-style-type: none"> Outdoor bypass outlet temperature sensor (defective or disconnected)
F50	Water inlet 2 sensor error	Continue for 5 sec.	<ul style="list-style-type: none"> Water inlet 2 sensor
F51	Economizer outlet sensor abnormality	Continue for 5 sec.	<ul style="list-style-type: none"> Economizer outlet sensor (defective or disconnected)
F52	Bypass inlet sensor abnormality	Continue for 5 sec.	<ul style="list-style-type: none"> Bypass inlet sensor (defective or disconnected)

Diagnosis display	Abnormality/Protection control	Abnormality judgement	Primary location to verify
F53	Main expansion valve overcurrent protection	4 times occurrence within 40 minutes	<ul style="list-style-type: none"> • Main expansion valve
F54	Bypass expansion valve overcurrent protection	4 times occurrence within 40 minutes	<ul style="list-style-type: none"> • Bypass expansion valve
F55	Electrical anode error	Continue for 60 sec.	<ul style="list-style-type: none"> • Electric anode • Electric anode PCB • Indoor PCB (main)
F56	Outdoor heat exchanger middle sensor abnormality	Continue for 5 sec.	<ul style="list-style-type: none"> • Outdoor heat exchanger middle sensor (defective or disconnected)

Note: * This error code is not applicable for this system.

18.5 Self-Diagnosis Method

18.5.1 Connection Capability Rank Abnormality (H12)

Malfunction Decision Conditions:

During startup operation of cooling and heating, the capability rank of indoor checked by the outdoor is used to determine connection capability rank abnormality.


Malfunction Caused:

- 1 Wrong model interconnected.
- 2 Wrong indoor unit or outdoor unit PCB (main) used.
- 3 Faulty indoor unit or outdoor unit PCB (main).

Abnormality Judgment:

Continue for 10 seconds.

Troubleshooting:



18.5.2 Compressor Tank Temperature Sensor Abnormality (H15)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the compressor tank temperature sensor are used to determine sensor error.


Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue for 5 seconds.

Troubleshooting:



18.5.3 Zone 2 Water Pump Abnormality (H17)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the rotation speed detected by the IPM of water pump motor during water pump operation is used to determine abnormal water pump (feedback of rotation > 6,000rpm or < 300rpm).

Malfunction Caused:

- 1 Operation stop due to short circuit inside the water pump motor winding.
- 2 Operation stop due to breaking of wire inside the water pump motor.
- 3 Operation stop due to breaking of water pump lead wires.
- 4 Operation stop due to water pump motor IPM malfunction.
- 5 Operation error due to faulty indoor unit PCB (main).


Abnormality Judgment:

Continue for 10 seconds.

Troubleshooting:



For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



18.5.4 Water Pump Abnormality (H20)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the rotation speed detected by the IPM of water pump motor during water pump operation is used to determine abnormal water pump (feedback of rotation > 6,000rpm or < 300rpm).

Malfunction Caused:

- 1 Operation stop due to short circuit inside the water pump motor winding.
- 2 Operation stop due to breaking of wire inside the water pump motor.
- 3 Operation stop due to breaking of water pump lead wires.
- 4 Operation stop due to water pump motor IPM malfunction.
- 5 Operation error due to faulty outdoor unit PCB (main).
- 6 Operation error due to faulty outdoor unit PCB (sub).

Abnormality Judgment:


Continue for 10 seconds.

Troubleshooting:



Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



18.5.5 Water Pressure Abnormality (H21)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the pressure detected by the water pressure sensor while the water pump is running is used to determine abnormalities in the water circuit (water pressure feedback > 5.0 bar or < 0.2 bar).

Malfunction Caused:

- 1 Water leak in system.
- 2 Faulty connector connection.
- 3 Faulty water Pressure sensor.
- 4 Faulty outdoor unit PCB (main).

Abnormality Judgment:


Continue for 300 seconds.

Troubleshooting:



Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



18.5.6 Tank 2 Temperature Sensor Abnormality (H22)

Malfunction Decision Conditions:

When tank connection is set to ON, the temperatures detected by the tank temperature sensor are used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty indoor unit PCB (main).

Abnormality Judgment:


Continue for 5 seconds.

Troubleshooting:



Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



18.5.7 Refrigerant Liquid Temperature Sensor Abnormality (H23)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the refrigerant liquid temperature sensor are used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:


Continue for 5 seconds.

Troubleshooting:



Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



18.5.8 Service Valve Error (H27)

Malfunction Decision Conditions:

During cooling operation, when:-

[a] Indoor refrigerant pipe temperature at compressor startup - present indoor refrigerant pipe temperature $< 2^{\circ}\text{C}$

[b] Present high pressure - high pressure at compressor startup $< 5\text{kg}/\text{cm}^2$

**Judgment only for first time cooling operation and not during pump down operation.

Malfunction Caused:

- 1 3 way valves closed.
- 2 Faulty high pressure sensor.
- 3 Faulty indoor refrigerant pipe temperature sensor
- 4 Faulty outdoor unit PCB (main).

Abnormality Judgment:


Continue for 5 minutes.

Troubleshooting:



Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.




18.5.9 Abnormal Solar Sensor (H28)

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty solar sensor.
- 3 Faulty indoor sub PCB.

Abnormality Judgment:

Continue for 5 seconds.




18.5.10 Abnormal Swimming Pool Sensor (H31)

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty swimming pool sensor.
- 3 Faulty indoor sub PCB.

Abnormality Judgment:

Continue for 5 seconds.




18.5.11 Abnormal Buffer Tank Sensor (H36)

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty buffer tank sensor.
- 3 Faulty indoor sub PCB.

Abnormality Judgment:


Continue for 5 seconds.



18.5.12 Brand Code Not Matching (H38)

Malfunction Caused:

- 1 Indoor and outdoor brand code not match.



Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.

18.5.13 Compressor Low Pressure Protection (H42)

Malfunction Decision Conditions:

During operation of heating and after 5 minutes compressor ON, when outdoor pipe temperature below -40°C or above 37°C is detected by the outdoor pipe temperature sensor.

Malfunction Caused:


- 1 Dust accumulation on the outdoor unit heat exchanger.
- 2 Air short circuit at outdoor unit.
- 3 Faulty outdoor unit fan motor.
- 4 Refrigerant shortage (refrigerant leakage).
- 5 Clogged expansion valve or strainer.
- 6 Faulty outdoor pipe temperature sensor.
- 7 Faulty outdoor unit main PCB (main).

Troubleshooting:



Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.




18.5.14 Abnormal Zone 1 Sensor (H43)

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty buffer tank sensor.
- 3 Faulty indoor sub PCB.

Abnormality Judgment:

Continue for 5 seconds.




18.5.15 Abnormal Zone 2 Sensor (H44)

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty buffer tank sensor.
- 3 Faulty indoor sub PCB.

Abnormality Judgment:

Continue for 5 seconds.



18.5.16 Water Flow Switch Abnormality (H62)

Malfunction Decision Conditions:

During operation of cooling and heating, the water flow detected by the outdoor water flow switch is used to determine water flow error.

Malfunction Caused:

- 1 Faulty water pump.
- 2 Water leak in system.
- 3 Faulty connector connection.
- 4 Faulty water flow switch.
- 5 Faulty outdoor unit PCB (sub).

Abnormality Judgment:

Continue for 140 seconds (but no judgment for 30 seconds after water pump startup/restart).

Troubleshooting: Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.





Figure 1

18.5.17 Outdoor High Pressure Abnormality (H64)

Malfunction Decision Conditions:

During operation of cooling and heating, when the outdoor high pressure sensor output signal is 0 Vdc or 5 Vdc.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:


Continue 4 times in 120 minutes.

Troubleshooting:



Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



18.5.18 Deice Circulation Error (H65)

Malfunction Decision Conditions:

During startup and operation of deice (mode 2), the water flow (> 8 l/min) detected by the water flow switch is used to determine deice circulation error.

Malfunction Caused:

- 1 Water flow in air-to-water heatpump unit circuitry.
- 2 Faulty outdoor unit water flow switch.
- 3 Faulty outdoor unit water pump.
- 4 Faulty outdoor unit PCB (sub).
- 5 Faulty outdoor unit PCB (main).


Abnormality Judgment:

Continue for 10 seconds.

Troubleshooting:



For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.




18.5.19 Abnormal External Thermistor 1 (H67)

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty room temperature zone 1 sensor.
- 3 Faulty indoor sub PCB.

Abnormality Judgment:

Continue for 5 seconds.




18.5.20 Abnormal External Thermistor 2 (H68)

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty room temperature zone 2 sensor.
- 3 Faulty indoor sub PCB.

Abnormality Judgment:

Continue for 5 seconds.



18.5.21 Indoor Backup Heater OLP Abnormality (H70)

Malfunction Decision Conditions:

During operation of indoor backup heater, when no power supplies to indoor backup heater or OLP open circuit.

Malfunction Caused:

- 1 Faulty power supply connector connection.
- 2 Faulty connector connection.
- 3 Faulty indoor backup heater overload protector (OLP).
- 4 Faulty indoor unit PCB (main).

Abnormality Judgment:


Continue for 60 seconds.

Troubleshooting:



Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



18.5.22 Tank Temperature Sensor Abnormality (H72)

Malfunction Decision Conditions:

When tank connection is set to ON, the temperatures detected by the tank temperature sensor are used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty indoor unit PCB (main).
- 4 Faulty outdoor unit PCB (sub).

Abnormality Judgment:


Continue for 5 seconds.

Troubleshooting:



Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



18.5.23 PCB Communication Error (H74)

Malfunction Decision Conditions:


When External PCB connection is select "YES" and no communication with External PCB micon for 10 seconds and above.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty indoor PCB.
- 3 Faulty indoor sub PCB.

Abnormality Judgment:

After 1 minute operation started.



18.5.24 Low Water Temperature Control (H75)

Malfunction Decision Conditions:

If defrosting is performed when the heater cannot be used and the water temperature is low, a warning will be issued as there is a risk of the water circuit freezing.

Malfunction Caused:

- 1 The heater setting is disabled.
- 2 Low water flow rate.
- 3 Target ΔT is large and the heating target temperature setting is low.

Abnormality Judgment:

Room heater disable and device request to operate under low water temperature.

Troubleshooting:



For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.

If the model you are using is equipped with a heater [AiO, Bi-bloc], enable the heater setting if it is disabled.

If the system stops frequently, the issue may be due to insufficient circulation flow or a heating set temperature that is too low.

18.5.25 Indoor-Control Panel Communication Abnormality (H76)

Malfunction Decision Conditions:


During standby and operation of cooling and heating, indoor-control panel error occur.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty control panel.
- 3 Faulty indoor unit PCB (main).
- 4 Faulty outdoor unit PCB (sub).

Troubleshooting: **Caution**

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



18.5.26 Indoor/Outdoor Abnormal Communication (H90)

Malfunction Decision Conditions:

During operation of cooling and heating, the data received from outdoor unit in indoor unit signal transmission is checked whether it is normal.

Malfunction Caused:

- 1 Faulty outdoor unit PCB (main).
- 2 Faulty outdoor unit PCB (sub).
- 3 Faulty indoor unit PCB (main).
- 4 Indoor-outdoor signal transmission error due to wrong wiring.
- 5 Indoor-outdoor signal transmission error due to breaking of wire in the connection wires between the indoor and outdoor units.
- 6 Indoor-outdoor signal transmission error due to disturbed power supply waveform.


Abnormality Judgment:

Continue for 15 seconds after operation.

Troubleshooting:



For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



18.5.27 Tank Booster Heater OLP Abnormality (H91)

Malfunction Decision Conditions:

During operation of tank booster heater, and tank booster heater OLP open circuit.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty tank booster heater overload protector (OLP).
- 3 Faulty indoor unit PCB (main).

Abnormality Judgment:

Continue for 60 seconds.

Troubleshooting:



Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.





Fig 1

18.5.28 Unspecified Voltage between Indoor and Outdoor (H95)

Malfunction Decision Conditions:

The supply power is detected for its requirement by the indoor/outdoor transmission.


Malfunction Caused:

- 1 Insufficient power supply.
- 2 Faulty outdoor unit PCB (noise filter/main).

Troubleshooting:



For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



18.5.29 Outdoor High Pressure Protection (H98 / F95)

Malfunction Decision Conditions:


During operation of cooling / heating, when pressure 3.2 MPa and above is detected by outdoor high pressure sensor.

Malfunction Caused:

- 1 Faulty water pump.
- 2 Insufficient water flow rate in system.
- 3 Water leak in system.
- 4 Dust accumulation in the outdoor unit heat exchanger.
- 5 Air short circuit at outdoor.
- 6 Faulty outdoor unit fan motor.
- 7 Clogged expansion valve or strainer.
- 8 Excessive refrigerant.
- 9 Faulty outdoor high pressure sensor.
- 10 Faulty outdoor unit PCB (main).

Troubleshooting:  **Caution**

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.




Troubleshooting:



Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



18.5.30 Indoor Freeze-up Protection (H99)

Malfunction Decision Conditions:

During anti-freezing control in cooling operation, when the refrigerant liquid temperature < 0°C.

Malfunction Caused:


- 1 Faulty water pump.
- 2 Insufficient water flow rate in system.
- 3 Water leak in system.
- 4 Clogged expansion valve or strainer.
- 5 Refrigerant shortage (refrigerant leakage).
- 6 Faulty indoor refrigerant liquid temperature sensor.
- 7 Faulty outdoor unit PCB (main).

Troubleshooting:



Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



18.5.31 Outdoor High Pressure Switch Activate (F12)

Malfunction Decision Conditions:

During operation of cooling and heating, when pressure 3.9 MPa and above is detected by outdoor high pressure switch.

Malfunction Caused:

- 1 Dust accumulation on the outdoor unit heat exchanger.
- 2 Air short circuit at outdoor unit.
- 3 Faulty water pump.
- 4 Insufficient water flow rate in system.
- 5 Water leak in system.
- 6 Clogged expansion valve or strainer.
- 7 Excessive refrigerant.
- 8 Faulty outdoor high pressure sensor and switch.
- 9 Faulty outdoor unit PCB (main).


Abnormality Judgment:

Continue 4 times in 30 minutes.

Troubleshooting:



For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



18.5.32 Compressor Rotation Failure (F14)

Malfunction Decision Conditions:

A compressor rotation failure is detected by checking the compressor running condition through the position detection circuit.

Malfunction Caused:

- 1 Compressor terminal disconnect.
- 2 Faulty outdoor unit PCB (main).
- 3 Faulty compressor.

Abnormality Judgment:


Continue 4 times in 20 minutes.

Troubleshooting:



Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



18.5.33 Outdoor Fan Motor (DC Motor) Mechanism Locked (F15)

Malfunction Decision Conditions:

The rotation speed detected by the Hall IC of the fan motor during fan motor operation is used to determine abnormal fan motor (feedback of rotation > 2550 rpm or < 20 rpm).

Malfunction Caused:

- 1 Operation stop due to short circuit inside the fan motor winding.
- 2 Operation stop due to breaking of wire inside the fan motor.
- 3 Operation stop due to breaking of fan motor lead wires.
- 4 Operation stop due to fan motor Hall IC malfunction.
- 5 Operation error due to faulty outdoor unit PCB (main).

Abnormality Judgment:


Continue 2 times in 20 minutes.

Troubleshooting:



Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



18.5.34 Input Over Current Detection (F16)

Malfunction Decision Conditions:

During operation of cooling and heating, when outdoor current above WXG09ME8 13.8A, WXG12ME8 16.8A & WXG16ME8 21.0A is detected by the current transformer (CT) in the outdoor unit PCB.

Malfunction Caused:


- 1 Excessive refrigerant.
- 2 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue 3 times in 20 minutes.

Troubleshooting: **Caution**

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



18.5.35 Compressor Overheating (F20)

Malfunction Decision Conditions:

During operation of cooling and heating, when temperature above 112°C is detected by the outdoor discharge pipe temperature sensor.

Malfunction Caused:

- 1 Faulty outdoor discharge pipe temperature sensor.
- 2 Refrigerant shortage (refrigerant leakage).
- 3 Clogged expansion valve or strainer.
- 4 Faulty outdoor unit PCB (main).
- 5 Faulty compressor.

Abnormality Judgment:


Continue 4 times in 30 minutes.

Troubleshooting:



Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



18.5.36 IPM Overheating (F22)

Malfunction Decision Conditions:

During operation of cooling and heating, when temperature 95°C is detected by the outdoor IPM temperature sensor.

Malfunction Caused:

- 1 Faulty outdoor unit fan motor.
- 2 Faulty outdoor unit PCB (main).


Abnormality Judgment:

Continue 4 times in 30 minutes.

Troubleshooting:



For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



18.5.37 Output Over Current Detection (F23)

Malfunction Decision Conditions:

During operation of cooling and heating, when outdoor DC current is above set value is detected by the IPM DC Peak sensing circuitry in the outdoor unit PCB (main).

Malfunction Caused:

- 1 Faulty outdoor unit PCB (main).
- 2 Faulty compressor.

Abnormality Judgment:

Continue for 7 times.

Troubleshooting:



For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.

Check the compressor winding resistance:
 - Turn OFF the power and disconnect the harnesses U, V, and W.
 - Measure the winding resistance between U-V, V-W, and W-U.

Are the compressor's winding resistance (U-V, V-W, or U-W) shorted?

Yes
 - Compressor defective due to winding shorted.
 - Replace the compressor.

No
 - Outdoor electronic circuit defect due to power transistor shorted.
 - Replace the outdoor unit PCB (main).

- Checking the power transistor
- Never touch any live parts for at least 10 minutes after turning off the circuit breaker.
- If unavoidably necessary touch a live part, make sure the power transistor's supply voltage is below 50 V using the tester.
- For the UVW, make measurements at the Faston terminal on the board or the relay connector.

Tester's negative terminal	Power transistor (+)	UVW	Power transistor (-)	UVW
Tester's positive terminal	UVW	Power transistor (+)	UVW	Power transistor (-)
Normal resistance	Several kohms to several Mohms			
Abnormal resistance	0 or ∞			

18.5.38 Refrigeration Cycle Abnormality (F24)

Malfunction Decision Conditions:


- 1 During compressor running (heating / cooling) for more than 10 minutes except deice and test mode.
- 2 During heating, water outlet and water inlet difference is less than 3°C.
- 3 During cooling, water outlet and water inlet difference is less than 2°C.
- 4 During heating, high pressure < 0.16 MPa (23 Psi) for more than 10 minutes or during cooling, high pressure < 0.04 MPa (6 Psi) for more than 10 minutes or high pressure < 0.01 MPa (1 Psi) for more than 5 minutes.
- 5 During heating, discharge temperature - saturation temperature of high pressure $\geq 65^{\circ}\text{C}$.
- 6 During cooling, discharge temperature - saturation temperature of high pressure $\geq 70^{\circ}\text{C}$.

Malfunction Caused:

- 1 Refrigerant shortage (refrigerant leakage).
- 2 Faulty indoor water inlet, indoor water outlet, compressor discharge temp sensor or high pressure sensor.
- 3 Clogged expansion valve or strainer.
- 4 Faulty indoor or outdoor PCB (main).

Abnormality Judgment:

Continue 2 times in 30 minutes.



18.5.39 Four Way Valve Abnormality (F25)

Malfunction Decision Conditions:

- 1 During heating operation, when the refrigerant liquid temperature of thermostat ON indoor unit < 0°C.
- 2 During cooling operation, when the refrigerant liquid temperature of thermostat ON indoor unit > 45°C.

Malfunction Caused:

- 1 Faulty sensor.
- 2 Faulty connector connection.
- 3 Faulty outdoor unit PCB (noise filter/main).
- 4 Faulty four way valve.

Abnormality Judgment:


Continue 3 times in 40 minutes.

Troubleshooting:



Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



18.5.40 Outdoor High Pressure Switch Abnormal (F27)

Malfunction Decision Conditions:

During compressor stop, and outdoor high pressure switch is remain opened.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty switch.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:


Continue for 1 minute.

Troubleshooting:



Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



18.5.41 Indoor Water Outlet Temperature Sensor 2 Abnormality (F30)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the water outlet temperature sensor 2 are used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:



Continue for 5 seconds.

Troubleshooting:



Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



18.5.42 Internal Thermostat Error [RC-1 or RC-2] (F32)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by Internal thermostat in control panel are used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty control panel.
- 3 Faulty Indoor unit PCB (main).
- 4 Faulty Outdoor unit PCB (sub).

Abnormality Judgment:


Continue for 5 seconds.

Troubleshooting:



Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



18.5.43 Outdoor Air Temperature Sensor Abnormality (F36)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the outdoor air temperature sensor are used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:


Continue for 5 seconds.

Troubleshooting:



Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



18.5.44 Indoor Water Inlet Temperature Sensor Abnormality (F37)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the indoor water inlet temperature sensor are used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty indoor unit PCB (main).

Abnormality Judgment:


Continue for 5 seconds.

Troubleshooting:



Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



18.5.45 Outdoor Discharge Pipe Temperature Sensor Abnormality (F40)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the outdoor discharge pipe temperature sensor are used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:


Continue for 5 seconds.

Troubleshooting:



Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



18.5.46 Power Factor Correction (PFC) Abnormality (F41)

Malfunction Decision Conditions:

During operation of cooling and heating, when the PFC protection circuitry in the outdoor unit PCB (main) senses abnormal high DC voltage level.

Malfunction Caused:

- 1 Power supply surge.
- 2 Compressor windings not uniform.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:


Continue 4 times in 20 minutes.

Troubleshooting:



Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



18.5.47 Outdoor Pipe Temperature Sensor Abnormality (F42)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the outdoor pipe temperature sensor are used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:


Continue for 5 seconds.

Troubleshooting:




Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



Evaporator Outlet Sensor /
Outdoor Pipe Sensor /
Bypass Outlet Sensor /
Bypass Inlet Sensor /
Economizer Outlet Sensor /
Outdoor Heat Exchanger Middle Sensor /
Defrost Sensor Characteristic



18.5.48 Outdoor Defrost Temperature Sensor Abnormality (F43)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the outdoor defrost temperature sensor are used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:



Continue for 5 seconds.

Troubleshooting:



Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



18.5.49 Indoor Water Outlet Temperature Sensor Abnormality (F45)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the indoor water outlet temperature sensor are used to determine sensor errors.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty indoor unit PCB (main).

Abnormality Judgment:


Continue for 5 seconds.

Troubleshooting:



Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



18.5.50 Outdoor Current Transformer Open Circuit (F46)

Malfunction Decision Conditions:

A current transformer (CT) open circuit is detected by checking the compressor running frequency (\geq rated frequency) and CT detected input current (< 0.65 A) for continuously 20 seconds.

Malfunction Caused:

- 1 CT defective.
- 2 Faulty outdoor unit PCB (main).
- 3 Compressor defective (low compression).


Abnormality Judgment:

Continue 3 times in 20 minutes.

Troubleshooting:



For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



18.5.51 Outdoor Evaporator Outlet Temperature Sensor Abnormality (F48)

Malfunction Decision Conditions:

During start up and operation of cooling and heating, the temperature detected by outdoor evaporator outlet sensor is used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection
- 2 Faulty sensor
- 3 Faulty outdoor unit PCB (main)

Abnormality Judgment:


Continuous for 5 seconds

Troubleshooting:




Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



Evaporator Outlet Sensor /
Outdoor Pipe Sensor /
Bypass Outlet Sensor /
Bypass Inlet Sensor /
Economizer Outlet Sensor /
Outdoor Heat Exchanger Middle Sensor /
Defrost Sensor Characteristic



18.5.52 Outdoor Bypass Outlet Temperature Sensor (F49)

Malfunction Decision Conditions:

During start up and operation of cooling and heating, the temperature detected by outdoor bypass outlet sensor is used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection
- 2 Faulty sensor
- 3 Faulty outdoor unit PCB (main)

Abnormality Judgment:



Continuous for 5 seconds

Troubleshooting:



Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



18.5.53 Outdoor Water Inlet 2 Temperature Sensor Abnormality (F50)

Malfunction Decision Conditions:

During startup and operation of cooling and heating, the temperatures detected by the indoor water inlet 2 temperature sensor are used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:



Continue for 10 seconds.

Troubleshooting:



Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



18.5.54 Outdoor Economizer Outlet Temperature Sensor Abnormality (F51)

Malfunction Decision Conditions:

During start up and operation of cooling and heating, the temperature detected by outdoor economizer outlet sensor is used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:



Continuous for 5 seconds.

Troubleshooting:



Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



18.5.55 Outdoor Bypass Inlet Temperature Sensor Abnormality (F52)

Malfunction Decision Conditions:

During start up and operation of cooling and heating, the temperature detected by outdoor bypass inlet sensor is used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:


Continuous for 5 seconds.

Troubleshooting:




Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



Evaporator Outlet Sensor /
Outdoor Pipe Sensor /
Bypass Outlet Sensor /
Bypass Inlet Sensor /
Economizer Outlet Sensor /
Outdoor Heat Exchanger Middle Sensor /
Defrost Sensor Characteristic



18.5.56 Main Expansion Valve Overcurrent Protection (F53)

Malfunction Decision Conditions:

During start up and operation of cooling and heating, the determination is made based on whether or not an overcurrent flows through the main expansion valve coil.

Malfunction Caused:

- 1 Faulty connector connection
- 2 Faulty main expansion valve coil
- 3 Faulty outdoor unit PCB (main)

Abnormality Judgment:


4 times occurrence in 40 minutes

Troubleshooting:



Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



18.5.57 Bypass Expansion Valve Overcurrent Protection (F54)

Malfunction Decision Conditions:

During start up and operation of cooling and heating, the determination is made based on whether or not an overcurrent flows through the bypass expansion valve coil.

Malfunction Caused:

- 1 Faulty connector connection
- 2 Faulty bypass expansion valve coil
- 3 Faulty outdoor unit PCB (main)

Abnormality Judgment:


4 times occurrence in 40 minutes

Troubleshooting:



Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



18.5.58 Electrical Anode Error (F55)

Malfunction Decision Conditions:

It detects if there is no water in the tank even though the electrical anode setting is enabled, or if there is an abnormality in the power circuit of the electrical anode.

Malfunction Caused:

- 1 There is no water in the tank.
- 2 Faulty connector connection.
- 3 Faulty Indoor unit PCB (main).
- 4 Faulty Electric Controller (ANODE).
- 5 Faulty Electrical Anode bar.

Abnormality Judgment:

Continue for 60 seconds.

Troubleshooting:



Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.





Figure 1




Figure 2

18.5.59 Outdoor Heat Exchanger Middle Temperature Sensor Abnormality (F56)

Malfunction Decision Conditions:

During start up and operation of cooling and heating, the temperature detected by outdoor heat exchanger middle sensor is used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:


Continuous for 5 seconds.

Troubleshooting:




Caution

For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



Evaporator Outlet Sensor /
Outdoor Pipe Sensor /
Bypass Outlet Sensor /
Bypass Inlet Sensor /
Economizer Outlet Sensor /
Outdoor Heat Exchanger Middle Sensor /
Defrost Sensor Characteristic




19. Disassembly and Assembly Instructions

⚠ WARNING

High Voltage are generated in the electrical parts area by the capacitor. Ensure that the capacitor has discharged sufficiently before proceeding with repair work. Failure to heed this caution may result in electric shocks.


19.1 Indoor Unit

19.1.1 To Remove Front Plate and Top Plate



- 1 Remove 2 screw at the bottom to remove the Front Plate
- 2 Remove 12 screw at the top to remove the Top Plate



19.1.2 To Remove Remote Control




1. Remove the top case from the bottom case.
2. Disconnect the Remote Controller wiring.
3. Remove 2 screws then take out the bottom case.

19.1.3 To Remove RCCB

1. Remove 2 screws to open the Control Board Cover.




2. Disconnect lead wires (Brown, black, grey and blue) from RCCB.



3. Remove screw and bracket to remove the RCCB.


19.1.4 To Remove Electronic Controller

1. Disconnect all connectors from main PCB. (CN-TH1, CN-TH2, CN-TH3, CN-PWR2, CN-PWR3, CN-PWR4, CN-CNT, CN-CNT2, CN-ERROR, CN-OLP1, CN1, CN2, CN3, CN4, CN5, CN6, CN-PWR, CN-AC)
2. Detach remote controller, 3-way valve and all wires. (G01, G05, AC-L3, HT-L3, AC-L2, HT-L2, AC-L1, HT-L1, AC-L3-2, AC-N, AC-N2)



19.1.5 To Remove Valve Body


1. Turn the Valve Body anti-clockwise then remove.




19.1.6 To Remove Bottle Complete

2. Disconnect the connector CN-OLP1 from Electronic controller and detached lead wires AC-L1 (Brown), HT-L2 (Orange), HT-L3 (Red), lead wire (Brown) from terminal B, lead wire (Red) from heater 2 and lead wire (Orange) from heater 3.


1. Remove 4 screws from bracket.



3. Remove valve body.



4. Disconnect 2 pipes connection and remove the bottle complete.






WARNING



This symbol shows that this equipment uses a flammable refrigerant with safety A3 group per ISO 817. If the refrigerant is leaked, together with an external ignition source, there is a possibility of fire / explosion.


- If you are working on the R290 product, before starting work and when entering the service area, always turn ON the combustible gas leak detector to ensure there is no leakage.
- Keep all ignition sources away from the product. In particular, open flames, hot surfaces, electrical devices that are not free from electrical sources, static discharges.
- Ensure the servicing area is well ventilated.
- Ensure all the serving tools and equipment complied with ATEX (Atmosphere Explosible) standard.
- Ensure the product is service by certified and authorized serviceman.
- Ensure to always have the approved fire extinguisher during servicing.
- Use a warning placard to ensure that unauthorized personnel cannot enter the protective zone.

19.2 Outdoor Unit

19.2.1 Electronic Controller Removal Procedures









Note: During re-assemble the Main PCB, ensure to attach the O-ring properly to avoid gas leakage into the control board complete.

19.2.2 To Remove Flow Sensor



⚠ When reinstall Flow sensor, ensure the arrow on the flow sensor is parallel with the pipe shaft and is facing in the direction of flow.

19.2.3 To Remove Water Pump



20. Technical Data

20.1 Operation Characteristics

20.1.1 WH-WXG09ME8

Heating Characteristics at Different Outdoor Air Temperature




Condition

Outdoor air temperature : 7°C (DBT), 6°C (WBT)

Indoor water inlet temperature : 30°C

Indoor water outlet temperature : 35°C

Water Piping length between outdoor unit and indoor unit : 5 m



Cooling Characteristics at Different Outdoor Air Temperature




Condition

Outdoor air temperature : 35°C (DBT), -°C (WBT)

Indoor water inlet temperature : 12°C

Indoor water outlet temperature : 7°C

Water Piping length between outdoor unit and indoor unit : 5 m



Cooling Characteristics at Different Outdoor Air Temperature




Condition

Outdoor air temperature : 35°C (DBT), -°C (WBT)

Indoor water inlet temperature : 19°C

Indoor water outlet temperature : 14°C

Water Piping length between outdoor unit and indoor unit : 5 m



Cooling Characteristics at Different Outdoor Air Temperature




Condition

Outdoor air temperature : 35°C (DBT), -°C (WBT)

Indoor water inlet temperature : 23°C

Indoor water outlet temperature : 18°C

Water Piping length between outdoor unit and indoor unit : 5 m



20.1.2 WH-WXG12ME8

Heating Characteristics at Different Outdoor Air Temperature




Condition

Outdoor air temperature : 7°C (DBT), 6°C (WBT)

Indoor water inlet temperature : 30°C

Indoor water outlet temperature : 35°C

Water Piping length between outdoor unit and indoor unit : 5 m



Cooling Characteristics at Different Outdoor Air Temperature




Condition

Outdoor air temperature : 35°C (DBT), -°C (WBT)

Indoor water inlet temperature : 12°C

Indoor water outlet temperature : 7°C

Water Piping length between outdoor unit and indoor unit : 5 m



Cooling Characteristics at Different Outdoor Air Temperature




Condition

Outdoor air temperature : 35°C (DBT), -°C (WBT)

Indoor water inlet temperature : 19°C

Indoor water outlet temperature : 14°C

Water Piping length between outdoor unit and indoor unit : 5 m



Cooling Characteristics at Different Outdoor Air Temperature




Condition

Outdoor air temperature : 35°C (DBT), -°C (WBT)

Indoor water inlet temperature : 23°C

Indoor water outlet temperature : 18°C

Water Piping length between outdoor unit and indoor unit : 5 m



20.1.3 WH-WXG16ME8

Heating Characteristics at Different Outdoor Air Temperature




Condition

Outdoor air temperature : 7°C (DBT), 6°C (WBT)

Indoor water inlet temperature : 30°C

Indoor water outlet temperature : 35°C

Water Piping length between outdoor unit and indoor unit : 5 m



Cooling Characteristics at Different Outdoor Air Temperature




Condition

Outdoor air temperature : 35°C (DBT), -°C (WBT)

Indoor water inlet temperature : 12°C

Indoor water outlet temperature : 7°C

Water Piping length between outdoor unit and indoor unit : 5 m



Cooling Characteristics at Different Outdoor Air Temperature




Condition

Outdoor air temperature : 35°C (DBT), -°C (WBT)

Indoor water inlet temperature : 19°C

Indoor water outlet temperature : 14°C

Water Piping length between outdoor unit and indoor unit : 5 m



Cooling Characteristics at Different Outdoor Air Temperature




Condition

Outdoor air temperature : 35°C (DBT), -°C (WBT)

Indoor water inlet temperature : 23°C

Indoor water outlet temperature : 18°C

Water Piping length between outdoor unit and indoor unit : 5 m



20.2 Heating Capacity Table

20.2.1 WH-WXG09ME8

Water Out (°C)	25			35			45		
Outdoor Air (°C)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)
-25	7900	3500	5.3	8200	4200	6.3	7900	4800	7.0
-20	7900	2940	4.4	8200	3340	5.0	7900	3990	5.9
-15	9000	2740	4.1	9000	3300	5.0	9000	3970	5.9
-7	9000	2260	3.4	9000	2610	4.0	9000	3350	5.0
2	8800	1950	3.0	9000	2360	3.6	9000	2910	4.4
7	9000	1240	2.0	9000	1720	2.6	9000	2300	3.5
25	9000	610	1.2	9000	1080	1.8	9000	1550	2.4

Water Out (°C)	55			65			75		
Outdoor Air (°C)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)
-25	7600	5700	8.3	-	-	-	-	-	-
-20	7600	4760	7.0	7100	5300	7.8	-	-	-
-15	9000	4480	6.8	9000	5270	7.8	8200	6500	9.5
-7	9000	3830	5.8	9000	4680	6.8	9000	5900	8.6
2	9000	3540	5.3	9000	4290	6.5	9000	5500	8.0
7	9000	2780	4.2	9000	3460	5.2	8900	4980	7.3
25	9000	2050	3.1	9000	2680	4.1	8400	3450	5.2

20.2.2 WH-WXG12ME8

Water Out (°C)	25			35			45		
Outdoor Air (°C)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)
-25	10200	4900	7.2	10500	5550	8.1	9800	6700	9.9
-20	11000	4250	6.3	11200	4750	6.9	11000	5500	8.1
-15	12000	4270	6.3	12000	4560	6.7	12000	5670	8.3
-7	11500	3680	5.6	12000	4000	6.1	12000	5020	7.4
2	11500	2920	4.5	12000	3390	5.2	12000	4200	6.3
7	12000	1930	3.1	12000	2370	3.6	12000	3130	4.7
25	12000	1000	1.8	12000	1400	2.3	12000	2000	3.1

Water Out (°C)	55			65			75		
Outdoor Air (°C)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)
-25	9700	7400	10.8	-	-	-	-	-	-
-20	10800	6450	9.5	10300	7550	11.0	-	-	-
-15	12000	6000	8.8	12000	7060	10.4	11000	8450	12.4
-7	12000	5530	8.2	12000	6570	9.6	11600	7300	10.6
2	12000	4950	7.3	12000	5940	8.6	12000	7300	10.6
7	12000	3710	5.6	12000	4620	7.1	12000	6100	9.0
25	12000	2600	3.9	12000	3260	4.9	12000	3920	5.9

20.2.3 WH-WXG16ME8

Water Out (°C)	25			35			45		
Outdoor Air (°C)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)
-25	14200	6800	9.9	14200	7800	11.4	14200	8600	12.5
-20	14200	5400	7.9	14200	6100	8.9	14200	6900	10.1
-15	16000	5900	8.6	16000	6700	9.8	16000	7700	11.2
-7	16000	5400	7.9	16000	6320	9.3	16000	7100	10.4
2	16000	3630	5.5	16000	4850	7.3	16000	5880	8.6
7	16000	2700	4.1	16000	3270	4.9	16000	4190	6.3
25	16000	1450	2.4	16000	1990	3.1	16000	2850	4.3

Water Out (°C)	55			65			75		
Outdoor Air (°C)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)
-25	14000	10530	15.4	-	-	-	-	-	-
-20	14200	8100	11.8	14200	10160	14.8	-	-	-
-15	16000	8700	12.7	16000	10150	14.8	14200	10900	15.9
-7	16000	8120	11.9	16000	9400	13.7	16000	10300	15.0
2	16000	6750	9.9	16000	8150	11.9	16000	9990	14.6
7	16000	5000	7.4	16000	6300	9.3	16000	7600	11.1
25	16000	3650	5.5	16000	4750	7.1	16000	6300	9.3

20.3 Cooling Capacity Table

20.3.1 WH-WXG09ME8

Water Out (°C)	7			14			18		
Outdoor Air (°C)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)
16	9800	2000	3.1	11000	2040	3.1	10800	1380	2.2
25	9300	2280	3.5	10500	2350	3.6	10200	1490	2.4
35	9000	2490	3.8	9800	2630	4.0	9000	1710	2.7
43	8400	2800	4.3	9000	2880	4.4	8600	2000	3.1

20.3.2 WH-WXG12ME8


Water Out (°C)	7			14			18		
Outdoor Air (°C)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)
16	12000	2000	3.1	13700	2050	3.2	12000	1030	1.7
25	12000	3050	4.6	13500	3120	4.7	12000	1880	3.0
35	12000	4210	6.2	13200	3250	4.8	12000	2800	4.2
43	10800	4890	7.1	11200	4870	7.1	12000	3600	5.3


20.3.3 WH-WXG16ME8

Water Out (°C)	7			14			18		
Outdoor Air (°C)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)	Capacity (W)	Input Power (W)	Current (A)
16	15500	3000	4.5	15800	2750	4.2	16000	2500	3.8
25	15000	3750	5.7	15500	3400	5.1	16000	3100	4.7
35	14500	5050	7.4	14500	4500	6.7	15500	3950	5.9
43	12000	5150	7.6	12000	5200	7.6	15000	5350	7.9

21. Exploded View and Replacement Parts List


21.1 Indoor Unit






Note:









The above exploded view is for the purpose of parts disassembly and replacement. The non-numbered parts are not kept as standard service parts.




Note:
 The above exploded view is for the purpose of parts disassembly and replacement.
 The non-numbered parts are not kept as standard service parts.



CABINET FRONT PLATE (REAR VIEW)



Note:
 The above exploded view is for the purpose of parts disassembly and replacement.
 The non-numbered parts are not kept as standard service parts.



Note:
 The above exploded view is for the purpose of parts disassembly and replacement.
 The non-numbered parts are not kept as standard service parts.

SAFETY	REF. NO.	DESCRIPTION & NAME	QTY.	WH-ADC0316M9E81	REMARK
	1	CHASSIS - COMPLETE	1	ACXD50C04840	
	2	BASE PAN	1	ACXD52-06310	
	3	NUT	4	ACXH56-01310	
	4	SCREW	4	H55451J	
	5	BRACKET - UNIT MOUNTING	2	ACXD57-03040	
	6	NUT (M10)	4	ACXH56-01360	
	7	TUBE CONNECTER	1	ACXT29-02570	
	8	PACKING	1	ACXB81-07070	
	9	NUT (M35)	1	ACXH56-01370	
⚠	10	PACKING	9	ACXB81-00010	
	11	RETAINING RING (12.7)	7	H581007	
	12	FOAMED POLYSTYRENE - BOTTOM	1	ACXG07-07690	
	13	U-SHAPED PLATE	3	ACXD62-02690	
	14	SCREW	3	H551029J	
	15	FOAMED POLYSTYRENE	3	ACXG07-07750	
⚠	16	TANK COMPLETE	1	ACXB56C01531	
	17	NON - COMBUSTIBLE FOAM	1	ACXG05-00560	
	18	CAP	1	H521306	
	19	FOAMED POLYSTYRENE	1	ACXG07-07700	
	20	FOAMED POLYSTYRENE	1	ACXG07-09260	
	21	FOAMED POLYSTYRENE	1	ACXG07-09270	
	22	FOAMED POLYSTYRENE - TOP	1	ACXG07-08350	
	23	PARTICULAR PIECE	2	D934023	
	24	STRAIGHT TUBE	2	T102044	
	25	NUT	4	H561116	
⚠	26	SENSOR - COMPLETE	1	ACXA50C20700	
	27	PLATE SPRING	2	H711010	
	28	FOAMED POLYSTYRENE	2	ACXG07-07740	
⚠	29	COCK - COMPLETE	1	ACXB65C00111	
	30	SOCKET	1	ACXT27-00090	
	31	SOCKET	1	ACXT27-00020	
⚠	32	VALVE BODY	1	ACXB62-00920	
	33	TUBE ASSY	1	ACXT00-77551	
	34	L-SHAPED PLATE - LEFT	1	ACXD60-05190	
	35	L-SHAPED PLATE - RIGHT	1	ACXD60-05200	
	36	SCREW	14	H551040J	
	37	CONNECTING BAR	1	ACXE26-02841	
	38	SCREW	57	H551217	
	39	U-SHAPED PLATE - LEFT	1	ACXD62-03070	
	40	U-SHAPED PLATE - RIGHT	1	ACXD62-03080	

SAFETY	REF. NO.	DESCRIPTION & NAME	QTY.	WH-ADC0316M9E81	REMARK
	41	L-SHAPED PLATE	2	ACXD60-04532	
	42	U-SHAPED PLATE	2	ACXD62-02721	
	43	FOAMED POLYSTYRENE	1	ACXG07-08360	
	44	FOAMED POLYSTYRENE	1	ACXG07-08400	
	45	TUBE ASSY INHOUSE	1	ACXT00-84190	
⚠	46	VALVE BODY - MOTORIZED 3 WAY	1	ACXB62-00092	
	47	L-SHAPED TUBE	1	ACXT20-15030	
	48	TUBE ASSY INHOUSE	1	ACXT00-84170	
⚠	49	SENSOR - COMPLETE	1	ACXA50C20841	
	50	PLATE SPRING	2	H711019	
⚠	51	PACKING	8	ACXB81-06910	
	52	RETAINING RING (25.4)	8	ACXH58-00370	
	53	RECEIVER	1	ACXB14-00840	
	54	TUBE ASSY	1	ACXT00-84400	
	55	PACKING	1	B811179	
	56	PACKING	1	ACXB81-07700	
	57	TUBE ASSY - COMPLETE	1	ACXT00C46860	
	58	SOCKET WITH FLANGE	2	ACXT28-01850	
	59	RETAINING RING (SPRING)	2	ACXH58-00080	
	60	TUBE ASSY - COMPLETE	1	ACXT00C46990	
	61	FOAMED POLYSTYRENE	1	ACXG07-08390	
	62	TUBE ASSY INHOUSE	1	ACXT00-84150	
	63	TUBE ASSY INHOUSE	1	ACXT00-84140	
	64	TUBE ASSY INHOUSE	1	ACXT00-84100	
	65	FOAMED POLYSTYRENE	1	ACXG07-08370	
	66	FOAMED POLYSTYRENE	1	ACXG07-08560	
⚠	67	HEATER ASSY	1	ACXA34K00620	
	68	SOUND PROOF MATERIAL	1	ACXG30-10530CZ	
⚠	69	THERMOSTAT	4	ACXA15-00260	
	70	U-SHAPED PIECE	1	D721031	
	71	MACHINE SCREW & WASHER ASS'Y	8	XYN3+C5FJ	
	72	LEAD WIRE - COMPLETE (CN-OLP1)	1	ACXA61C00990	
⚠	73	LEAD WIRE - COMPLETE (AC-L1)	1	ACXA61C01000	
⚠	74	LEAD WIRE - COMPLETE (HEAT-B)	1	ACXA61C01010	
⚠	75	LEAD WIRE - COMPLETE (HT-L2)	1	ACXA61C01020	
⚠	76	LEAD WIRE - COMPLETE (HEAT-HEAT3)	1	ACXA60C58550	
⚠	77	LEAD WIRE - COMPLETE (HT-L3)	1	ACXA61C01040	
⚠	78	LEAD WIRE - COMPLETE (HEAT-HEAT2)	1	ACXA61C05340	
	79	TERMINAL COVER	1	H171051	
	80	PACKING	1	B811177	

SAFETY	REF. NO.	DESCRIPTION & NAME	QTY.	WH-ADC0316M9E81	REMARK
	81	POLY - E. FOAM (FLAME PROOF)	1	EN5A15-40	
	82	LEAD WIRE - COMPLETE (HEAT-A)	3	ACXA61C01200	
	83	LEAD WIRE - COMPLETE (HT-L1)	1	ACXA61C01230	
	84	MACHINE SCREW & WASHER ASSY	6	XYN4DC8FJ	
	85	VALVE BODY - COMPLETE	1	ACXB62C01130	
	90	RETAINING RING (14-23)	1	H581038	
	91	CONNECTING BAR	1	ACXE26-03181	
	92	CONNECTING BAR	1	ACXE26-03170	
	93	PARTICULAR PLATE	1	ACXD90-30560	
	94	CONNECTING BAR	1	ACXE26-02880	
	95	FOAMED POLYSTYRENE	1	ACXG07-08610	
	96	FOAMED POLYSTYRENE	1	ACXG07-08620	
	97	FOAMED POLYSTYRENE	1	ACXG07-08380	
	98	FOAMED POLYSTYRENE	1	ACXG07-08600	
	99	ADH. POLY - E. FOAM	1	ACXG12-40850	
	100	CONTROL BOARD - COMPLETE	1	ACXH11C17161	
	101	ELECTRONIC CONTROLLER (MAIN)	1	ACXA74C20900	
	102	LEAD WIRE - COMPLETE (AC-L2)	1	ACXA61C01100	
	103	LEAD WIRE - COMPLETE (AC-L3)	1	ACXA61C01780	
	104	LEAD WIRE - COMPLETE (AC-N)	1	ACXA61C01120	
	105	LEAD WIRE - COMPLETE (AC-N2)	1	ACXA61C01130	
	106	LEAD WIRE - COMPLETE (CN-AC)	1	ACXA61C03550	
	107	LEAD WIRE - COMPLETE (CN-DATA)	1	ACXA61C01140	
	108	LEAD WIRE - COMPLETE (G01)	2	ACXA61C01150	
	109	HOLDER - P.S. CORD	1	H31103	
	110	HOLDER - P.S. CORD	1	H31042	
	111	TERMINAL BOARD ASSY	1	A28K1238	
	112	LEAD WIRE - COMPLETE (WIRE1)	1	ACXA61C01090	
	113	CIRCUIT BREAKER	1	ACXA18-00021	
	114	U-SHAPED PLATE	1	ACXD62-02950	
	115	U-SHAPED PIECE	1	ACXD72-00940	
	116	PARTICULAR PLATE	1	ACXD90-30350	
	117	CONTROL BOARD	1	ACXH10-10391	
	118	WASHER	2	H57094	
	119	MACHINE SCREW & WASHER ASSY	2	XTB3+8CFJ	
	120	SELF TAPPING SCREW	1	XTN4+20CFJ	
	121	SELF TAPPING SCREW	2	XTT4+12CFJ	
	122	SELF TAPPING SCREW	2	XTT4+16GFJ	
	123	SELF TAPPING SCREW	1	XTT4+8CFJ	
	124	CAUTION LABEL	1	ACXF75-14410	


SAFETY	REF. NO.	DESCRIPTION & NAME	QTY.	WH-ADC0316M9E81	REMARK
	125	SELF TAPPING SCREW	1	XTT4+8FFJ	
	126	INDICATION LABEL (L1)	1	ACXF71-35080	
	127	BOX SHAPED PLATE	1	ACXD66-04341	
⚠	128	TERMINAL BOARD ASSY	1	A28K1064J	
	129	INDICATION LABEL	1	ACXF71-31170	
	130	CONTROL BOARD COVER	1	ACXH13-09660	
⚠	131	LEAD WIRE - COMPLETE (CN-CNT2)	1	ACXA61C01190	
⚠	132	WIRING DIAGRAM	1	ACXF29-01020	
	133	INDICATION LABEL	1	ACXF71-35090	
⚠	134	CAUTION LABEL	1	ACXF75-15040	
	135	CABINET SIDE PLATE_R	1	ACXE04-14380A	
	136	CABINET REAR PLATE	1	ACXE02-03790	
	137	PACKING	2	ACXB81-00030	
	138	PACKING	2	ACXB81-00040	
	139	HANDLE	2	ACXE16-00300	
	140	SCREW	4	ACXH55-07220	
	141	CABINET TOP PLATE	1	ACXE03-05040	
	142	CIRCUIT CONNECTION LABEL	1	ACXF71-34610	
	143	SHOWER CONNECTION LABEL	1	ACXF71-34620	
⚠	144	NETWORK ADAPTOR	1	CZ-TAW1B	
⚠	145	REMOTE CONTROL SWITCH - COMPLETE	1	ACXA75C26380	
	146	LEAD WIRE - COMPLETE (REMOTE)	1	ACXA60C99510	
	147	BOX SHAPED PLATE (DECO)	1	ACXD66-03970	
	148	SELF TAPPING SCREW	2	XTB4+8CFJ	
	149	SELF TAPPING SCREW	4	XTB4+8FFJ	
	150	CABINET FRONT PLATE	1	ACXE06-05780A	
	151	RUBBER (DECO)	1	ACXB81-07400	
	152	DECORATION BASE ASSY (PANASONIC)	1	ACXE35K03630	
	153	DECORATION BASE ASSY (AQUAREA)	1	ACXE35K03640	
	154	QR CODE	1	ACXF71-03400	
	155	ACCESSORY - ADJUSTABLE FEET	1	H82C2112	
	156	ACCESSORY - DRAIN ELBOW	1	G87C900	
⚠	157	INSTALLATION INSTRUCTION COMPLETE	1	ACXF60C21520	
⚠	158	MODEL LABEL	1	ACXF87-54360	
⚠	159	NAME PLATE	1	ACXF09-11070	
	160	INDICATION LABEL (DATE)	1	ACXF70-70060	
⚠	161	INDICATION LABEL (FLAME)	1	F746943	
	162	BRACKET - UNIT MOUNTING COMPLETE	2	ACXD57C00450	
	163	POLY - E. FOAM	2	ACXE5A55-90	
	164	POLY - E. FOAM	4	ACXE25A25-55	

SAFETY	REF. NO.	DESCRIPTION & NAME	QTY.	WH-ADC0316M9E81	REMARK
	165	SHOCK ABSORBER	4	G713134	
	166	BAG (UNIT)	1	ACXG86-04782	
	167	C.C. CASE	1	ACXG50-61793	
	168	BASE BOARD - COMPLETE	1	ACXG62C02791	
	169	SHOCK ABSORBER (BOTTOM)	1	ACXG70-15201	
	170	CORRUGATED CARDBOARD (BOTTOM)	1	ACXG57-09491	
	171	TOP BOARD COMPLETE	1	ACXG60C00301	
	172	CORRUGATED CARDBOARD (TOP)	1	ACXG57-12321	
	173	SHOCK ABSORBER (TOP)	2	ACXG70-15211	


Note:

- All parts are supplied from PHVACCZ, Czech (Vendor Code: 00029407).
- "O" marked parts are recommended to be kept in stock.


21.2 Outdoor Unit



Note:
The above exploded view is for the purpose of parts disassembly and replacement.
The non-numbered parts are not kept as standard service parts.




Note:
 The above exploded view is for the purpose of parts disassembly and replacement.
 The non-numbered parts are not kept as standard service parts.




Note:


The above exploded view is for the purpose of parts disassembly and replacement. The non-numbered parts are not kept as standard service parts.




Note:
 The above exploded view is for the purpose of parts disassembly and replacement.
 The non-numbered parts are not kept as standard service parts.




DTL A





DTL B



DTL C




Note:
 The above exploded view is for the purpose of parts disassembly and replacement.
 The non-numbered parts are not kept as standard service parts.



Note:


The above exploded view is for the purpose of parts disassembly and replacement.
The non-numbered parts are not kept as standard service parts.




DTL G

Note:


The above exploded view is for the purpose of parts disassembly and replacement. The non-numbered parts are not kept as standard service parts.



DTL H




DTL I




DTL J

Note:

The above exploded view is for the purpose of parts disassembly and replacement.
The non-numbered parts are not kept as standard service parts.




DTL K




DTL L

Note:
 The above exploded view is for the purpose of parts disassembly and replacement.
 The non-numbered parts are not kept as standard service parts.




DTL M



DTL N

Note:



The above exploded view is for the purpose of parts disassembly and replacement.
 The non-numbered parts are not kept as standard service parts.



DTL O

Note:


The above exploded view is for the purpose of parts disassembly and replacement. The non-numbered parts are not kept as standard service parts.



DTL P

Note:

The above exploded view is for the purpose of parts disassembly and replacement.
The non-numbered parts are not kept as standard service parts.



Note:
 The above exploded view is for the purpose of parts disassembly and replacement.
 The non-numbered parts are not kept as standard service parts.

SAFETY	REF. NO.	DESCRIPTION & NAME	QTY.	WH-WXG09ME8	WH-WXG12ME8	WH-WXG16ME8	REMARK
	1	BASE PAN - COMPLETE	1	ACXD52C01870	←	←	
	2	BASE PAN ASSY	1	ACXD52K05580	←	←	
	3	CONVEX PIECE	2	ACXD75-00710	←	←	
	4	SCREW	6	H551040J	←	←	
	5	PACKING	4	B811017	←	←	
	6	ANTI - VIBRATION BUSHING	4	ACXH50-00480	←	←	
	7	FLAT PLATE	1	ACXD64-01770	←	←	
	8	SCREW	4	ACXH55-08360	←	←	
	9	NUT	4	H561049	←	←	
	10	PACKING	4	ACXB81-07660	←	←	
	11	ANTI - VIBRATION BUSHING	4	H501113	←	←	
	12	COMPRESSOR	1	ACXB09-09930	←	←	O
	13	CONNECTING BAR ASSY	1	ACXE26K00011A	←	←	
	14	SCREW	4	H551040J	←	←	
	15	NUT	4	H561049	←	←	
	16	FIN & TUBE CONDENSER COMPLETE (U & L)	1	ACXB32C29731	←	ACXB32C28551	O
	17	MANIFOLD TUBE ASSY	1	ACXT07K11430	←	ACXT07K11420	
	18	SCREW	2	ACXH55-07140	←	←	
	19	SOUND - PROOF BOARD	1	ACXH15-04300	←	←	
	20	SOUND PROOF MATERIAL	1	ACXG30-14870	←	←	
	21	PACKING	1	ACXB81-00030	←	←	
	22	CAP	1	H521180	←	←	
	23	EPT SEAL	1	ACXD3A15-440	←	←	
	24	POLY - E. FOAM	1	ACXE5A45-80	←	←	
	25	SCREW	3	ACXH55-07140	←	←	
	26	FIXED INDUCTORS	3	G0C392J00060	←	←	
	27	SCREW	12	ACXH55-07140	←	←	
	28	4-WAYS VALVE COMPLETE	1	ACXB00C03631	←	←	O
	29	4-WAYS VALVE	1	ACXB00-01530	←	←	O
	30	STRAIGHT TUBE	1	T102044	←	←	
	31	PRESSURE SWITCH	1	ACXA10-00710	←	←	O
	32	2-WAYS VALVE	1	ACXB02-04110	←	←	O
	33	STRAINER	1	B111032	←	←	
	34	HIGH PRESSURE SENSOR	1	ACXA50-06870	←	←	O
	35	TUBE ASSY	1	ACXT00-87530	←	←	
	36	2-WAYS VALVE	1	ACXB02-03960	←	←	O
	37	TUBE ASSY	1	ACXT00-87710	←	ACXT00-87540	
	38	EXPANSION VALVE (SUB EXP. VALVE)	1	ACXB05-01580	←	←	O
	39	2-WAYS VALVE	1	ACXB02-04110	←	←	O
	40	STRAINER	1	B111032	←	←	

SAFETY	REF. NO.	DESCRIPTION & NAME	QTY.	WH-WXG09ME8	WH-WXG12ME8	WH-WXG16ME8	REMARK
	41	EXPANSION VALVE (MAIN EXP. VALVE)	1	ACXB05-01570	←	←	O
	42	STRAINER	2	B111032	←	←	
	43	SOUND PROOF MATERIAL - COMP. BODY	1	ACXG30-14830	←	←	
	44	SOUND PROOF MATERIAL - COMP. TOP	1	ACXG30-14840	←	←	
	45	SOUND - PROOF BOARD	1	ACXH15-04310	←	←	
	46	L-PIECE	1	ACXD70-02530	←	←	
	47	PARTICULAR PLATE	1	ACXD90-30940	←	←	
	48	FOAMED POLYSTYRENE	1	ACXG07-08650	←	ACXG07-08660	
⚠	49	HOT WATER COIL - COMPLETE	1	ACXB90C02140	←	ACXB90C02130	
	50	PARTICULAR PLATE	2	ACXD90-30950	←	←	
	51	ADH. POLY - E. FOAM	1	ACXG12-42390	←	ACXE2A40-140	
	52	BUSHING	2	ACXH51-01760	←	←	
	53	SCREW	4	ACXH55-07140	←	←	
	54	BAND	4	4605008	←	←	
	55	POLY - E. FOAM	1	ACXE15A25-60	←	←	
	56	HOLDER - COUPLING	1	ACXH35-02360	←	←	
	57	TUBE CONNECTER	2	ACXT29-01030	←	←	
	58	CAP	1	ACXH52-03610	←	←	
	59	TOOTHED LOCK WASHER	4	XWC5BV	←	←	
	60	SCREW	4	H551049J	←	←	
	61	PLUG	2	B821027	←	←	
⚠	62	PACKING	2	ACXB81-06770	←	←	
	63	PACKING	2	ACXB81-06910	←	←	
	64	SCREW	2	ACXH55-07140	←	←	
	65	FILTER COMPLETE	1	ACXB51C00110	←	←	O
	66	PLUG	1	ACXB82-00840	←	←	
⚠	67	PACKING	1	ACXB81-06810	←	←	
	68	RETAINING RING (14-23)	1	H581038	←	←	
	69	PACKING	1	ACXB81-06910	←	←	
	70	RETAINING RING (25.4)	1	ACXH58-00370	←	←	
⚠	71	PUMP	1	ACXB53-01000	←	←	O
	72	PARTICULAR PLATE	1	ACXD90-30970	←	←	
	73	SELF TAPPING SCREW	2	XTT4+16CFJ	←	←	
	74	SCREW	2	ACXH55-07140	←	←	
	75	U-SHAPED TUBE - COMPLETE	1	ACXT23C00180	←	ACXT00C49270	
	76	L-SHAPED TUBE	1	ACXT20-13860	←	-	
	77	L-SHAPED TUBE	1	ACXT20-14150	←	-	
	78	PACKING	1	ACXB81-06910	←	-	
	79	RETAINING RING (25.4)	1	ACXH58-00370	←	-	
	80	PACKING	2	ACXB81-06910	←	←	

SAFETY	REF. NO.	DESCRIPTION & NAME	QTY.	WH-WXG09ME8	WH-WXG12ME8	WH-WXG16ME8	REMARK
	81	RETAINING RING (25.4)	2	ACXH58-00370	←	←	
	82	L-SHAPED TUBE	1	ACXT20-15030	←	ACXT20-15330	
	83	PACKING	2	ACXB81-06910	←	←	
	84	RETAINING RING (25.4)	2	ACXH58-00370	←	←	
	85	FILTER COMPLETE	1	ACXB51C00160	←	←	O
	86	TUBE ASSY COMPLETE INHOUSE	1	ACXT00C49260	←	ACXT00C49250	
	87	PACKING	2	ACXB81-06910	←	ACXB81-06900	
⚠	88	PACKING	1	ACXB81-06820	←	←	
	89	RETAINING RING (25.4)	2	ACXH58-00370	←	←	
⚠	90	FLOW SENSOR (VALVE BODY)	1	ACXB62-00912	←	←	O
⚠	91	LEAD WIRE - COMPLETE (FLOW SENSOR)	1	ACXA61C04000	←	←	O
	92	U-SHAPED TUBE - COMPLETE	1	ACXT23C00170	←	←	
	93	PACKING	1	ACXB81-06910	←	←	
	94	RETAINING RING (25.4)	1	ACXH58-00370	←	←	
	95	PACKING	1	ACXB81-06910	←	←	
	96	RETAINING RING (25.4)	3	ACXH58-00370	←	←	
	97	PARTICULAR PLATE	1	ACXD90-31030	←	←	
	98	SCREW	1	ACXH55-07140	←	←	
⚠	99	VALVE BODY (PRESSURE RELIEF VALVE)	1	ACXB62-01320	←	←	O
	100	RETAINING RING (14-23)	1	H581038	←	←	
	101	TUBE ASSY	1	ACXT00-85820	←	←	
	102	STRAIGHT TUBE	1	ACXT10-21230	←	←	
⚠	103	PACKING	1	ACXB81-06820	←	←	
	104	RETAINING RING (14-23)	1	H581038	←	←	
⚠	105	SENSOR - COMPLETE (WATER PRESSURE SENSOR CN-DPS)	1	ACXA50C20090	←	←	O
⚠	106	PACKING	1	ACXB81-06790	←	←	
	107	SCREW	2	H55406J	←	←	
⚠	108	SENSOR - COMPLETE (WATER OUTLET SENSOR 2 & WATER INLET TEMP. SENSOR CN-TH3)	1	ACXA50C20630	←	←	O
⚠	109	PACKING	2	ACXB81-06780	←	←	
	110	SELF TAPPING SCREW	2	XTT4+8CFJ	←	←	
	111	SCREW	2	ACXH55-07140	←	←	
	112	PARTICULAR PLATE	1	ACXD90-30930	←	←	
⚠	113	TERMINAL BOARD ASSY	2	ACXA28K02540	←	←	O
	114	SELF TAPPING SCREW	2	XTN4+16CFJ	←	←	
	115	INDICATION LABEL (TERMINAL)	1	ACXF71-34380	←	←	
⚠	116	LEAD WIRE - COMPLETE (OUTDOOR UNIT STAND ALONE CONNECTION)	1	ACXA61C00650	←	←	O
	117	SCREW	2	ACXH55-07140	←	←	
	118	PARTICULAR PLATE	1	ACXD90-30960	←	←	

SAFETY	REF. NO.	DESCRIPTION & NAME	QTY.	WH-WXG09ME8	WH-WXG12ME8	WH-WXG16ME8	REMARK
	119	SCREW	1	ACXH55-07140	←	←	
	120	SCREW	2	ACXH55-07140	←	←	
	121	SCREW	2	H55440J	←	←	
	122	SCREW	4	H55406J	←	←	
	123	RUBBER	1	G251015	←	←	
⚠	124	V-COIL COMPLETE (4-WAY VALVE)	1	ACXA43C08090	←	←	O
	125	SCREW	1	H55082J	←	←	
⚠	126	V-COIL COMPLETE (MAIN EXP. VALVE CN-EV)	1	ACXA43C08100	←	←	O
⚠	127	V-COIL COMPLETE (BYPASS EXP. VALVE CN-INJ)	1	ACXA43C08110	←	←	O
⚠	128	V-COIL COMPLETE (DIS/INLET BYPASS 2-WAY VALVE)	1	ACXA43C08120	←	←	O
⚠	129	V-COIL COMPLETE (INJECTION 2-WAY VALVE)	1	ACXA43C08130	←	←	O
	130	SCREW	2	H55082J	←	←	
	131	RUBBER	3	ACXG25-02300	←	←	
	132	RUBBER	2	G251015	←	←	
	133	RUBBER	1	G251021	←	←	
	134	HOSE BAND	1	4090023	←	←	
⚠	135	SENSOR - COMPLETE (OUTDOOR DISCHARGE TEMP SENSOR CN-TH1)	1	ACXA50C20620	←	←	O
⚠	136	SENSOR - COMPLETE (OUTDOOR AMBIENT TEMP. SENSOR CN-TH1)	1	ACXA50C19550	←	←	O
⚠	137	SENSOR - COMPLETE (OUTDOOR HEAT EXCHANGER MIDDLE TEMP. SENSOR CN-TH1)	1	ACXA50C19710	←	←	O
⚠	138	SENSOR - COMPLETE (BYPASS OUTLET TEMP. SENSOR & EVAP. OUTLET TEMP. SENSOR CN-TH2)	1	ACXA50C19570	←	←	O
⚠	139	SENSOR - COMPLETE (ECONOMIZER OUTLET TEMP. SENSOR CN-TH2)	1	ACXA50C19560	←	←	O
⚠	140	SENSOR - COMPLETE (REFRIGERANT TEMP. SENSOR CN-TH3)	1	ACXA50C19720	←	←	O
	141	PLATE SPRING	8	H711010	←	←	
	142	FAN MOTOR BRACKET	2	ACXD54-05180	←	←	O
	143	SCREW	18	H551040J	←	←	
	144	SCREW	2	H551040J	←	←	
⚠	145	DC MOTORS (UPPER)	1	L6CBYYL0475	←	←	O
⚠	146	DC MOTORS (LOWER)	1	L6CBYYL0476	←	←	O
	147	SCREW	8	H551455	←	←	
	148	FAN ASSY	2	ACXH03K01200	←	←	
	149	WASHER	2	H571075A	←	←	
	150	NUT	2	H561112A	←	←	
	151	CONTROL BOARD ASSY	1	ACXH10K03210A	←	←	
⚠	152	ELECTRONIC CONTROLLER - COMPLETE	1	ACXA74C07610	ACXA74C07620	ACXA74C07630	O
	153	PACKING	1	ACXB81-07211	←	←	

SAFETY	REF. NO.	DESCRIPTION & NAME	QTY.	WH-WXG09ME8	WH-WXG12ME8	WH-WXG16ME8	REMARK
	154	SCREW	31	H551198	←	←	
⚠	155	LEAD WIRE - COMPLETE (COMPRESSOR)	1	ACXA61C00660	←	←	O
	156	MACHINE SCREW & WASHER ASSY	3	XYN4+F10FJ	←	←	
	157	FIXED INDUCTORS	1	G0C103Z00006	←	←	
⚠	160	CIRCUIT BREAKER	1	ACXA18-00021	←	←	O
	161	SELF TAPPING SCREW	2	XTT4+10CFJ	←	←	
	162	MACHINE SCREW & WASHER ASSY	2	XYN5DC10FJ	←	←	
⚠	163	TERMINAL BOARD ASSY	1	A28K1294	←	←	O
	164	SELF TAPPING SCREW	1	XTN4+20CFJ	←	←	
	165	HOLDER - P.S. CORD	1	ACXH31-01640	←	ACXH31-01480	
	166	HOLDER - P.S. CORD	1	ACXH31-01620	←	←	
	167	HOLDER - P.S. CORD	1	ACXH31-01630	←	←	
	169	PACKING BOX SHAPE PLATE	1	ACXB81-07670	←	←	
	170	SELF TAPPING SCREW	6	XTT4+12CFJ	←	←	
⚠	171	ELECTRONIC CONTROLLER (SUB)	1	ACXA74C07640	←	←	O
	172	CONTROL BOARD/SUB	1	ACXH10-10570	←	←	
	173	SCREW	4	XTB3+8CFJ	←	←	
	174	SELF TAPPING SCREW	2	XTT4+10CFJ	←	←	
	176	CONTROL BOARD/NF	1	ACXH10-10560	←	←	
	177	SCREW	6	XTB3+8CFJ	←	←	
	178	SELF TAPPING SCREW	2	XTT4+10CFJ	←	←	
	179	PACKING	1	ACXB81-07680	←	←	
	181	SCREW	1	H551040J	←	←	
⚠	183	LEAD WIRE - COMPLETE (L1-IN, L2-IN, L3-IN, N-IN)	1	ACXA61C00670	←	←	O
	184	HOSE BAND	1	4090023	←	←	
	185	CONTROL BOARD COVER - COMPLETE	1	ACXH13C06720	←	←	
	186	PACKING	1	ACXB81-07690	←	←	
	188	HOLDER - P.S. CORD	1	ACXH31-01650	←	←	
	189	SCREW	3	ACXH55-00120	←	←	
	190	CONTROL BOARD COVER - COMPLETE	1	ACXH13C06650	←	←	
	191	PACKING	1	ACXB81-07650	←	←	
	192	MACHINE SCREW & WASHER ASSY	4	XYN4+F10FJ	←	←	
	193	HOLDER - SENSOR	1	ACXH32-01480	←	←	
	194	SOUND PROOF MATERIAL	1	ACXG30-14880	←	←	
	195	CABINET SIDE PLATE - COMPLETE (R)	1	ACXE04C09050	←	←	
	196	HANDLE	1	ACXE16-00230G	←	←	
	197	EPT SEAL	1	ACXD3A10-92	←	←	
	198	SCREW	1	ACXH55-07980	←	←	
	199	CAP (CABINET SIDE PLATE)	6	ACXH52-04230G	←	←	

SAFETY	REF. NO.	DESCRIPTION & NAME	QTY.	WH-WXG09ME8	WH-WXG12ME8	WH-WXG16ME8	REMARK
	200	SCREW	15	ACXH55-07980	←	←	
	201	SCREW	2	ACXH55-07140	←	←	
	202	CABINET FRONT PLATE (L)	1	ACXE06-05620	←	←	
	203	HANDLE	1	ACXE16-00230G	←	←	
	204	EPT SEAL	1	ACXD3A10-92	←	←	
	205	SCREW	1	ACXH55-07980	←	←	
	206	SCREW	7	ACXH55-07980	←	←	
	207	SCREW	5	ACXH55-07140	←	←	
	208	CABINET SIDE PLATE (L)	1	ACXE04-13910	←	←	
	209	PARTICULAR PLATE	1	ACXD90-29140	←	←	
	210	SCREW	3	ACXH55-07740	←	←	
	211	CABINET TOP PLATE - COMPLETE	1	ACXE03C02510	←	←	
	212	SCREW	9	ACXH55-07980	←	←	
	213	CABINET FRONT PLATE (R)	1	ACXE06-05630	←	←	
	214	PARTICULAR PIECE	4	ACXD93-25230	←	←	
	215	NUT	4	ACXH56-00120	←	←	
	216	HANDLE	1	ACXE16-00230G	←	←	
	217	EPT SEAL	1	ACXD3A10-92	←	←	
	218	SCREW	1	ACXH55-07980	←	←	
	219	SCREW	8	ACXH55-07740	←	←	
	220	SOUND PROOF MATERIAL	1	ACXG30-14860	←	←	
	221	SCREW	9	ACXH55-07980	←	←	
	222	ACCESSORY - COMPLETE	1	ACXH82C29860	←	←	
	223	CAP (OR PART ACXH52-01980)	3	ACXH52-04310	←	←	
	224	DRAIN NOZZLE	1	ACXH41-00700	←	←	
	225	SCREW	8	H551198	←	←	
	226	CAP (ACCESSORY - COMPLETE CAP)	15	ACXH52-04470	←	←	
	227	INDICATION LABEL (OUT)	1	ACXF71-25700	←	←	
	228	INDICATION LABEL (IN)	1	ACXF71-25710	←	←	
	229	CAUTION LABEL (CONTROL BOARD COVER)	1	ACXF71-34831	←	←	
	230	OPERATING INSTRUCTION - COMPLETE	1	ACXF55C30530	←	←	O
	231	INSTALLATION INSTRUCTION COMPLETE	1	ACXF60C20620	←	←	O
	232	MODEL LABEL	1	ACXF87-30900	ACXF87-30910	ACXF87-30920	
	233	DISCHARGE GRILLE - COMPLETE (R TOP)	1	ACXE20C09371	←	←	
	234	DISCHARGE GRILLE - COMPLETE (L BOTTOM)	1	ACXE20C09380	←	←	
	235	DISCHARGE GRILLE - COMPLETE (L TOP)	1	ACXE20C09390	←	←	
	236	DISCHARGE GRILLE - COMPLETE (R BOTTOM)	1	ACXE20C09400	←	←	
	237	BAG	1	ACXG86-06800	←	←	

SAFETY	REF. NO.	DESCRIPTION & NAME	QTY.	WH-WXG09ME8	WH-WXG12ME8	WH-WXG16ME8	REMARK
	238	BASE - BOARD COMPLETE	1	ACXG62C03020	←	←	
	239	SHOCK ABSORBER (MIDDLE LEFT)	1	ACXG70-16300	←	←	
	240	SHOCK ABSORBER (MIDDLE)	1	ACXG70-16310	←	←	
	241	SHOCK ABSORBER (MIDDLE RIGHT)	1	ACXG70-16320	←	←	
	242	SHOCK ABSORBER (UPPER LEFT)	1	ACXG70-15320	←	←	
	243	SHOCK ABSORBER (UPPER RIGHT)	1	ACXG70-15330	←	←	
	244	CORRUGATED CARDBOARD	2	ACXG57-13710	←	←	
	245	C.C. CASE	1	ACXG50-64400	←	←	O
	246	CONTROL BOARD ASSY	1	ACXH10K03540	←	←	
	247	ELECTRONIC CONTROLLER - COMPLETE	1	ACXA74C10550	←	←	O
	248	BOX SHAPED PLATE - COMPLETE	1	ACXD66C00840	←	←	
	249	CONTROL BOARD ASSY	1	ACXH10K03560	←	←	

Note:

- All parts are supplied from PHVACCZ, Czech (Vendor Code: 00029407).
- "O" marked parts are recommended to be kept in stock.